

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Brandt](#) /
- › [Brandt Built-in Multifunction Electric Oven FE901XD User Manual](#)

Brandt FE901XD

Brandt Built-in Multifunction Electric Oven FE901XD User Manual

Model: FE901XD | Brand: Brandt

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Brandt Built-in Multifunction Electric Oven, model FE901XD. Please read these instructions carefully before installation, operation, or maintenance, and keep them for future reference.

The Brandt FE901XD is a built-in electric oven featuring mechanical controls, a sleek black glass and stainless steel front panel, and a generous net capacity of 60 liters. It offers 6 distinct cooking programs and boasts an energy efficiency class of A.



Image: Front view of the Brandt Built-in Multifunction Electric Oven FE901XD, showcasing its black glass and stainless steel design.

SAFETY INSTRUCTIONS

Important: Read all safety warnings and instructions before using this appliance to prevent electric shock, fire, injury, or property damage.

- Ensure the oven is properly installed and grounded by a qualified technician.
- Do not touch hot surfaces. Use oven mitts or pot holders.
- Never use water to extinguish grease fires. Smother the fire or use a dry chemical or foam-type extinguisher.
- Keep children away from the oven during operation and when it is cooling down.
- Do not store flammable materials in or near the oven.
- Always unplug the oven from the power supply before cleaning or performing maintenance.
- Do not obstruct ventilation openings.
- Use only accessories recommended by the manufacturer.

SETUP AND INSTALLATION

This oven is designed for built-in installation, typically as a wall-mounted unit. Professional installation is highly recommended to ensure proper electrical connection and secure mounting.

Unpacking

- Carefully remove all packaging materials from the oven and its accessories.
- Inspect the oven for any signs of damage during transit. Contact your retailer immediately if damage is found.
- Keep packaging materials out of reach of children.

Electrical Connection

- Ensure the electrical supply matches the voltage and frequency specified on the rating plate (220 Volts, 50 Hz).
- The oven must be properly grounded.
- Do not use extension cords or adapters.

Mounting

- Prepare the cabinet opening according to the dimensions provided in the installation template (refer to separate installation guide if provided).
- Secure the oven into the cabinet using the provided screws and brackets. Ensure it is level and stable.
- Allow adequate ventilation space around the oven as specified in the installation instructions.

OPERATING INSTRUCTIONS

Your Brandt FE901XD oven features mechanical controls for selecting cooking programs, temperature, and timer functions.

Control Panel Overview

The front panel consists of control knobs for function selection, temperature setting, and timer activation.

Cooking Programs

The oven offers 6 cooking programs. Rotate the function selector knob to choose the desired program. Common programs may include:

- **Conventional Heating:** For general baking and roasting.
- **Convection (Fan-assisted) Heating:** For even cooking and faster results, ideal for multiple dishes.
- **Grill:** For browning and toasting.
- **Bottom Heating:** For crisping bases.
- **Defrost:** Gentle thawing of frozen foods.
- **Eco Mode:** Energy-saving cooking.

Temperature Setting

After selecting a program, rotate the temperature knob to set the desired cooking temperature.

Timer Function

The oven includes a timer function. Rotate the timer knob to set the cooking duration. The oven will automatically switch off or signal when the set time has elapsed.

Internal Lighting

The interior lights can be activated to monitor cooking progress without opening the oven door.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your oven.

General Cleaning

- Always ensure the oven is cool and unplugged before cleaning.
- Clean the interior with a damp cloth and mild detergent. Avoid abrasive cleaners or scouring pads.
- The black glass and stainless steel exterior can be cleaned with a soft cloth and a non-abrasive cleaner suitable for these materials.
- Remove and clean oven racks and accessories separately in warm soapy water.

Self-Cleaning Feature

This oven is equipped with a self-cleaning function. Refer to the detailed instructions in the full product manual for proper use of this feature. Ensure all racks and large food debris are removed before initiating a self-clean cycle.

TROUBLESHOOTING

If you encounter issues with your oven, consult the following common troubleshooting steps before contacting service.

Problem	Possible Cause	Solution
Oven does not heat up.	No power supply; incorrect program/temperature setting; faulty element.	Check power connection and circuit breaker. Ensure program and temperature are set correctly. If problem persists, contact service.
Timer not working.	Timer not set correctly; power interruption.	Ensure timer knob is properly engaged and set. Reset power if necessary.
Uneven cooking.	Incorrect rack position; overloaded oven; door not sealed properly.	Refer to cooking guidelines for rack positions. Avoid overcrowding. Check door seal for damage.

For problems not listed here or if solutions do not resolve the issue, please contact customer support.

SPECIFICATIONS

Brand Name	Brandt
Model Number	FE901XD
Product Type	Oven
Color	Silver/Black
Heating Method	Convection
Finish Type	Polished
Fuel Type	Electric
Installation Type	Wall Mount

Wattage	1200 Watts
Product Dimensions (D x W x H)	60 cm x 60 cm x 60 cm
Item Weight	20 Kilograms
Special Features	Interior Lights, Self-cleaning, Timer
Timer Function	Available
Voltage	220 Volts
Capacity	60 Liters
Energy Efficiency Class	A

WARRANTY AND SUPPORT

Warranty Information

This Brandt FE901XD oven comes with an International Warranty. Please refer to the warranty card included with your product for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, spare parts, or warranty service, please contact Brandt customer support. Contact details can typically be found on the manufacturer's website or in the documentation provided with your appliance.

Online Resources: Visit the official Brandt website for FAQs, additional manuals, and support contact information.