

WE-VIBE Sync Go

WE-VIBE Sync Go Couples Vibrator Instruction Manual

Model: Sync Go

INTRODUCTION

Thank you for choosing the WE-VIBE Sync Go Couples Vibrator. This manual provides essential information for the safe and effective use, care, and maintenance of your device. Please read it thoroughly before first use and retain it for future reference.

PRODUCT OVERVIEW

The WE-VIBE Sync Go is a wearable couples vibrator designed for shared experiences. It features an ergonomic shape with vibrating inner and outer arms for dual stimulation, targeting both the clitoris and G-spot. The device is app-controlled, rechargeable, waterproof, and made from body-safe silicone.



Image: The Sync Go device shown with its companion mobile application.



Image: Overview of Sync Go features including dual stimulation, app control, travel case, rechargeability, and waterproof design.

SETUP

1. Unboxing and Initial Inspection

Carefully remove the Sync Go from its packaging. Inspect the device for any visible damage. The package should contain the Sync Go device, a USB charging cable, and a travel case.



Image: Contents of the Sync Go package.

2. Initial Charge

Before first use, fully charge your Sync Go. Connect the USB charging cable to the device and a compatible USB power source. A full charge provides up to 90 minutes of playtime.



Rechargeable



Simply charge Sync Go via USB cable – your toy provides up to 90 minutes of play on one full 90-minute charge.

Image: Sync Go connected to its USB charging cable.

3. Cleaning Before First Use

Clean the device thoroughly with warm water and a mild soap or a specialized toy cleaner before its initial use. Rinse well and pat dry with a lint-free cloth.

4. App Download and Pairing

1. Download the free We-Vibe App from your smartphone's app store.
2. Ensure your Sync Go is charged and turned on.
3. Open the We-Vibe App and follow the on-screen instructions to pair your device via Bluetooth.

OPERATING INSTRUCTIONS

1. Basic On/Off and Control

The Sync Go can be operated using its single button or through the We-Vibe App. Press and hold the power button on the device to turn it on or off. Short presses will cycle through vibration patterns or intensities.



App & Single-button Controls



Use the simple button on the toy or play together with the We-Vibe app to explore more options.

Image: Sync Go with app control interface.

2. App Control

For advanced control and customization, use the We-Vibe App. The app allows you to:

- Adjust intensity levels.
- Explore various vibration patterns.
- Create custom patterns.
- Control the device over long distances.

3. Usage and Lubrication


For optimal comfort and experience, always use the Sync Go with a water-based lubricant. Apply a small amount of lubricant to the device before insertion.



Image: Visual guide for using the Sync Go.

4. Dual Stimulation

The Sync Go is designed to provide simultaneous clitoral and G-spot stimulation through its inner and outer arms. Position the device to maximize comfort and pleasure for both partners.



Dual Stimulation

Vibrating inner and outer arms provide clitoral & G-Spot stimulation.



Image: Illustration of the dual stimulation design.

MAINTENANCE AND CARE

1. Cleaning After Use

The Sync Go is fully waterproof (IPX7 rated), making it easy to clean. After each use, wash the device with warm water and a mild soap or a specialized toy cleaner. Rinse thoroughly and pat dry with a lint-free cloth. Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone.



Waterproof



Sync Go is waterproof (IPX7), making it safe in the shower and simple to clean.

Image: Sync Go shown in a bathroom, highlighting its waterproof feature.

2. Storage

Store your Sync Go in its provided travel case in a clean, dry place away from direct sunlight and extreme temperatures. Avoid storing it with other toys made of different materials, especially those containing phthalates, as this can cause damage to the silicone.



Travel Case



Sync Go comes in a convenient travel case to discreetly protect your toy.

Image: Sync Go with its discreet travel case.

TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Connect it to the USB charging cable and allow it to charge for at least 90 minutes.
- **App connectivity issues:** Make sure Bluetooth is enabled on your smartphone and the Sync Go is turned on and within range. Try restarting both the device and the app. If issues persist, try unpairing and re-pairing the device in the app settings.
- **Weak or inconsistent vibrations:** A low battery can cause reduced performance. Fully charge the device. If the issue persists after charging, contact customer support.
- **Device not responding to button presses:** Ensure the device is not in a locked mode (if applicable, check app settings). If unresponsive, try a full charge.

If you encounter problems not listed here or if troubleshooting steps do not resolve the issue, please refer to the support section.

SPECIFICATIONS

Feature	Detail
---------	--------

Model Name	Sync Go
Brand	WE-VIBE
Material	Silicone
Color	Blue (as per current variant)
Product Dimensions	3.54 x 3.54 x 1.85 inches
Weight	6.77 ounces
Battery	1 Lithium Ion battery (included)
Playtime	Up to 90 minutes (on full charge)
Waterproof Rating	IPX7
Manufacturer	WOW Tech

OFFICIAL PRODUCT VIDEOS

No relevant official product videos from the seller were found for embedding in this manual.

WARRANTY AND SUPPORT


Warranty Information






For detailed warranty information, please refer to the official WE-VIBE website or the documentation included with your product. Warranty terms typically cover manufacturing defects.

Customer Support

If you require further assistance, have questions about your Sync Go, or need to report an issue, please visit the official WE-VIBE support page or contact their customer service directly. Contact details are usually available on the manufacturer's website.

Related Documents - Sync Go

	<p>We-Vibe Sync™: User Guide and Product Information</p> <p>Comprehensive guide for the We-Vibe Sync™ couples vibrator, including setup, app connectivity, safety warnings, warranty, and compliance information. Features external and G-spot stimulation.</p>
---	---

	<p>We-Vibe Sync™ User Manual: Features, Operation, and Care</p> <p>Comprehensive user manual for the We-Vibe Sync™ personal massager, covering features, charging, operation, safety, app connectivity, and troubleshooting. Learn how to use your Sync for optimal pleasure.</p>
	<p>Thrill by We-Vibe User Manual: Dual Stimulation and Features</p> <p>Comprehensive user manual for the Thrill by We-Vibe, detailing its dual stimulation design, charging, operation, cleaning, troubleshooting, and warranty information.</p>
	<p>We-Vibe 4 Plus Vibrator for Couples: User Guide and Features</p> <p>Comprehensive guide to the We-Vibe 4 Plus, a couples vibrator designed for enhanced intimacy and pleasure. Learn about its features, app control, usage, charging, cleaning, and specifications.</p>
	<p>We-Vibe Sync User Manual</p> <p>Comprehensive guide to the We-Vibe Sync, covering features, usage, charging, pairing, and safety instructions. Learn how to maximize your experience with this advanced personal massager.</p>
	<p>We-Vibe Sync Lite: The Simple, Intuitive Couples Vibrator</p> <p>Discover the We-Vibe Sync Lite, an intuitive and simple couples vibrator designed for connection. Explore its features, how to use it, and what makes it a perfect choice for couples.</p>