Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOFTRONIC 5449758

HOFTRONIC Miles XL LED Outdoor Wall Light User Manual

Model: 5449758

Introduction

This manual provides essential information for the safe and effective installation, operation, and maintenance of your HOFTRONIC Miles XL LED Outdoor Wall Light. Please read this manual thoroughly before installation and retain it for future reference.



Figure 1: HOFTRONIC Miles XL LED Outdoor Wall Light in operation.

Safety Information

Always adhere to local electrical codes and regulations. Installation should be performed by a qualified electrician.

- Disconnect power before installation or servicing.
- Ensure the mounting surface can support the weight of the fixture.
- Do not modify the fixture.
- This product is rated IP65 for outdoor use, providing protection against dust and water jets.




Figure 2: The Miles XL light is designed for durability in various weather conditions, featuring an IP65 rating for protection against dust and water.

Product Overview

The HOFTRONIC Miles XL is a modern LED outdoor wall light designed for both aesthetic appeal and functional illumination. It features a robust aluminum construction with a powder coating for enhanced durability and rust resistance.

Key Features:

- **Adjustable Beam Angle:** The light beam can be continuously adjusted from 0 to 90 degrees, allowing for customized lighting effects.
- **High Luminous Output:** Provides 2000 lumens of warm white light (3000K) for effective illumination.
- **Durable Construction:** Made from maintenance-free aluminum with an AKZO Nobel powder coating, ensuring IP65 water and rust resistance.
- **Versatile Application:** Suitable for both indoor and outdoor use, including facades, entryways, and bathrooms.



Figure 3: The internal mechanism allows for precise adjustment of the light beam angle.



Figure 4: Examples of adjustable light beam patterns.

Setup (Installation)

Installation of the HOFTRONIC Miles XL LED Outdoor Wall Light should be carried out by a qualified professional to ensure safety and proper functionality.

Installation Steps:

1. **Preparation:** Ensure the power supply to the installation area is turned off at the main circuit breaker.
2. **Mounting:** Secure the mounting bracket (if separate) or the fixture's base directly to the desired wall surface using appropriate screws and anchors. Ensure the mounting is firm and stable.
3. **Wiring:** Connect the electrical wires from the wall to the fixture's terminals. Follow the wiring diagram provided with the product. Ensure all connections are secure and insulated.
4. **Fixture Attachment:** Carefully attach the main body of the light fixture to the mounted base, ensuring it is properly seated and secured.
5. **Power On:** Restore power to the circuit and test the light.



Figure 5: Rear view of the fixture showing the mounting plate and connection points.

Operating

The HOFTRONIC Miles XL LED Outdoor Wall Light is designed for simple operation once installed. Its primary adjustable feature is the beam angle.

Adjusting the Beam Angle:

The light features internal adjustable flaps that allow you to modify the upward and downward light beams. To adjust:

1. Carefully access the internal adjustable mechanisms. This may require removing the outer casing or accessing specific adjustment points.
2. Gently move the internal flaps to achieve the desired beam spread, from 0 degrees (narrow, focused beam) to 90 degrees (wide, diffused beam).
3. Test the light after adjustment to ensure the desired effect is achieved.



Figure 6: Internal view showing the adjustable beam mechanism.

Maintenance

The HOFTRONIC Miles XL LED Outdoor Wall Light requires minimal maintenance due to its durable construction and IP65 rating.

Cleaning:

- Ensure the power is off before cleaning.
- Wipe the exterior of the fixture with a soft, damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.

Inspection:

- Periodically inspect the fixture for any signs of damage, loose connections, or wear.
- If any damage is observed, disconnect power and contact a qualified electrician for repair or replacement.

Troubleshooting

If you encounter issues with your HOFTRONIC Miles XL LED Outdoor Wall Light, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Light does not turn on.	No power supply, loose wiring, faulty switch, or damaged fixture.	Check circuit breaker. Ensure all wiring connections are secure. Test the switch. If issues persist, consult a qualified electrician.
Light flickers.	Unstable power supply or loose connection.	Verify stable power. Check wiring connections.
Beam angle not adjusting.	Mechanism obstructed or damaged.	Inspect the internal flaps for obstructions. Do not force the mechanism.

For problems not listed above, or if solutions do not resolve the issue, please contact HOFTRONIC customer support.

Specifications

Attribute	Value
Brand	HOFTRONIC
Model Number	5449758
Dimensions (L x W x H)	230 x 120 x 100 mm
Weight	5 Kilograms
Material	Aluminum
Finish Type	Powder Coated
IP Rating	IP65
Power Consumption	20 Watts
Voltage	230 Volts
Luminous Flux	2000 Lumens
Color Temperature	3000 Kelvin (Warm White)
Average Life	30,000 Hours
Energy Efficiency Class	F




Figure 7: Energy Efficiency Label. For more details, scan the QR code or visit EPREL Database.

Warranty and Support

HOFTRONIC products are manufactured to high-quality standards. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

Customer Support:

For technical assistance, troubleshooting, or warranty inquiries, please contact HOFTRONIC customer support through their official website or the retailer where the product was purchased.
Manufacturer: HOFTRONIC

© 2025 HOFTRONIC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CNSHCCC2

More documents and user manuals: **https://manuals.plus/**