

[Manuals.plus](#) /

› [Asuwish](#) /

› Asuwish Phone Case Instruction Manual for Samsung Galaxy S20 5G

## Asuwish Samsung Galaxy S20 5G

# Asuwish Phone Case Instruction Manual for Samsung Galaxy S20 5G

Model: Samsung Galaxy S20 5G

## INTRODUCTION

---

This manual provides detailed instructions for the Asuwish Zipper Wallet Phone Case designed for the Samsung Galaxy S20 5G. This case offers comprehensive protection, convenient storage, and enhanced functionality for your device.

Key features include multiple card slots, a cash pocket, a secure zipper purse, RFID blocking technology, and compatibility with wireless charging. It also comes with detachable wrist and crossbody straps for versatile carrying options.

## COMPATIBILITY

---

This phone case is specifically designed for the **Samsung Galaxy S20 (6.2 inch)** and **Samsung Galaxy S20 5G (6.2 inch)** models only. It is not compatible with other Samsung Galaxy S20 series models such as the S20 Ultra (6.9 inch), S20 Plus (6.7 inch), or S20 FE (6.5 inch).

# Compatible with **Samsung S20 (4G&5G) only**




Image: Compatibility chart illustrating that the case fits only the Samsung Galaxy S20 (6.2 inch) model.

## PACKAGE CONTENTS

- 1 x Asuwish Zipper Wallet Phone Case for Samsung Galaxy S20 / S20 5G
- 1 x Tempered Glass Screen Protector
- 1 x Detachable Wrist Strap
- 1 x Detachable Crossbody Strap

## SETUP

### 1. Installing the Phone

1. Open the wallet case and locate the inner phone holder.
2. Carefully align your Samsung Galaxy S20 / S20 5G with the cutouts of the phone holder.
3. Gently press your phone into the holder until it is securely seated. Ensure all buttons and ports are accessible.

## 2. Attaching Straps

1. Locate the small metal rings on the top edge of the phone case.
2. Attach the desired strap (wrist or crossbody) by clipping its metal hook onto these rings.
3. The crossbody strap can be adjusted to your preferred length using the buckle.



Image: The phone case featuring both the detachable wrist strap and the adjustable crossbody strap.

## 3. Applying the Tempered Glass Screen Protector

1. Clean your phone screen thoroughly with the provided cleaning wipes (if included) to remove dust and smudges.
2. Carefully peel off the protective film from the adhesive side of the tempered glass.
3. Align the screen protector with your phone screen, ensuring it is centered and the cutouts match.
4. Gently lower the protector onto the screen. Press down lightly from the center outwards to adhere it, pushing out any air bubbles.

## OPERATING INSTRUCTIONS

## 1. Using Card Slots and Cash Pockets

The wallet case features 7 card slots and 1 cash slot. Insert your ID, credit cards, driver's license, and bills into the designated slots. The design allows for secure storage without adding excessive bulk.



## 2. Using the Zipper Pocket

A dedicated zipper purse is integrated into the case, providing a secure compartment for coins, keys, or other small essentials. Ensure the zipper is fully closed to prevent items from falling out.

# FOCUS ON THE DETAILS



Adjustable Clip



Smooth Zipper Pocket



Multi-card Design



Cash Pocket



Removable Hook

Image: Detailed view of the case, showing the smooth zipper pocket and other features.

### 3. Wireless Charging

The case is designed to be compatible with wireless charging. You do not need to remove your phone from the case to use a wireless charger. Simply place the cased phone onto a compatible wireless charging pad.

# MATCH YOUR NEEDS

Be your Crossbody Purse ▶

Be your Clutch Bag ▼



Be your Shoulder Bag ▲



Image: The phone case actively charging wirelessly on a charging pad.

## 4. RFID Blocking Function

The case incorporates RFID blocking materials to protect your credit cards, debit cards, ID cards, and other RFID-enabled cards from unauthorized scanning and electronic theft. This feature helps safeguard your personal information.

# RFID BLOCKING



Aiming to protect your personal information from being stolen




Image: Illustration of the RFID blocking material layers within the case.

## MAINTENANCE

To ensure the longevity and appearance of your Asuwish phone case, follow these maintenance guidelines:

- **Cleaning:** Wipe the faux leather surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive water, as these can damage the material.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight to prevent discoloration or material degradation.
- **Avoid Overstuffing:** While the case offers ample storage, avoid overstuffing card slots or the zipper pocket, as this can stretch the material and compromise the case's closure and protective qualities.

## TROUBLESHOOTING

### 1. Phone Does Not Fit

Ensure your phone model is indeed a Samsung Galaxy S20 or S20 5G (6.2 inch). This case is not compatible with other S20 variants like the S20 Ultra, S20 Plus, or S20 FE, which have different dimensions. Verify your phone's model number in its settings.

## 2. Difficulty with Snaps or Zipper

New cases may have slightly stiff snaps or zippers. With regular use, they should become smoother. If a zipper is stuck, gently try to move it back and forth. Avoid forcing it, as this can cause damage.

## 3. Wireless Charging Not Working

Ensure your wireless charger is compatible with your Samsung Galaxy S20 5G. Check that the phone is correctly centered on the charging pad. Remove any metal objects or very thick cards from the case's back before charging, as these can interfere with the wireless charging signal.

## SPECIFICATIONS

|                           |                                                    |
|---------------------------|----------------------------------------------------|
| Brand                     | Asuwish                                            |
| Compatible Phone Models   | Samsung Galaxy S20, Samsung Galaxy S20 5G          |
| Color                     | Green                                              |
| Material                  | Faux Leather                                       |
| Form Factor               | Flip                                               |
| Additional Features       | Lanyard, Card Holder, Zipper Pocket, RFID Blocking |
| Water Resistance Level    | Not Water Resistant                                |
| Screen Size Compatibility | 6.2 Inches                                         |
| Model Number              | Samsung Galaxy S20 5G                              |

## WARRANTY AND SUPPORT

Asuwish products are designed for quality and durability. While specific warranty details are not provided in this manual, standard return policies typically apply for products purchased through authorized retailers. For any issues, questions, or support needs regarding your Asuwish phone case, please contact the seller or the platform where the purchase was made.

Please refer to your purchase documentation or the retailer's website for detailed information on return periods and customer service contact options.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0CNSQW264>

More documents and user manuals: <https://manuals.plus/>