

[Manuals.plus](#) /

› [Singing Machine](#) /

› Singing Machine SingCast One Karaoke System User Manual

Singing Machine SMC2020

Singing Machine SingCast One Karaoke System User Manual

Model: SMC2020 | Brand: Singing Machine

INTRODUCTION

The Singing Machine SingCast One Karaoke System (SMC2020) is designed to elevate your karaoke experience with advanced features and easy connectivity. This system combines video-casting technology, synchronized LED lights, Bluetooth audio streaming, and echo effect control to provide an immersive and fun singing environment for all ages.

It includes a wireless microphone and an AC adapter, making it simple to set up and start enjoying your favorite tunes. With its versatile connectivity options and dynamic features, the SingCast One is perfect for any gathering or solo performance.



Figure 1: The SingCast One Karaoke System with its wireless microphone.

PACKAGE CONTENTS

- SingCast One Karaoke System (SMC2020)
- Wireless Microphone (batteries not included)
- AC Adapter

SETUP GUIDE

1. Power Connection

1. Connect the provided AC adapter to the DC IN jack on the SingCast One unit.
2. Plug the AC adapter into a standard 110V (AC) wall outlet.
3. Press the Power button to turn on the unit.

2. Microphone Setup

- Insert the required batteries (not included) into the wireless microphone.
- Turn on the wireless microphone. It will automatically pair with the SingCast One unit.
- Place the microphone in the rotatable microphone holder on the unit when not in use.

3. Device Placement & Connectivity

- Place your smartphone, tablet, or other smart device into the anti-slip device cradle on top of the unit.
- For Bluetooth audio streaming, enable Bluetooth on your smart device and select "SingCast One" from the list of available devices.
- Alternatively, use the Line-in option to connect external audio devices.
- To project lyrics and video onto your TV, connect an HDMI cable (not included) from the SingCast One's HDMI port to your TV's HDMI input.



Figure 2: Key features and connection points of the SingCast One.

OPERATING INSTRUCTIONS

1. Playing Music

- **Bluetooth Streaming:** Once paired, play music from your smart device. The audio will stream wirelessly to the SingCast One.
- **Line-in:** Connect an audio device to the Line-in port using an appropriate cable (not included) and play music directly.
- **SMC Karaoke App:** Download the official Singing Machine Karaoke App for access to a vast library of songs and family-friendly lyrics. Project content from the app to your TV via HDMI for a seamless experience.




Figure 3: Stream lyrics directly to your TV for an enhanced karaoke experience.


2. Using Microphone Effects

- **Echo Effects:** Use the dedicated controls on the unit to adjust the echo effect on your voice, adding a professional touch to your performance.
- **Lead Vocal Removal:** Activate the lead vocal removal technology to minimize original vocals from tracks, allowing you to sing along more clearly.

3. LED Light Show

- The SingCast One features dynamic LED lights that pulse and change colors to the beat of the music, creating an exciting party atmosphere.
- Controls on the unit allow you to manage the light show settings.

SINGING MACHINE'S SINGCAST ONE



Transform karaoke night with advanced technology like video casting, synchronized LED lights, Bluetooth audio streaming, echo effects, and more

Includes one wireless microphone

Figure 4: Transform your karaoke night with advanced technology and dynamic lighting.

MAINTENANCE

- Keep the unit clean by wiping it with a soft, dry cloth.
- Avoid using abrasive cleaners or solvents.
- Store the unit in a cool, dry place when not in use.
- Ensure proper ventilation around the unit during operation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No Power	AC adapter not connected or power outlet is faulty.	Ensure AC adapter is securely plugged into the unit and a working wall outlet.
No Sound from Speaker	Volume too low; incorrect input source selected; device not properly connected.	Increase volume on the unit and connected device. Verify correct input. Reconnect device.
Microphone Not Working	Microphone off; batteries low/dead; microphone not paired.	Ensure microphone is turned on. Replace batteries. Re-pair microphone if necessary (refer to microphone instructions).
Bluetooth Pairing Issues	Device too far; Bluetooth not enabled; incorrect device selected.	Move device closer to the unit. Ensure Bluetooth is enabled on your device. Select "SingCast One" from the Bluetooth list.
No Video on TV	HDMI cable not connected; incorrect TV input selected.	Ensure HDMI cable is securely connected to both unit and TV. Select the correct HDMI input on your TV.

SPECIFICATIONS

- **Model Number:** SMC2020
- **Item Weight:** 4.89 pounds
- **Product Dimensions:** 10.18 x 10.25 x 11.25 inches
- **Color:** Black
- **Compatible Devices:** Smartphone, Tablet, Personal Computer, Laptop
- **Connector Type:** HDMI
- **Speaker Count:** 1
- **Media Format:** Karaoke
- **Power Source:** Battery Powered (for microphone), 110 Volts (AC) for unit
- **Special Feature:** Echo Effect, Video Casting Technology, Bluetooth, LED Light Show, Lead Vocal Removal
- **Included Components:** Karaoke System, Wireless Microphone, AC Adapter

WARRANTY & SUPPORT

Singing Machine is a leading provider of consumer karaoke systems, committed to the quality and craftsmanship of its products. While specific warranty details are not provided in this manual, please refer to the product packaging or the official Singing Machine website for comprehensive warranty information.

For any questions or support needs, our US-based customer service team is ready to assist you. Please visit the [Singing Machine Store on Amazon](#) or their official website for contact details.