

[Manuals.plus](#) /

› [fishkeeper](#) /

› fishkeeper Automatic Fish Feeder (Model FK036-200ml) Instruction Manual

fishkeeper FK036-200ml

fishkeeper Automatic Fish Feeder Instruction Manual

Model: FK036-200ml

INTRODUCTION

The fishkeeper Automatic Fish Feeder is designed to provide convenient and reliable feeding for your aquarium fish. This device offers both manual and automatic feeding options, with adjustable feeding intervals and precise food dispensing to ensure your aquatic pets are fed consistently, whether you are home or away.



Image: The fishkeeper Automatic Fish Feeder, a black and clear unit designed for aquariums.

PACKAGE CONTENTS

Please verify that all items are present in your package:

- 1 x fishkeeper Automatic Fish Feeder Unit
- 2 x AAA Batteries
- 1 x Adjustable Clamp Base
- 1 x Plastic Latch Base
- 3 x Fish Food Dischargers (various sizes)
- 1 x Double-Side Sticker
- 1 x User Manual

Package Included



Capacity:	200ml/160g
Noise:	<5db
Item Weight:	0.45lb/205g
Diameter:	4.92 × 3.15 × 2.95 inch
Housing:	High-quality ABS, black
Attachment Method:	Clamp base fixing clip or double-sided sticker

Image: A visual representation of all components included in the fishkeeper Automatic Fish Feeder package, including the feeder unit, batteries, mounting accessories, and dischargers.

SETUP

1. Battery Installation

1. Locate the battery compartment on the back of the feeder unit.

2. Open the battery compartment cover.
3. Insert 2 AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

2. Choosing a Food Discharger

The feeder comes with three interchangeable food dischargers to accommodate different types and sizes of fish food. Select the appropriate discharger based on your fish food type (powder, small pellet, large pellet, strip). Flake food is not recommended for this feeder.

- **5mm x 5mm:** For powder and small pellets (<1g/time).
- **10mm x 10mm:** For small and large pellets (1g/time).
- **17mm x 10mm:** For larger pellets and strips (3g/time).

To change the discharger, press the 'Change Different Fish Food Dischargers Key' (top left button on the control panel) to push out the current bin. Replace it with the desired discharger and press the key again to pull it back into place.


THREE Sizes Precise Feeding



5mm × 5mm
<1g/time



10mm × 10mm
1g/time



17mm × 10mm
3g/time

Suitable for fish food:



Powder



Small pellet



Large pellet



Strip



Flake



Image: Illustration of the three different food discharger sizes (5x5mm, 10x10mm, 17x10mm) and their suitability for various fish food types, indicating that flake food is not suitable.

3. Filling the Food Container

1. Open the top lid of the feeder unit.
2. Carefully pour your chosen fish food into the transparent container. The container has a 200ML capacity.
3. Close the top lid securely.

4. Mounting the Feeder

The feeder offers three methods for attachment to your aquarium:

1. On Aquarium Cover (Method 1):

Snap the plastic latch base into the slot on the feeder base. Remove the protective film from the double-sided sticker and attach it to the plastic latch. Securely attach the feeder to the tank cover.

2. On Ribbed Glass (Method 2):

Insert the adjustable clamp base into the feeder base. Fix the clamp base onto the edge of ribbed tank glass (up to 0.9 inches / 2.4 cm thick). Tighten the adjustable clamp base to secure the feeder.

3. On Vertical Glass (Method 3):

Insert the adjustable clamp base into the feeder base (note: different direction from Method 2). Fix the clamp base onto the edge of vertical tank glass (up to 0.9 inches / 2.4 cm thick). Tighten the adjustable clamp base to secure the feeder.

THREE Fixing Methods




Method 1

Attach it to the tank top cover with the double-side sticker



Method 2

Fix it to the ribbed tank glass $\leq 0.9\text{in}(2.4\text{cm})$ thick with adjustable base



Method 3

Fix it to the vertical tank glass $\leq 0.9\text{in}(2.4\text{cm})$ thick with adjustable base

Image: Visual guide demonstrating the three methods to fix the fishkeeper Automatic Fish Feeder to an aquarium: using a double-sided sticker on the tank cover, clamping to ribbed tank glass, and clamping to vertical tank glass.

Fixed on Aquarium Cover:



1. Snap the plastic latch into slot on the feeder base



2. Remove the protective film of double-side sticker, and attach it to the plastic latch



3. Attach the feeder on the tank cover

Fixed on Ribbed Glass:



1. Insert the adjustable clamp base into the feeder base



2. Fixed the clamp base on the edge of ribbed tank glass (thick ≤ 0.9 in/2.4cm)




3. Clamp and tighten the adjustable clamp base.

Fixed on Vertical Glass:



1. Insert the adjustable clamp base into the feeder base (Note is different direction)



2. Fixed the clamp base on the edge of vertical tank glass (thick ≤ 0.9 in/2.4cm)



3. Clamp and tighten the adjustable clamp base.

Image: Detailed step-by-step illustrations for each of the three mounting methods: on aquarium cover, on ribbed glass, and on vertical glass, ensuring secure installation.

OPERATING INSTRUCTIONS

1. Manual Feeding

To feed your fish manually at any time, press the 'Manual Feeding Key' (top right button on the control panel). This will dispense food once without affecting your programmed automatic feeding schedule.

2. Automatic Feeding

The feeder offers three automatic feeding intervals:

- **8H:** Auto feeding every 8 hours.
- **12H:** Auto feeding every 12 hours.
- **24H:** Auto feeding every 24 hours.

To select an automatic feeding interval, press the corresponding button (8H, 12H, or 24H) on the control panel. The feeder will begin dispensing food at the selected interval from the time the button is pressed.

TWO Feeding Modes

Manual Feeding

Press the "👉" key, feed the fish whenever you want

Automatic Feeding

8H: Auto feeding every 8 hours/time

12H: Auto feeding every 12 hours/time

24H: Auto feeding every 24 hours/time




Image: Diagram illustrating the two feeding modes: Manual feeding (press key for immediate feed) and Automatic feeding (8H, 12H, 24H intervals).

3. Adjusting Food Volume

The food volume is primarily controlled by the size of the selected food discharger. Ensure you have chosen the appropriate discharger for your fish and food type to prevent over or underfeeding.

MAINTENANCE

Cleaning

The fishkeeper Automatic Fish Feeder is designed for easy maintenance. The food container can be detached for cleaning. Always ensure the unit is turned off and batteries are removed before cleaning.

- **Care Instructions:** Hand Wash Only.
- Do not immerse the main electronic unit in water.
- Clean the food container and dischargers regularly to prevent food buildup and ensure proper operation.
- Allow all parts to dry completely before reassembling.

Battery Check

While there is no specific low battery indicator, it is recommended to check and replace the AAA batteries every couple of months to ensure continuous and reliable operation of the feeder.

SPECIFICATIONS

Feature	Specification
Capacity	200ml / 160g
Noise Level	<5db
Item Weight	11.3 ounces / 205g
Dimensions (LxWxH)	3.15 x 2.95 x 4.92 inches
Housing Material	High-quality ABS, black
Power Source	Battery Powered (2 x AAA)
Operation Mode	Automatic, Manual
Attachment Method	Clamp base fixing clip or double-sided sticker

PRODUCT VIDEO GUIDE

Watch this official product video for a visual guide on setting up and operating your fishkeeper Automatic Fish Feeder.

Video: An official guide demonstrating the features, setup, and operation of the fishkeeper Automatic Timer Fish Feeder for aquariums.

© 2024 fishkeeper. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CNSYQ49H>

More documents and user manuals: <https://manuals.plus/>