

- Manuals.plus /
- › BAYBEE /
- › Baybee Convertible ISOFIX Car Seat BS12 Instruction Manual

BAYBEE BS12

Baybee Convertible ISOFIX Car Seat Instruction Manual

Model: BS12 | Brand: BAYBEE

INTRODUCTION

This manual provides essential information for the correct installation, safe use, and maintenance of your Baybee Convertible ISOFIX Car Seat. Please read these instructions carefully before using the car seat and keep them in a safe place for future reference. Proper installation and use are crucial for your child's safety.



Image: The Baybee Convertible ISOFIX Car Seat in black, with a baby secured in the 5-point harness, installed in a car's back seat. This image illustrates the product in use.

Safety Information

Your child's safety is paramount. Always adhere to the following safety guidelines:

- **Read the Entire Manual:** Ensure you understand all instructions before installation and use.
- **Correct Installation:** Always install the car seat according to the instructions provided for your vehicle and the car seat. Incorrect installation can compromise safety.
- **Harness Adjustment:** Ensure the 5-point harness is snug against your child's body, with no slack. The chest clip should be at armpit level.
- **Age and Weight Limits:** This car seat is designed for children from 0 to 12 years, weighing up to 36 kg. Always follow the specific weight and age guidelines for rear-facing, forward-facing, and booster modes.
- **Rear-Facing Longer:** Keep your child in the rear-facing position for as long as possible, up to the maximum weight and height allowed by the car seat, as this is the safest position for infants and toddlers.

- **Never Leave Unattended:** Do not leave your child unattended in the car seat, even for short periods.
- **Avoid Modifications:** Never modify the car seat or use accessories not approved by the manufacturer.
- **After an Accident:** Replace the car seat after any moderate to severe accident, even if there is no visible damage, as its structural integrity may be compromised.
- **Temperature:** Check the car seat surface temperature before placing your child in it, especially after the car has been parked in direct sunlight.

PRODUCT FEATURES

The Baybee Convertible ISOFIX Car Seat is designed with several features to ensure comfort and safety for your child:

- **360° Rotatable Base:** Allows for easy transitions between rear-facing and forward-facing modes, and simplifies placing and removing your child.
- **ISOFIX Safety System:** Provides a secure and stable installation directly to your vehicle's ISOFIX anchor points.
- **Adjustable Headrest:** Multiple height positions to accommodate your child's growth.
- **3 Recline Positions:** Offers comfort for sleeping or sitting upright.
- **5-Point Safety Harness:** Secures your child firmly at the shoulders, hips, and crotch.
- **Side Impact Protection:** Enhanced cushioning and design to protect against side collisions.

360° Rotation

The car seat features a 360-degree swivel function, allowing you to easily rotate the seat for rear-facing, forward-facing, or to face the car door for easier access when placing or removing your child. To rotate, locate the rotation lever (usually at the front base of the seat) and pull it up, then turn the seat to the desired position until it clicks securely into place.

360°

Rotatable **ISOFIX** car seat

ISOFIX arrangement makes this car seat really easy to install, enables better stability and strength to absorb the shock



ISOFIX LATCH CONNECTORS

Image: A diagram illustrating the 360-degree rotatable base of the car seat, with arrows indicating the full range of motion. This highlights the ease of changing seat orientation.



Image: A woman demonstrating the "Flexi Rotate" feature, turning the car seat towards the car door for easy access. This shows the practical benefit of the 360-degree rotation.

Adjustable Headrest

The headrest can be adjusted to multiple height positions to ensure optimal head and neck support as your child grows. To adjust, locate the headrest adjustment clip (usually at the top back of the headrest) and pull it up while simultaneously moving the headrest to the desired height. Release the clip to lock it in place.



Image: A detailed view of the car seat's headrest, showing the mechanism to pull a clip to lift and lower the headrest. This illustrates how to adjust the headrest height.

Recline Positions

The car seat offers 3 recline positions for your child's comfort. To adjust the recline, locate the recline lever (typically at the front or side of the base) and pull it, then tilt the seat to one of the three positions. Ensure it clicks firmly into place.

3 Position Recline ADJUSTMENT



Image: A side view diagram of the car seat illustrating three distinct recline positions, numbered 1, 2, and 3, demonstrating the adjustable comfort settings.

5-Point Safety Harness

The 5-point harness system includes straps over both shoulders, across the hips, and between the legs, securing your child safely in the seat. Always ensure the harness straps are free of twists and are snug against your child's body. The chest clip should be positioned at armpit level.



5 POINT SAFETY HARNESS

5 point safety harness secures your child from shoulders, waist & crotch.



SOFT FABRIC

Ultra Soft & Thick, deep padding on Head, back, shoulder & sides for maximum comfort & safety

SAFETY BELTS



Image: A split image showing a close-up of the 5-point safety harness system and the soft, thick padding on the head, back, shoulder, and sides of the car seat, emphasizing comfort and safety features.

SETUP AND INSTALLATION

The Baybee Convertible ISOFIX Car Seat can be installed using the ISOFIX system. Always refer to your vehicle's owner's manual for specific instructions regarding child restraint installation.

ISOFIX Installation

The ISOFIX system provides a rigid and secure connection between the car seat and your vehicle's chassis. This method minimizes installation errors.

1. Locate the ISOFIX anchor points in your vehicle's back seat. These are usually marked with an ISOFIX symbol.
2. Extend the ISOFIX connectors from the car seat base by pressing the release buttons (if applicable).
3. Align the ISOFIX connectors with the vehicle's anchor points and push firmly until you hear a "click" sound and the indicators turn green (if present).

4. Push the car seat firmly against the vehicle's seat back to remove any slack.
5. Ensure the car seat is securely installed by pulling on it. There should be minimal movement.



Image: The Baybee car seat securely installed in a vehicle using the ISOFIX system, demonstrating a strong and safe ride.

BOOSTER MODE 15–35 KG

Booster mode ensures proper seatbelt positioning and comfortable support for children from 15 to 35 KG.



Image: A close-up view showing a hand engaging the ISOFIX latch connectors into the vehicle's anchor points, illustrating the installation process.

Usage Modes by Weight/Age

The car seat adapts to your child's growth through different modes:

- **Rear-Facing Mode (Below 9 kg):** For infants and younger toddlers. This position offers enhanced head, neck, and spine support.

REAR-FACING BELOW 9 KG

Rear-facing mode provides enhanced head, neck, and spine support for babies below 9 KG, ensuring safer and more comfortable travel.



Image: A mother gently placing a baby into the car seat in the rear-facing position, emphasizing the secure and comfortable setup for infants.

- **Forward-Facing Mode (9-18 kg):** For older toddlers and preschoolers. Ensure your child meets the minimum weight and height requirements before switching to forward-facing.

ISOFIX

STRONG & SAFE RIDE

ISOFIX arrangement makes this car seat really easy to install, enables better stability and strength to absorb the shock.



Image: A young child seated in the car seat in the forward-facing position, secured by the harness, demonstrating the setup for children weighing 9-18 kg.

- **Booster Mode (15-36 kg):** For older children who have outgrown the 5-point harness. The car seat transitions to a high-back booster, using the vehicle's seat belt to secure the child. Remove the internal harness system when using booster mode.

AVAILABLE COLORS



Image: An older child seated in the car seat configured as a booster, secured by the vehicle's seat belt, suitable for children weighing 15-36 kg.

OPERATING INSTRUCTIONS

Securing Your Child

1. Place your child in the car seat.
2. Bring the shoulder straps over your child's shoulders and buckle the two buckle tongues into the crotch buckle.
3. Slide the chest clip up to armpit level.
4. Pull the harness adjustment strap (usually located at the front of the seat) to tighten the harness until it is snug. You should not be able to pinch any slack in the harness straps at your child's shoulder.
5. To loosen the harness, press the harness release button (usually under a flap near the adjustment strap) and pull the shoulder straps forward.

MAINTENANCE

Cleaning Instructions

- **Fabric Covers:** The fabric covers can be removed for cleaning. Refer to the care label on the fabric for specific washing instructions. Typically, machine wash on a gentle cycle with mild detergent and air dry. Do not bleach or tumble dry.
- **Harness Straps:** Wipe harness straps with a damp cloth and mild soap. Do not immerse in water or machine wash, as this can weaken the webbing.
- **Plastic Parts:** Wipe plastic parts with a damp cloth and mild soap. Do not use abrasive cleaners or solvents.
- **Buckle:** Clean the buckle by rinsing it under warm water. Do not use soap or detergents on the buckle mechanism.

Storage

When not in use, store the car seat in a cool, dry place away from direct sunlight. Ensure all components are clean and dry before storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Car seat feels loose after installation.	ISOFIX connectors not fully engaged or slack in the installation.	Ensure ISOFIX connectors are clicked in and indicators are green. Push the seat firmly into the vehicle's seat back to remove slack. Re-install if necessary.
Harness is difficult to tighten or loosen.	Harness straps are twisted or buckle mechanism is dirty.	Untwist any harness straps. Clean the buckle by rinsing with warm water (no soap). Ensure the harness release button is fully pressed when loosening.
Seat does not rotate smoothly.	Rotation lever not fully engaged or obstruction.	Ensure the rotation lever is fully pulled up before attempting to rotate. Check for any obstructions under the base.
Headrest adjustment is stiff.	Adjustment clip not fully pulled or mechanism is dirty.	Ensure the headrest adjustment clip is fully pulled. Clean any visible debris from the adjustment mechanism.

SPECIFICATIONS

Brand	BAYBEE
Model Number	BS12
Installation Type	ISOFIX (also compatible with vehicle seat belt for booster mode)
Colour	Black
Orientation	Rear-Facing, Forward-Facing, Booster
Product Dimensions (D x W x H)	47D x 40W x 65H Centimeters
Item Weight	9 Kilograms

Maximum Weight Recommendation	36 Kilograms
Harness Type	5-Point
Age Range (Description)	Baby, Kids (0 to 12 Years)
Safety Certification	ECE R44/04 Certified



Image: A visual representation of the car seat with its key dimensions labeled: 47 cm depth, 40 cm width, and 65 cm height, indicating it supports up to 36 kg and ages up to 12 years.

WARRANTY AND SUPPORT

For warranty information, product support, or any queries regarding your Baybee Convertible ISOFIX Car Seat, please contact our customer service team:

Email: care@baybee.co.in
WhatsApp: [+91 8939028239](tel:+918939028239) / [+91 7520444000](tel:+917520444000)
Manufacturer: BAYBEE, Galaxy Incorporation

Please retain your proof of purchase for warranty claims.

© 2026 BAYBEE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page
<https://manuals.plus/asin/B0CNT1TNFY>
More documents and user manuals: <https://manuals.plus/>