

## NEWQIDA B0CNT3P818

# NEWQIDA 24V 4WD Off-Road Buggy Side by Side UTV Ride On Toy Car User Manual

Model: B0CNT3P818

## INTRODUCTION

Thank you for choosing the NEWQIDA 24V 4WD Off-Road Buggy Side by Side UTV Ride On Toy Car. This electric vehicle is designed to provide an exciting and safe driving experience for children. Equipped with a powerful 24V battery, 4WD capability, and durable EVA tires, it offers versatile performance on various terrains. This manual provides essential information for assembly, operation, maintenance, and safety to ensure proper use and longevity of your product.

## SAFETY INFORMATION

Please read all safety warnings and instructions before operating the vehicle. Failure to do so may result in serious injury or property damage. This product is certified by ASTM F963 for safety standards.

- **Adult Supervision Required:** Always supervise children when they are operating the vehicle.
- **Age and Weight Limits:** Suitable for children aged 3-7 years (under 4.5ft height). Maximum load capacity is 110 lbs (50 kg). Do not exceed these limits.
- **Protective Gear:** Always ensure the child wears a helmet and appropriate safety gear when riding.
- **Operating Environment:** Use on flat, dry surfaces. Avoid slopes, uneven terrain, sand, gravel, or wet conditions. Do not operate near roads, swimming pools, or other bodies of water.
- **Battery Safety:** Only use the provided charger and battery. Do not modify the electrical system. Keep the battery away from heat sources and flammable materials.
- **Braking:** The vehicle stops when the foot pedal is released. Ensure the child understands how to stop the vehicle.
- **Remote Control Priority:** The remote control can override manual operation for safety.

## COMPONENTS LIST

Before assembly, ensure all parts are present and undamaged. Refer to the packing list included with your product for a detailed inventory.

- Main Vehicle Body

- Steering Wheel
- EVA Tires (4)
- Seats (2)
- Roll Bar Assembly
- 24V Rechargeable Battery
- Charger
- Remote Control
- Assembly Hardware (screws, washers, nuts)
- User Manual

## SETUP AND ASSEMBLY

---

Assembly should be performed by an adult. Please follow these steps carefully.

1. **Unpacking:** Carefully remove all components from the packaging. Keep packaging materials away from children.
2. **Battery Connection:** Locate the battery compartment, typically under the hood or seat. Connect the battery terminals (red to red, black to black). Ensure a secure connection.
3. **Wheel Installation:** Attach each EVA tire to its axle, securing with the provided washers and nuts. Ensure wheels spin freely.
4. **Steering Wheel Attachment:** Connect the steering wheel to the steering column. Ensure the electrical connector for horn/music is properly plugged in before fully securing the steering wheel.
5. **Seat Installation:** Place the seats into their designated slots on the vehicle body and secure them with the provided screws.
6. **Roll Bar Assembly:** Attach the roll bar to the vehicle frame, ensuring all connection points are firm and stable.
7. **Initial Charge:** Before first use, fully charge the battery for 8-12 hours. Refer to the charging section for details.



Image: The NEWQIDA 24V 4WD Off-Road Buggy Side by Side UTV Ride On Toy Car in black, showcasing its robust design and large EVA tires.

# 24V 4X4 Ride On Truck Car



Image: A rear view of the UTV, illustrating its 4WD system, dual shock absorbers for a smooth ride, and durable EVA wheels designed for various terrains.

## OPERATING INSTRUCTIONS

This vehicle offers two primary driving modes: manual operation by the child and remote control by an adult.

### Manual Operation (Child)

- **Start Button:** Press the 'Power' button to turn on the vehicle.
- **Foot Pedal:** Press the foot pedal to accelerate. Release the pedal to brake.
- **Steering Wheel:** Turn the steering wheel left or right to change direction.
- **Gear Shift:** Use the gear lever (if present) to select Forward, Neutral, or Reverse.
- **Music/Horn:** Use the buttons on the steering wheel or dashboard to activate the horn or play built-in music. The vehicle also features Bluetooth connectivity for playing external audio.



## Remote Control Operation (Parent)

The 2.4G remote control allows parents to safely guide the vehicle, especially for younger children.

- **Pairing:** Turn on the vehicle. Hold the pairing button on the remote control until the indicator light flashes, then release. The light will become solid when paired.
- **Forward/Backward:** Use the corresponding buttons to move the vehicle forward or backward.
- **Left/Right:** Use the directional buttons to steer the vehicle.
- **Speed Selection:** The remote control typically has buttons to select high or low speeds.
- **Emergency Brake:** Press the 'P' or 'Emergency Brake' button on the remote to stop the vehicle immediately.

## Two Driving Modes

1. Kids Manual
2. Remote



## REMOTE CONTROL

**S** High/Low Speeds

**▲** Forward

**▼** Backward



Left **◀**

Right **▶**

Emergency Brake **P**

Image: A child operating the UTV, demonstrating the two driving modes: manual control by the child and remote control by an adult, with an illustration of the remote's functions.





Image: A close-up of the remote control unit, showing its buttons for high/low speeds, forward, backward, left, right, and emergency brake functions.



Image: A child seated in the UTV, with icons highlighting key features such as remote control capability, music playback, phone connectivity, 24V 17Ah battery, LED headlights, 4WD power, and EVA tires.

## MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your vehicle.

- **Cleaning:** Wipe the vehicle with a soft, damp cloth. Do not use abrasive cleaners or solvents. Avoid spraying water directly on electrical components.
- **Battery Care:** Charge the battery after each use. If storing for extended periods, charge the battery once a month to prevent deep discharge. Do not overcharge.
- **Storage:** Store the vehicle in a dry, cool place away from direct sunlight and moisture.
- **Inspections:** Periodically check all screws, nuts, and connections to ensure they are tight. Inspect tires for wear and tear.

## TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Vehicle does not move	Battery not connected or low charge	Check battery connections. Charge battery fully.
Vehicle runs slowly	Low battery charge; Overload; Rough terrain	Charge battery. Reduce load. Operate on smoother surfaces.
Remote control not working	Remote not paired; Remote battery low	Re-pair remote. Replace remote batteries.
No sound from music/horn	Loose wiring; Speaker issue	Check wiring connections to speakers. Contact support if issue persists.
Vehicle stops suddenly	Overload protection activated; Loose battery connection	Reduce load. Check battery connections. Allow vehicle to cool down.

## SPECIFICATIONS

Detailed technical specifications for the NEWQIDA 24V 4WD Off-Road Buggy.

Feature	Detail
Product Dimensions	44.9 x 29 x 25 inches (L x W x H)
Item Weight	52.9 pounds
Battery Type	24V 7Ah Rechargeable
Motors	4 x 550 (10000rpm)
Tire Type	EVA Tires
Max Load Capacity	110 lbs (50 kg)
Recommended Age	3-7 Years
Charge Time	8-12 hours



Feature	Detail
Max Speed	3.1-4.4 mph
Seat Width	19 inches

**Dimensions: 44.9x29x25inch**



Image: Visual representation of the UTV's dimensions (44.9x29x25 inches) and seat width (19 inches), along with icons indicating 24V power, 19-inch seat width, and 110 lbs max load.





## Product Specifications

Load Capacity	110lbs
Max Speed	3.1-4.4mph
Tired Type	EVA Tires
Battery Type	24V 7ah
Charge Time	8-12 hrs
Recommended for Age	3 -7 Years

Image: A table summarizing the product specifications including load capacity, max speed, tire type, battery type, charge time, and recommended age.

## WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation included in your product packaging or contact NEWQIDA customer support.

If you have any questions, require technical assistance, or need to report a missing/damaged part, please contact NEWQIDA customer service through the retailer's platform or the official brand website. Please have your model number (B0CNT3P818) and purchase date ready when contacting support.



[illegible]

A comprehensive function manual for the Sports Dance Mat, detailing product features, game modes, and usage precautions.