

Nerf Alfa Strike Big Cat DB-2

Nerf Alpha Strike Big Cat DB-2 Blaster User Manual

Model: Alfa Strike Big Cat DB-2 | Brand: Nerf

INTRODUCTION

Thank you for choosing the Nerf Alpha Strike Big Cat DB-2 blaster. This manual provides essential information for the safe and effective use of your new blaster. Please read all instructions carefully before operating the product and retain this manual for future reference.

SAFETY INFORMATION

- **WARNING:** Do not aim at eyes or face.
- Use only official Nerf darts. Other darts may not meet safety standards.
- Do not modify darts or blaster.
- Eyewear is recommended (not included).
- This product is intended for users aged 8 years and older.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Nerf Alpha Strike Big Cat DB-2 Blaster
- 8 x Official Nerf Darts



Image 1.1: Contents of the Nerf Alpha Strike Big Cat DB-2 package, showing the blaster and eight darts.

SETUP

The Nerf Alpha Strike Big Cat DB-2 blaster requires no assembly. Follow these steps to prepare your blaster for use:

1. **Load Darts:** Insert one official Nerf dart into each of the two barrels at the front of the blaster. Ensure darts are fully seated.



Image 2.1: Demonstrates inserting darts into the blaster's barrels.

OPERATING INSTRUCTIONS

The Big Cat DB-2 features a pump-action mechanism to fire two darts consecutively.

1. **Prime the Blaster:** Hold the blaster firmly. Pull the pump handle located under the barrels all the way back until it clicks, then push it all the way forward until it clicks again. This action primes the blaster.
2. **Aim:** Point the blaster at your target, ensuring no one is in the line of fire. Remember to wear eyewear.
3. **Fire:** Pull the trigger to fire the first dart.
4. **Fire Second Dart:** To fire the second dart, pull the trigger again. No re-priming is needed between the first and second dart.
5. **Reload:** After firing both darts, reload the barrels as described in the "Setup" section to continue use.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your blaster.

- **Cleaning:** Wipe the blaster with a dry or slightly damp cloth. Do not submerge the blaster in water or use harsh chemicals.
- **Storage:** Store the blaster and darts in a cool, dry place away from direct sunlight and extreme temperatures.
- **Darts:** Inspect darts regularly for damage. Discard bent or torn darts as they may affect performance or jam the blaster.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Dart does not fire or fires weakly.	Blaster not fully primed. Damaged dart. Dart not fully inserted.	Ensure pump handle is fully cycled (back and forth until clicks). Replace with a new, undamaged dart. Push dart fully into the barrel.
Pump handle is stuck.	Dart jammed in barrel. Debris in mechanism.	Check barrels for jammed darts and carefully remove. Ensure blaster is clean and free of foreign objects.

SPECIFICATIONS

- **Model:** Alfa Strike Big Cat DB-2
- **Brand:** Nerf
- **Manufacturer:** Hasbro
- **Model Number:** F2463
- **UPC:** 195166112220
- **GTIN:** 195166112220
- **Dimensions (L x W x H):** 20 x 2 x 7 inches (50.8 x 5.08 x 17.78 cm)
- **Material:** Plastic
- **Power Source:** Manual (no batteries required)
- **Dart Capacity:** 2 darts (fires 2 in a row)
- **Recommended Age:** 8+ years

WARRANTY AND SUPPORT

For information regarding warranty coverage, product support, or to purchase replacement parts and darts, please visit the official Nerf website or contact Hasbro customer service. Contact details can typically be found on the product packaging or the official brand website.

Note: Keep your purchase receipt as proof of purchase for any warranty claims.