ECONTROLLY RKN502A500

User Manual

ECONTROLLY RKN502A500 Replacement Remote Control

Introduction

This manual provides comprehensive instructions for the operation and maintenance of your ECONTROLLY RKN502A500 Replacement Remote Control. This remote is designed to be compatible with various Mitsubishi Air-Conditioning units, including models RKN502A500, RKN502A500A, RKN502A 500C, 500A, RYA502A001A, and RYA502A002A. It offers a direct replacement solution, requiring no programming for immediate use.





Figure 1: ECONTROLLY RKN502A500 Remote Control

This image displays the front of the remote control, highlighting its ergonomic design, the LCD screen, and the primary control buttons for air conditioning functions such as power, temperature adjustment, and mode selection.

Safety Information

Please read and understand all safety precautions before using this product. Failure to follow these instructions may result in damage to the remote control or connected devices.

- Do not expose the remote control to direct sunlight, high temperatures, or high humidity.
- Avoid dropping or subjecting the remote control to strong impacts.
- Do not attempt to disassemble or modify the remote control. This will void the warranty.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.
- Dispose of used batteries properly according to local regulations.

Setup

Battery Installation

The remote control requires two (2) AAA alkaline batteries for operation. Ensure correct polarity when inserting batteries.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two new AAA alkaline batteries, matching the (+) and (-) terminals as indicated inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 2: Battery Compartment

This image illustrates the open battery compartment on the back of the remote, clearly showing the slots for two AAA batteries and the

polarity markings.

Note: No programming is required. The remote control will function immediately after battery installation.

Operating Instructions

This remote control provides intuitive access to your Mitsubishi Air-Conditioning unit's functions. Ensure the remote is pointed towards the air conditioning unit's receiver for optimal performance.

Button Functions

Button Name	Function
ON/OFF	Powers the air conditioning unit on or off.
Temperature Up (▲)	Increases the set temperature.
Temperature Down (▼)	Decreases the set temperature.
MODE	Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
FAN SPEED	Adjusts the fan speed (e.g., Low, Medium, High, Auto).
AIR FLOW	Controls the direction or swing of the airflow.
HI POWER	Activates a powerful cooling/heating mode for rapid temperature change.
SLEEP	Activates sleep mode, which adjusts temperature gradually for comfort during sleep.
ON TIMER / HR / MIN	Sets a timer for the unit to turn on. Use HR and MIN buttons to adjust time.
ECONO	Activates economy mode for energy-efficient operation.
ACL	Accesses advanced control settings or resets certain functions. Consult your AC unit's manual for specific ACL functions.

The remote control offers a fast response time of 0.5 seconds and an effective operating range of 8 to 10 meters (26-33 feet).

Maintenance

Proper care will extend the life of your remote control.

- Clean the remote control with a soft, dry cloth. Do not use liquid cleaners or aerosols.
- If the remote control will not be used for an extended period, remove the batteries to prevent leakage and corrosion.
- Store the remote control in a cool, dry place away from direct sunlight.
- The remote is made of durable ABS environmental protection material with soft silicone buttons for longevity.





Figure 3: Back of Remote Control with Instructions

This image shows the back of the remote control, including the battery cover and printed instructions regarding battery usage and care, reinforcing the importance of proper maintenance.

Troubleshooting

If you experience issues with your remote control, try the following solutions:

Problem	Solution
Remote control not responding.	◦ Check if batteries are inserted correctly with correct polarity. ◦ Replace old batteries with new AAA alkaline batteries. ◦ Ensure there are no obstructions between the remote and the air conditioning unit. ◦ Verify the remote is within the effective operating range (8-10 meters).
Buttons are sticky or unresponsive.	◦ Clean the remote control surface and buttons with a soft, dry cloth. ◦ Avoid spilling liquids on the remote.
Remote control display is blank or dim.	◦ Replace batteries. Low battery power can cause a dim display.

Specifications

Feature	Detail
Model Number	RKN502A500
Brand	ECONTROLLY
Compatible With	Mitsubishi Air-Conditioning units (RKN502A500, RKN502A500A, RKN502A 500C, 500A, RYA502A001A, RYA502A002A)
Power Source	2 x AAA Alkaline Batteries (not included)
Material	ABS Environmental Protection Material, Silicone Buttons
Dimensions (L x W x H)	7 x 2 x 0.65 inches (approximately)
Item Weight	2.3 ounces (approximately)
Response Time	0.5 seconds
Operating Distance	8-10 meters (26-33 feet)
Special Feature	Ergonomic design

Warranty and Support

For warranty information or technical support, please contact your retailer or the manufacturer, ECONTROLLY. Refer to your purchase documentation for specific warranty terms and contact details.
This remote control is designed for ease of use and durability, providing a reliable replacement for your original Mitsubishi Air-Conditioning remote.

© 2024 ECONTROLLY. All rights reserved.