

[Manuals.plus](#) /

› [Waterpik](#) /

› Waterpik Cordless Pulse Water Flosser Instruction Manual

Waterpik WF-20CD010


Waterpik Cordless Pulse Water Flosser

Model: WF-20CD010

PRODUCT OVERVIEW

The Waterpik Cordless Pulse water flosser is designed for effective oral hygiene, offering a portable and rechargeable solution. It is ideal for use in smaller bathrooms, during travel, and is waterproof for shower use. This device utilizes PrecisionPulse technology to remove up to 99.9% of plaque bacteria from treated areas, contributing to improved gum health and fresher breath. It is accepted by the American Dental Association (ADA) for its safety and effectiveness.

WHAT'S INCLUDED




The Waterpik Cordless Pulse package includes the main water flosser unit, two Classic Jet tips for general use, and a USB-C to USB-A charging cable. Please note that a wall adapter is not included and must be provided by the user.

- 1 Waterpik Cordless Pulse Water Flosser Unit
- 2 Waterpik Classic Jet Tips
- 1 USB-C to USB-A Charging Cable

SETUP

1. **Initial Charge:** Before first use, fully charge the unit. Connect the USB-C end of the charging cable to the port on the flosser and the USB-A end to a compatible wall adapter (not included) or USB port. The recharge indicator light will show charging status. A full charge provides up to 4 weeks of use.
2. **Attach Tip:** Insert a Classic Jet Tip into the center of the handle until it clicks into place. To remove, press the tip eject button and pull the tip away from the handle.
3. **Fill Reservoir:** Open the flip-top lid on the reservoir. Fill the reservoir with warm water. The reservoir has a 6oz capacity, providing up to 45 seconds of flossing time. Close the lid securely.



The easy-fill reservoir allows for quick and convenient refills, ensuring continuous flossing without interruption. It holds enough water for a thorough cleaning session.

OPERATING INSTRUCTIONS

1. **Select Pressure Setting:** The device features two safe and effective pressure settings: low and high. Use the power switch to select your desired intensity. First-time users should start with the low setting and gradually increase as comfortable.
2. **Positioning:** Lean over a sink. Place the tip in your mouth, aiming it along the gumline at a 90-degree angle. Close your lips enough to prevent splashing while allowing water to flow from your mouth into the sink.
3. **Begin Flossing:** Turn the unit ON. Guide the tip along your gumline, pausing briefly between teeth. Floss both the inside and outside surfaces of your upper and lower teeth.
4. **Waterproof Use:** The Waterpik Cordless Pulse is waterproof and can be used in the shower for added convenience.



The ergonomically designed non-slip hand grip ensures comfortable and easy control during flossing, enhancing precision and effectiveness.

MAINTENANCE

- **Empty Reservoir:** After each use, empty any remaining water from the reservoir. The reservoir is top-rack dishwasher safe for easy cleaning.
- **Clean Unit:** Wipe the exterior of the unit with a soft cloth. Do not immerse the main unit in water.
- **Tip Replacement:** Replace Classic Jet Tips every 6 months, or sooner if they show signs of wear.

TROUBLESHOOTING

Problem	Possible Cause / Solution
No water flow	Ensure reservoir is filled. Check if tip is securely attached. Ensure unit is charged.
Weak water pressure	Check battery charge level. Ensure selected pressure setting is appropriate.
Unit not charging	Verify USB cable is properly connected. Ensure wall adapter/USB port is functional.
Unit turns off unexpectedly	Battery may be low. Recharge the unit.

SPECIFICATIONS

- **Model Number:** WF-20CD010
- **Product Dimensions:** 3.7 x 2.5 x 11.88 inches
- **Weight:** 10.4 ounces
- **Power Source:** Rechargeable Lithium Ion Battery (included)
- **Reservoir Capacity:** 6 ounces (approx. 45 seconds flossing time)
- **Pressure Settings:** 2 (Low/High)
- **Waterproof:** Yes, for shower use
- **UPC:** 073950025317
- **Country of Origin:** China

WARRANTY AND SUPPORT

The Waterpik Cordless Pulse Water Flosser is backed by a 2-year limited manufacturer's warranty. For detailed warranty information or product support, please refer to the product manual or contact Waterpik's customer support team. Waterpik's Colorado support team is available to help with any product questions or needs. For additional resources, you may visit the official Waterpik website or refer to the User Guide (PDF) and User Manual (PDF) available online.

- [User Guide \(PDF\)](#)
- [User Manual \(PDF\)](#)

SAFETY INFORMATION

- Do not immerse the main unit in water.
- Keep away from children.
- Use with caution in the shower.
- Always follow the instructions provided with the product.