

ASTRUM KT210

Astrum KT210 Wireless Touch Multi-mode Keyboard User Manual

Model: KT210 (A51021-B)

INTRODUCTION

The Astrum KT210 is a versatile wireless keyboard featuring a multi-mode connection, integrated touchpad, and RGB backlighting. It is designed for seamless use across multiple devices such as laptops, PCs, tablets, and smartphones, supporting both Bluetooth and 2.4GHz wireless connections. This manual provides detailed instructions for setting up, operating, and maintaining your keyboard.



Image: Top view of the Astrum KT210 Wireless Touch Multi-mode Keyboard, showcasing its full layout including the integrated touchpad and multimedia keys.

SETUP INSTRUCTIONS

Package Contents

- Astrum KT210 Wireless Touch Multi-mode Keyboard
- USB Charging Cable
- User Manual

Charging the Keyboard

Before first use, fully charge the keyboard. Connect the provided USB charging cable to the keyboard's charging port and to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will show the charging status and turn off when fully charged. A full charge provides up to 160 hours of working time.



Image: Close-up of the Astrum KT210 keyboard showing the USB charging port with a cable connected, indicating the charging process.

Powering On/Off

Locate the power switch on the keyboard. Slide the switch to the "ON" position to power on the keyboard. Slide it to "OFF" when not in use to conserve battery life.

Colourful Backlit Illumination

Multi-colour LED backlit illuminated keys with 3 level adjustable brightness for a more personalized experience



Image: Illustration showing the location of the On/Off switch on the Astrum KT210 keyboard, emphasizing battery saving.

Connecting to Devices (Multi-mode Pairing)

The keyboard supports connecting up to three devices via Bluetooth. Use the dedicated function keys to switch between paired devices.

1. Bluetooth Pairing:

- Press and hold **Fn + BT1** (or **BT2, BT3**) for 3-5 seconds until the corresponding indicator light flashes rapidly. This indicates the keyboard is in pairing mode.
- On your device (laptop, tablet, smartphone), enable Bluetooth and search for available devices.
- Select "Astrum KT210" from the list of found devices.
- Follow any on-screen prompts to complete the pairing process. The indicator light will stop flashing once connected.

2. Switching Between Devices:

- Once paired, simply press **Fn + BT1**, **Fn + BT2**, or **Fn + BT3** to switch between your connected devices. The indicator light will illuminate steadily for the active connection.

OPERATING INSTRUCTIONS

Touchpad Functionality

The integrated multipoint touchpad allows for precise navigation and gesture control. Refer to your operating system's settings for specific multi-touch gesture configurations.

- **Single Finger Tap:** Left-click.
- **Two Finger Tap:** Right-click.
- **Two Finger Scroll:** Scroll up/down or left/right.
- **Pinch to Zoom:** Zoom in/out (if supported by application).



Image: The Astrum KT210 keyboard highlighting the multipoint touchpad and dedicated multimedia hotkeys for seamless control.

RGB Backlight Control

The keyboard features multi-color LED backlighting with adjustable brightness levels.

- Press the **light bulb icon key** (usually near the spacebar) to cycle through different backlight colors or turn the backlight on/off.
- Press **Fn + Light Brightness Up/Down keys** (often F11/F12 or dedicated keys) to adjust the backlight brightness through 3 levels.



Image: The Astrum KT210 keyboard displaying its multi-color LED backlighting feature with different color options.

Multimedia Hotkeys

The keyboard includes dedicated multimedia hotkeys for quick access to media controls. These are typically located in the function key row (F1-F12) and may require pressing the **Fn** key simultaneously.

- **Fn + F1-F12:** Control media playback, volume, and other system functions. Refer to the key legends for specific functions.

Operating System Compatibility

The Astrum KT210 keyboard is compatible with a wide range of operating systems:

- Windows
- Mac OS
- Chrome OS
- Linux
- Android

Some keys may have dual legends (e.g., Windows/Android, iOS/Mac). The keyboard automatically adapts to the connected operating system or can be manually switched using **Fn + Q (iOS)**, **Fn + W (Android)**, **Fn + E (Windows)**.

MAINTENANCE

Cleaning

To clean the keyboard, power it off and disconnect any cables. Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution. Avoid excessive moisture and harsh chemicals. Do not immerse the keyboard in liquid.

Spill Resistance

The keyboard features a spill-resistant design, offering protection against accidental liquid spills. In case of a spill, immediately power off the keyboard, disconnect it, and gently wipe away the liquid. Allow it to dry completely before powering on again. While spill-resistant, it is not waterproof; avoid intentional exposure to liquids.

TROUBLESHOOTING

Problem	Solution
Keyboard does not power on.	Ensure the power switch is in the "ON" position. Charge the keyboard fully using the provided USB cable.
Unable to pair via Bluetooth.	<ul style="list-style-type: none"> • Ensure the keyboard is in pairing mode (indicator light flashing). • Make sure Bluetooth is enabled on your device. • Move the keyboard closer to your device. • Remove "Astrum KT210" from your device's Bluetooth list and try pairing again. • Ensure no other devices are actively connected to the keyboard's selected Bluetooth channel.
Keys are not responding or typing incorrectly.	<ul style="list-style-type: none"> • Check battery level and recharge if necessary. • Ensure the keyboard is connected to the correct device channel (BT1, BT2, or BT3). • Verify the correct operating system mode is selected (Fn + Q/W/E). • Restart the keyboard and your device.
Backlight is not working or dim.	<ul style="list-style-type: none"> • Press the light bulb icon key to turn on/off or change color. • Use Fn + Brightness Up/Down keys to adjust brightness. • Ensure the keyboard has sufficient battery charge.
Touchpad is unresponsive.	<ul style="list-style-type: none"> • Ensure the touchpad is not accidentally disabled (check for a dedicated touchpad lock key, if present). • Clean the touchpad surface. • Restart the keyboard and your device.

SPECIFICATIONS

Brand	ASTRUM
Model Number	A51021-B (KT210)
Connectivity Technology	Bluetooth (Multi-mode)
Compatible Devices	Laptop, PC, Tablet, Smartphone
Operating System Compatibility	Windows, Mac OS, Chrome OS, Linux, Android

Special Features	Multi-Device Pairing and Switching, RGB Backlight (3 levels), Integrated Multipoint Touchpad, Spill-Resistant Design, Rechargeable Battery
Battery Type	Lithium Ion
Battery Life	Up to 160 hours (working time)
Colour	Black
Material	Plastic

WARRANTY INFORMATION

The Astrum KT210 Wireless Touch Multi-mode Keyboard comes with a **12 Months Limited Warranty** from the manufacturer. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or external causes such as spills (beyond spill resistance), drops, or extreme temperatures.

Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, refer to the warranty card included with your product or visit the official Astrum website.

CUSTOMER SUPPORT

For technical assistance, troubleshooting, or warranty inquiries, please contact Astrum customer support through their official website or the contact information provided in your product packaging.

Official Website: www.astrum.com

Please have your product model number (A51021-B) and proof of purchase ready when contacting support.