

KIVI 32F750NB

KIVI 32F750NB 32-inch UHD 4K Smart TV User Manual

Model: **32F750NB** | Brand: **KIVI**

1. INTRODUCTION

Thank you for choosing the KIVI 32F750NB 32-inch UHD 4K Smart TV. This television combines advanced display technology with smart features to provide an immersive entertainment experience. This manual will guide you through the setup, operation, and maintenance of your new TV.

Key features include:

- **UHD 4K Resolution (3840 x 2160):** Delivers crisp, detailed images.
- **Android TV 11.0:** Access to a wide range of streaming apps and smart functionalities.
- **HDR10 and HLG Support:** Enhanced contrast and color reproduction.
- **Dolby Audio:** Provides clear and powerful sound.
- **Frameless Design:** Modern aesthetic with minimal bezels.
- **Voice Control:** Convenient operation through integrated voice commands.
- **Wi-Fi and Bluetooth Connectivity:** Seamless integration with your home network and devices.

2. SAFETY INFORMATION

Please read all safety instructions carefully before using your TV and keep this manual for future reference. Incorrect installation or use may result in electric shock or fire.

- **Power Source:** Connect the TV only to an AC 220V, 50Hz power supply.
- **Ventilation:** Ensure adequate ventilation around the TV. Do not block ventilation openings.
- **Water and Moisture:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases, on the TV.

- **Heat Sources:** Keep the TV away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Unplug the TV from the wall outlet before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Children:** Supervise children to ensure they do not play with the TV.
- **Wall Mounting:** If wall-mounting, ensure the wall mount is suitable for the TV's weight and installed by qualified personnel.

3. PACKAGE CONTENTS

Verify that all items are present in the box:

- KIVI 32F750NB Television
- Remote Control
- 2 x AAA Batteries (for remote control)
- TV Stand (2 pieces)
- 4 x Screws (for stand installation)
- Hex Screwdriver
- User Manual (this document)
- Warranty Card
- Energy Label
- Microfiber Cleaning Cloth

4. SETUP

4.1 Unpacking and Placement

Carefully remove the TV from its packaging. Place the TV on a stable, flat surface or mount it on a wall using a compatible VESA mount (not included). Ensure proper ventilation around the TV.

4.2 Stand Installation

1. Place the TV screen-down on a soft, clean surface to prevent scratches.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure each stand piece with the provided screws using the hex screwdriver.
4. Carefully lift the TV to its upright position.

Brand New TV Offer "Room by Room"

In 2023, we are introducing our new range of TVs, equipped with special, completely unique features to meet the needs of all customer families and to equip specific rooms with unique characteristics.



Image: KIVI 32F750NB TV with its stand installed, viewed from the front.

4.3 Connecting Peripherals

The KIVI 32F750NB TV offers various connection ports for your external devices.



Da Vinci × KIVI Contenus éducatifs et divertissements

Les utilisateurs de KIVI Smart TV bénéficient d'un abonnement d'un an à la plateforme Da Vinci Kids.

Qualité et sécurité élevées

Comme nous croyons fermement à la qualité de nos produits, nos écrans bénéficient d'une garantie de 3 ans.



Image: Diagram showing the various connection ports on the back of the KIVI 32F750NB TV, including HDMI, USB, Ethernet, Optical, and Antenna inputs.

- **HDMI (eARC):** Connect Blu-ray players, game consoles, or other HDMI-enabled devices. The eARC port supports enhanced audio return channel for compatible sound systems.
- **USB 2.0:** Connect USB storage devices for media playback.
- **Ethernet:** For a wired internet connection.
- **Optical:** Digital audio output for soundbars or home theater systems.
- **Mini RCA:** Analog audio/video input for older devices.
- **Antenna (75Ω):** Connect your terrestrial or cable antenna.
- **Headphone:** For connecting headphones.
- **CI Slot:** For Conditional Access Modules (CAM) from your service provider.

4.4 Initial Power On and First-Time Setup

1. Connect the power cord to the TV and then to a wall outlet.
2. Press the power button on the remote control or on the TV itself.
3. Follow the on-screen instructions to complete the initial setup, which typically includes:
 - Language selection.
 - Network connection (Wi-Fi or Ethernet).
 - Google Account sign-in (for Android TV features).
 - Channel scanning.

5. OPERATING THE TV

5.1 Remote Control Overview

The included remote control allows you to navigate the TV's features and settings.

From Fast to **STABLY FASTER PERFORMANCE**

Modern, powerful SoC

30% better compared to the market average.

New GPU pushes the limits of features forward

Enables the use of MEMC, ALLM, and other technologies.



2.6 mm
Frameless
front bezel

Image: The KIVI 32F750NB remote control, featuring a circular navigation pad, dedicated app buttons, and a microphone for voice control.

- **Power Button:** Turns the TV on or off.
- **Navigation Pad (Up/Down/Left/Right/OK):** Navigates menus and selects options.
- **Back Button:** Returns to the previous screen.
- **Home Button:** Accesses the Android TV home screen.
- **Volume Up/Down:** Adjusts the volume.
- **Channel Up/Down:** Changes TV channels.
- **Microphone Button:** Activates voice control for searching or commands.
- **Dedicated App Buttons:** Quick access to popular streaming services (e.g., Netflix, YouTube).

5.2 Smart TV Features (Android TV)

Your KIVI TV runs on Android TV 11, providing access to a vast ecosystem of apps and services.



Da Vinci × KIVI Contenus éducatifs et divertissements

Les utilisateurs de KIVI Smart TV bénéficient d'un abonnement d'un an à la plateforme Da Vinci Kids.

Qualité et sécurité élevées

Comme nous croyons fermement à la qualité de nos produits, nos écrans bénéficient d'une garantie de 3 ans.



Image: Screenshot of the Android TV 11 interface on a KIVI TV, showing various streaming app icons and a user-friendly layout.

- **App Access:** Download and install apps from the Google Play Store.
- **Voice Control:** Use the remote's microphone button to search for content, control playback, or ask questions.
- **Chromecast Built-in:** Cast content from your smartphone, tablet, or computer directly to the TV.
- **Google Assistant:** Integrated for smart home control and information retrieval.

5.3 Picture Settings

Adjust picture settings to optimize your viewing experience. Access these settings via the TV's main menu.


Android 11 TV

La dernière version du système d'exploitation le plus populaire: Android TV OS est rapide, stable, sûr et durable.

Haute
compatibilité

Système intégré
avec le écosystème
Google

Rapide,
stable et sûr



Interface
intuitive et facile
à utiliser

Le plus grand magasin
d'applications: une
application pour tous

Mémoire
extensible

Télécommande pratique et ergonomique

La télécommande a une forme ergonomique et des caractéristiques modernes. Développée en coopération avec nos concepteurs en Corée, grâce au Bluetooth intégré, au microphone et aux boutons silencieux avec fonction de pointage supplémentaire, cette télécommande est conçue pour un confort maximal.



Image: Visual representation of KIVI TV's picture enhancement features, including Max Vivid, Super Contrast Control, Ultra Clear, and ALLM & Game Mode.

- **Picture Mode:** Select from preset modes (e.g., Standard, Vivid, Movie, Game) or customize your own.
- **Brightness/Contrast/Saturation:** Fine-tune these parameters for optimal image quality.
- **HDR10/HLG:** Automatically detected for compatible content, enhancing dynamic range and color.
- **Game Mode (ALLM):** Reduces input lag for a smoother gaming experience.

5.4 Sound Settings

Customize audio output to suit your preferences.

- **Sound Mode:** Choose from presets like Standard, Music, Movie, or Speech.
- **Dolby Audio:** Ensures clear and powerful sound for an immersive audio experience.
- **Equalizer:** Manually adjust frequency bands for personalized sound.
- **Digital Audio Output:** Configure settings for external audio devices connected via Optical or HDMI eARC.

5.5 Connectivity

- **Wi-Fi:** Connect to your home wireless network for internet access. Supports Wi-Fi 5G.
- **Bluetooth 5.1:** Connect wireless headphones, speakers, or game controllers.
- **Chromecast:** Built-in for casting content from compatible devices.

6. MAINTENANCE

6.1 Cleaning

- **Screen:** Gently wipe the screen with the provided microfiber cloth. For stubborn marks, lightly dampen the cloth with water or a screen-specific cleaner (do not spray directly on the screen).
- **TV Body:** Use a soft, dry cloth to wipe the TV frame and back.
- **Important:** Always unplug the TV before cleaning. Avoid using abrasive cleaners, alcohol, or solvents.

6.2 Software Updates

Your KIVI Smart TV may receive software updates to improve performance and add new features. It is recommended to keep your TV's software up to date.

- **Automatic Updates:** Ensure your TV is connected to the internet and automatic updates are enabled in the settings.
- **Manual Check:** You can manually check for updates through the TV's settings menu (typically under System > About > System update).

7. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cord disconnected; no power from outlet	Check power cord connection; test outlet with another device.

Problem	Possible Cause	Solution
No picture, but sound is present	Incorrect input source; faulty HDMI cable	Verify input source (e.g., HDMI 1, TV); try a different HDMI cable.
No sound, but picture is present	Volume muted or too low; incorrect audio output settings	Unmute or increase volume; check audio output settings (e.g., TV speakers, external audio system).
Remote control not working	Dead batteries; obstruction; remote not paired	Replace batteries; remove obstructions; re-pair Bluetooth remote if applicable.
Cannot connect to Wi-Fi	Incorrect password; router issue; TV too far from router	Re-enter password; restart router; move TV closer or use Ethernet.
Apps are slow or crashing	Insufficient memory; outdated app/system software	Close background apps; clear app cache; update apps and TV software.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Detailed technical specifications for the KIVI 32F750NB Smart TV:

Feature	Specification
Model Number	32F750NB
Screen Size	32 Inch
Display Technology	LED with Direct Backlighting
Resolution	UHD 4K (3840x2160)
Refresh Rate	60 Hz
Operating System	Android 11
Internal Storage	8 GB
Connectivity	Wi-Fi, Bluetooth 5.1, Ethernet
HDMI Ports	3 (including 1 eARC)
USB 2.0 Ports	2
Audio Output	Optical, Headphone, Dolby Audio (2 x 8W speakers)
Special Features	HDR10, HLG, Chromecast Built-in, Voice Control
Power Consumption	27 Watts
Energy Efficiency Class	G
Product Dimensions (W x H x D)	72 x 42.5 x 6.4 cm (without stand)
Weight	5.68 kg

For more details on energy consumption, please refer to the official EU energy label:




Image: EU Energy Label for KIVI 32F750NB, showing energy class G and 26 kWh/1000h consumption.

Official EU Energy Label Link: <https://eprel.ec.europa.eu/qr/1320380>

9. WARRANTY AND SUPPORT

9.1 Warranty Information

The KIVI 32F750NB Smart TV comes with a **3-year display warranty**. Please refer to the included warranty card for full terms and conditions regarding your product's warranty.

9.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact KIVI customer support through their official website or the contact information provided on your warranty card.