

[Manuals.plus](#) /

› [TOSING](#) /

› TOSING G6 Pro Karaoke Machine User Manual

TOSING G6PRO

TOSING G6 Pro Karaoke Machine User Manual

MODEL: G6PRO

Introduction

Thank you for choosing the TOSING G6 Pro Karaoke Machine. This versatile device combines a 20W Bluetooth speaker with wireless microphones, designed for various uses including parties, church events, and personal entertainment. Featuring advanced DSP intelligent technology and a sensitive vocal pickup, the G6 Pro delivers clear, powerful sound for an immersive audio experience. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.





Figure 1: TOSING G6 Pro Karaoke Machine

What's in the Box

- TOSING G6 Pro Karaoke Microphone with 20W Levitation PA Bluetooth Speaker
- USB Type-C Charging Cable
- User Manual
- (Potentially other accessories like a strap, not explicitly listed in "whats_in_the_box" but mentioned in images)

Key Features

- **20W Louder Speakers:** Built-in dual symmetric PA levitation speakers covering a full frequency range (lowest to 70Hz) for abundant 3D stereo output and home theater enjoyment.
- **DSP Chip Set:** Advanced DSP intelligent technology ensures ultra-strong, long-distance lossless transmission, compatible with smartphones, tablets, TVs, PCs, car audio systems, projectors, and power amplifiers.
- **360-degree Sensitive 30mm Vocal Pickup:** Features a 30mm large diameter dynamic pickup with 3 layers of noise reduction and filtering, ensuring pure, in-tune singing vocals.
- **Accurate Adjustment by LCD:** Easy control and adjustment of microphone volume, TWS duet function, and sound effects via a transparent LCD screen, providing clear working status.

- **Portable Design:** Ideal for both outdoor and indoor use, suitable for gatherings, parties, church events, karaoke nights, birthdays, weddings, and music hosting.

Setup

1. Charging the Device

Before first use, fully charge the TOSING G6 Pro. Connect the provided USB Type-C cable to the charging port on the device and the other end to a compatible USB power adapter (not included). The LCD screen will indicate charging status. A full charge typically takes approximately 2-3 hours.

2. Power On/Off

Press and hold the power button (usually located on the front panel near the LCD) for a few seconds to turn the device on or off. The LCD screen will illuminate upon power-on.




Figure 2: LCD Dynamic Screen for Visual Volume and Frequency Control

3. Bluetooth Pairing

1. Turn on the TOSING G6 Pro. It will automatically enter Bluetooth pairing mode.

2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for "TOSING G6 Pro" (or similar name) in the list of available devices.
4. Select the device to pair. A voice prompt will confirm successful connection.

The device supports Bluetooth 5.2 for stable and efficient wireless connection up to 10 meters.

Advanced DSP intelligent technology, Ultra Strong Long-distance Lossless Transmission, New Multi-media Wireless Link To Each Other Easily.



Figure 3: Advanced DSP Intelligent Technology for Multi-media Compatibility

4. TWS (True Wireless Stereo) Duet Function

For an enhanced stereo experience, you can pair two TOSING G6 Pro microphones together.

1. Ensure both G6 Pro units are powered on and not connected to any other Bluetooth device.
2. On one of the units, press the "TWS" button. It will enter TWS pairing mode.

3. The two units will automatically connect to each other. A voice prompt will confirm successful TWS pairing.
4. Once TWS is established, connect your primary G6 Pro unit to your Bluetooth device as described in step 3. Audio will now play through both units in stereo.



Figure 4: Advanced DSP intelligent technology allows transforming family Bluetooth equipment into a KTV system.

Operating Instructions

1. Volume Control

Use the "Vol+" and "Vol-" buttons on the device to adjust the microphone's volume. The LCD screen will visually display the current volume level.

2. Sound Effects

Press the "Effect" button to cycle through various sound effects such as Karaoke, Pop, Professional, and Original. Experiment to find the best effect for your singing style or environment.

FUNCTIONALITEIT

- Microfoon Cap
- Microvezelleer
- Dynamisch LCD-scherm
- Aan/uit knop
- Volume omhoog
- Volume lager
- Geluidseffecten (Karaoke,Pop,Professionele,Originele)
- TWS aan/uit knop
- Net voor luidsprekerhoorn



Figure 5: Detailed Functionality of the TOSING G6 Pro Microphone

3. Audio Output

The G6 Pro features two symmetric PA levitation speakers for powerful 3D stereo sound. The 30mm dynamic vocal pickup ensures clear voice capture with noise reduction. For optimal sound, ensure the microphone is positioned correctly during use.

**70Hz 3D Surround Super Bass
Bring You with Home Theater Experience Firsthand**



Figure 6: Experience 70Hz 3D Surround Super Bass for Home Theater Enjoyment

360°Autotune Pickup Sound Design 30MM Big Diameter,Noise Reduction and Filtering




Figure 7: 360-degree Autotune Pickup Sound Design with 30mm Big Diameter, Noise Reduction and Filtering

4. Connecting to External Devices (AUX/USB)

In addition to Bluetooth, the G6 Pro supports 3.5mm Jack and USB Type-C connections for versatile compatibility with various audio sources and devices.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Do not use abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Microphone Care:** Avoid dropping the microphone or exposing it to excessive moisture.

Troubleshooting

Problem	Possible Cause	Solution
No power	Battery is low or dead.	Charge the device fully using the provided USB Type-C cable.
Cannot connect via Bluetooth	Bluetooth is off on your device; G6 Pro is already connected to another device; too far from the device.	Ensure Bluetooth is enabled. Disconnect from other devices. Move closer to the G6 Pro (within 10 meters). Restart both devices.
Poor sound quality / Distortion	Microphone too close to speakers; volume too high; interference.	Adjust microphone distance from speakers. Lower the volume. Move away from sources of interference.
TWS pairing failed	One or both units are already connected to another device.	Ensure both G6 Pro units are disconnected from all other Bluetooth devices before attempting TWS pairing.

Specifications

Feature	Detail
Model Number	G6PRO
Item Weight	1.01 pounds
Product Dimensions	8 x 14 x 8 inches
Batteries	2 Lithium Polymer batteries (included)
Speaker Count	2
Power Source	Battery Powered
Connector Type	3.5 mm Jack, USB Type C
Compatible Devices	Bluetooth speaker/stage speaker/amplifier, car audio/tablet/mp3, karaoke machine/pc/laptop/tv/lcd monitor
Special Feature	20W levitation PA Bluetooth speaker, dynamic LCD screen, speakers with diaphragms integrated
Recommended Uses	Karaoke, Recording, Singing, Streaming

Official Product Video

Your browser does not support the video tag.

Video 1: Official product video demonstrating the TOSING G6 Pro microphone for adults karaoke singing machine. This video showcases the product's features and use cases.

Warranty and Support

For warranty information and technical support, please refer to the contact details provided on the product packaging or visit the official TOSING website. Keep your purchase receipt for warranty claims.

© 2024 TOSING. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CNP9LHH7>

More documents and user manuals: <https://manuals.plus/>