

[Manuals.plus](#) /

› [Amazon](#) /

› Amazon Kindle 16 GB User Manual

Amazon Kindle (11th Generation)

Amazon Kindle 16 GB User Manual

Model: Kindle (11th Generation)

Brand: Amazon

INTRODUCTION

The Amazon Kindle (11th Generation) is designed for an enhanced reading experience, offering a lightweight and compact design with faster page turns and a higher contrast ratio. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.



Now with 25% brighter front light at max setting and higher contrast ratio

The Amazon Kindle (11th Generation) features a glare-free display, adjustable front light, weeks of battery life, and storage for thousands of books.

Key Features

- **Lightweight and Compact:** Designed for comfortable, one-handed reading.
- **Enhanced Display:** Features a 6-inch glare-free display with 300 ppi, optimized font technology, and 16-level grayscale.
- **Adjustable Front Light:** Now 25% brighter at max setting for effortless reading in any light, including dark mode.
- **Long Battery Life:** Up to six weeks on a single charge, based on typical usage.
- **Ample Storage:** 16 GB of on-device storage, capable of holding thousands of books.
- **Distraction-Free Reading:** Designed to help you focus solely on your books.
- **Sustainable Design:** Constructed with 75% recycled plastics and 90% recycled magnesium, with 100% recyclable device packaging.

GETTING STARTED: SETUP

What's in the Box

- Amazon Kindle (11th Generation) device
- USB-C charging cable
- Quick Start Guide

Charging Your Kindle

Before first use, fully charge your Kindle. Connect the included USB-C cable to the Kindle's charging port and the other end to a power source (e.g., a computer USB port or a 9W USB power adapter, sold separately).

- Charging from a computer via USB cable: Approximately 4 hours.
- Charging with a 9W USB power adapter: Approximately 2 hours.

Powering On/Off

To power on your Kindle, press and hold the power button located on the bottom edge of the device until the screen lights up. To put your Kindle to sleep, briefly press the power button. To power off completely, press and hold the power button until a power dialog appears, then select "Power Off".

Initial Setup and Wi-Fi Connection

Upon first power-on, follow the on-screen instructions to set up your Kindle. This typically involves selecting your language, connecting to a Wi-Fi network, and registering your device to your Amazon account. Your Kindle supports 2.4 GHz and 5.0 GHz Wi-Fi networks with WEP, WPA, WPA2, WPA3, and OWE security protocols.

OPERATING YOUR KINDLE

Navigating the Interface

The Kindle features a touch-sensitive screen for navigation. Tap to select items, swipe left or right to turn pages in a book, and swipe down from the top of the screen to access quick settings and notifications.



16 GB storage to hold
thousands of books

Experience faster page turns for a seamless reading flow.

Reading Books

Tap on a book cover from your library to open it. To turn pages, tap the right side of the screen for the next page or the left side for the previous page. You can also swipe. Tap the top of the screen to bring up reading options, including font size, font face, line spacing, margins, and dark mode.



Now with faster page turns

The Kindle's display provides a clear and comfortable reading experience, mimicking real paper.




6" glare-free display, no distractions, and up to 6 weeks of battery life

The 6-inch glare-free display and up to 6 weeks of battery life allow for extended, distraction-free reading sessions.

Managing Content

Your Kindle has 16 GB of on-device storage, capable of holding thousands of books. All Amazon content is also stored in the cloud for free, allowing you to download books as needed. You can find new stories through the Kindle Store directly on your device. A Kindle Unlimited subscription provides access to over 4 million titles and thousands of audiobooks.



Access over 4 million titles with a Kindle Unlimited subscription

Access a vast library of over 4 million titles with a Kindle Unlimited subscription.

Supported content formats include Kindle Format 8 (AZW3), Kindle (AZW), TXT, PDF, unprotected MOBI, PRC natively. Other formats like DOCX, DOC, HTML, EPUB, RTF, JPEG, GIF, PNG, and BMP can be read through conversion services.

MAINTENANCE

Cleaning Your Kindle

To clean your Kindle, use a soft, lint-free cloth. Do not use abrasive cleaners, solvents, or aerosol sprays. Avoid getting moisture into any openings.

Software Updates

Your Kindle automatically receives software security updates when connected to Wi-Fi. Ensure your device is connected to the internet periodically to receive the latest updates, which improve performance and add new features. This device receives guaranteed software security updates until at least four years after it is last available for purchase as a new unit.

TROUBLESHOOTING

Common Issues and Solutions

- **Kindle is unresponsive:** If your Kindle is frozen or not responding to touch, press and hold the power button for 40 seconds until the device restarts.
- **Cannot connect to Wi-Fi:** Ensure your Wi-Fi password is correct. Try restarting your Kindle and your Wi-Fi router. The Kindle does not support ad-hoc (peer-to-peer) Wi-Fi networks.
- **Battery not charging:** Ensure the USB-C cable is securely connected to both the Kindle and the power source. Try a different USB-C cable or power adapter if available.
- **Books not downloading:** Check your Wi-Fi connection. Ensure your Amazon account is correctly registered on the device.
- **Screen flickering or ghosting:** This is normal for e-ink displays. The screen refreshes periodically to clear residual images. If it persists or is severe, try a device restart.

For further assistance, refer to the official Amazon Kindle support pages or contact Amazon Customer Service.

SPECIFICATIONS

Feature	Detail
Display	6-inch display with built-in light, 300 ppi, optimized font technology, 16-level grayscale.
Size	6.2" x 4.3" x 0.32" (157.8 x 108.6 x 8.0 mm)
Weight	5.56 oz (158 g)
On-Device Storage	16 GB (holds thousands of books)
Cloud Storage	Free cloud storage for all Amazon content
Battery Life	Up to six (6) weeks on a single charge (based on 30 mins/day reading, wireless off, light setting 13)
Charge Time	Approx. 4 hours (USB-C to computer); Approx. 2 hours (9W USB power adapter)
Wi-Fi Connectivity	2.4 GHz and 5.0 GHz networks (WEP, WPA, WPA2, WPA3, OWE security)
Accessibility Features	VoiceView screen reader (Bluetooth audio), invert Black and White, adjustable font size/face, line spacing, margins.
Content Formats	Kindle Format 8 (AZW3), Kindle (AZW), TXT, PDF, unprotected MOBI, PRC natively; PDF, DOCX, DOC, HTML, EPUB, TXT, RTF, JPEG, GIF, PNG, BMP through conversion.
Generation	Kindle (11th Generation) - 2024 release

WARRANTY AND SUPPORT

Warranty Information

Your Amazon Kindle (11th Generation) includes a 1-year limited warranty and service. Optional 1-year, 2-year, or 3-year

Extended Warranty plans are available for U.S. customers and are sold separately. Use of the Kindle is subject to Amazon's Conditions of Use.

Additional Resources

- For more detailed information, refer to the [Kindle User Guide](#).
- Information specific to your device can be found by visiting [Manage Your Content and Devices](#).
- Learn more about [Accessibility for Kindle](#).
- Learn more about [supported file types for personal documents](#)

© 2024 Amazon. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question