

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MARTVSEN](#) /

› [MARTVSEN S7MAX Magnetic Neck Holder User Manual](#)

## MARTVSEN S7MAX

# MARTVSEN S7MAX Magnetic Neck Holder User Manual

Model: S7MAX | Brand: MARTVSEN

## INTRODUCTION

The MARTVSEN S7MAX Magnetic Neck Holder is designed to provide a stable and hands-free solution for recording point-of-view (POV) videos with action cameras and smartphones. Its innovative magnetic suction stabilization module minimizes shaking and blurring, ensuring clearer footage. Made from elastic and skin-friendly silicone, it offers a comfortable and secure fit for various activities.

## WHAT'S IN THE Box

- Magnetic Anti-shake Module
- Neck Holder
- AEE Adapter
- Phone Clip
- User Guide




Image: All components included in the MARTVSEN S7MAX package.

## KEY FEATURES

- **More Stable, Clearer Shooting:** The invisible magnetic suction stabilization module keeps your device close to the body, significantly reducing shaking and blurring during movement.



Image: The magnetic neck holder in use, demonstrating its stability for clear footage.

- **Safe & Skin-friendly:** Constructed from elastic and skin-friendly silicone material, ensuring safety and comfort during prolonged wear. The ergonomic design provides a natural fit to the shoulder and neck.

# Safe & Skin-friendly Not Easy To Break




Image: Demonstrates the flexibility and skin-friendly material of the neck holder.

- **Smart Quick Release:** Features an automatic locking mechanism after installation and supports one-click unlocking for quick disassembly and assembly.

# Omni-directional Locking & Smart Quick Release

More Stable & Safer For Cell Phone Use



Traditional quick release cannot be completely locked, and there is a certain risk of pop-up quick release.



Image: Detailed view of the omni-directional locking and smart quick release buttons.

- **Free To Bend, Not Easy To Break:** Built with a non-slip stainless steel gooseneck and metal aluminum support, allowing for free bending into any shape. The plate lock design enables 180° camera angle adjustment.

# The Exercise Is Stable & Does Not Shake

## Shoot More Clearly

---

"Invisible" magnetic module,  
Exercise jumps without shaking



Image: The neck holder maintaining stability during active use, highlighting its robust yet flexible design.

- **Widely Compatible:** Supports all action cameras (GoPro Hero 13/12/11/10/9/8/7 Black Max, DJI Osmo Action 5 Pro/4/3/2, Insta360 x4/x3/Go3 Ace Pro, AKASO EK7000 Brave 7/4, etc.) and all smartphones (iPhone 16 Pro Max Plus/15/14/13/12, Samsung Galaxy S24/S23/S22 A15, Google Pixel 9 Pro XL/8/8a, Motorola Moto Android, etc.) with the included phone clip.

# Widely Compatibility

Make pov vlog shooting easier

## For Phone



## For Action Camera



### \*Suitable for body size: 50-110KG

For GoPro all series/ Insta360 One R One X2 Go3 Go2 / DJI OSMO Action, Pocket 3 2/ SONY, MI and other action cameras

Image: Visual representation of the wide compatibility with different phone and action camera models.

## SETUP GUIDE

Follow these steps to properly set up your MARTVSEN S7MAX Magnetic Neck Holder. For a visual guide, please refer to the video below.

Your browser does not support the video tag.

Video: How to use the action camera version of the neck holder. This video demonstrates the full assembly and usage of the neck holder with an action camera.

### 1. Initial Assembly (Action Camera)

- 1. Install Quick Release Head:** Take the quick release head and align the slot with the mount on the neck holder. Turn clockwise to tighten it securely.
- 2. Attach Magnetic Sheet:** Peel off the backing from the attractive magnet sheet and stick it firmly into the groove on the back of the neck holder. This enhances magnetic stability.

3. **Mount Camera:** Align your action camera with the interface on the quick release head. Insert the screw rod through the camera's mounting bracket and tighten it to fix the camera in place.

## 2. Anti-Shake Magnetic Module Installation

1. **Remove Quick Release Head (if necessary):** To remove the quick release head, press and hold the button below the mount and turn counter-clockwise.
2. **Insert Magnetic Module into Lanyard:** Take the anti-shake magnetic module and insert the lanyard through its designated slot.
3. **Position Module:** Place the anti-shake magnetic module inside your clothing, against your chest. The neck holder will then adsorb together with this module from the outside, creating a stable, anti-shake connection.

## 3. Optional: Centered Vertical Shooting Adapter

If your package includes the optional centered vertical shooting adapter, follow these steps for installation:

1. **Install Vertical Adapter:** Attach the centered vertical shooting adapter to the neck holder's mount, similar to the standard quick release head.
2. **Mount Camera Vertically:** Align your action camera with the vertical adapter's interface. Use the provided screw rod to secure the camera in a vertical orientation.

## OPERATING INSTRUCTIONS

### Wearing the Neck Holder

Gently bend the neck holder to fit comfortably around your neck. Ensure the main module with the device attachment point is positioned at the front of your chest. If using the anti-shake magnetic module, ensure it is correctly placed inside your clothing to align with the external holder for optimal stability.

### Attaching Your Device

For action cameras, ensure the camera is securely fastened to the quick release head using the screw rod. For smartphones, attach the phone clip to the quick release head, then insert your phone into the clip, ensuring it is held firmly.

### Adjusting the Angle

The neck holder features a flexible gooseneck and a plate lock design that allows for 180° free adjustment of your camera or phone. Gently bend the neck holder to achieve your desired POV angle. The quick release mechanism also allows for easy rotation between horizontal and vertical shooting modes (with the appropriate adapter).

# Enjoy POV

## First-person Perspective




Free your hands  
feel the immersive visual experience



Daily Life




Riding



Fishing



Practicing Move



Skiing

Image: Examples of immersive first-person perspective video capture during daily activities.

## MAINTENANCE

To ensure the longevity and optimal performance of your MARTVSEN S7MAX Magnetic Neck Holder, follow these maintenance guidelines:

- Cleaning:** Wipe the silicone and plastic parts with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the material.
- Storage:** Store the neck holder in a cool, dry place away from direct sunlight and extreme temperatures. When not in use, you can gently coil it for compact storage.
- Inspection:** Periodically check all connection points, screws, and the quick release mechanism for any signs of wear or looseness. Tighten screws as needed to maintain secure attachment.

## TROUBLESHOOTING

If you encounter any issues with your MARTVSEN S7MAX Magnetic Neck Holder, refer to the following common problems and solutions:

- **Device is not stable/shaking:**

- Ensure the quick release head is fully tightened onto the neck holder.
- Verify that the camera/phone is securely attached to the quick release head or phone clip.
- Confirm the anti-shake magnetic module is correctly positioned inside your clothing and aligned with the external holder.

- **Neck holder feels uncomfortable:**

- Adjust the shape of the flexible gooseneck to better conform to your neck and shoulders.
- Ensure the neck holder is not too tight. The silicone material is designed for comfort, but improper positioning can cause discomfort.

- **Quick release mechanism is stiff:**

- Ensure you are pressing the correct release button firmly while rotating.
- Clean any dust or debris from the mechanism.

## PRODUCT SPECIFICATIONS

Attribute	Value
Model Number	S7MAX
Brand	MARTVSEN
Color	Elephant Gray
Item Weight	8.1 ounces (230 Grams)
Package Dimensions	7.83 x 5.55 x 1.73 inches
Compatible Devices	Action Camera, Cell Phones
Maximum Weight Recommendation	3 Kilograms
Folded Size	10 cm (l) x 5 cm (w) x 3 cm (h)
Manufacturer	MARTVSEN
Country of Origin	China
Date First Available	November 23, 2023

## WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official user guide provided with your product. A digital version of the user manual is available [here](#).

For further assistance, you may contact MARTVSEN customer service directly.

© 2024 MARTVSEN. All rights reserved.