

[Manuals.plus](#) /

> [Bnnwa](#) /

> Bnnwa Multi-Device Wireless Bluetooth Keyboard User Manual

## Bnnwa D817

# Bnnwa Multi-Device Wireless Bluetooth Keyboard User Manual

Model: D817

## PRODUCT OVERVIEW

The Bnnwa Multi-Device Wireless Bluetooth Keyboard (Model D817) is a compact and slim keyboard designed for seamless compatibility across various operating systems and devices. It offers dual-mode connectivity (2.4G USB and Bluetooth) and allows for easy switching between up to three connected devices, enhancing productivity and comfort for everyday use.



Image: Front view of the Bnnwa Multi-Device Wireless Bluetooth Keyboard, showcasing its compact design and white color.

## PACKAGE CONTENTS

Upon opening your Bnnwa Multi-Device Wireless Bluetooth Keyboard package, you should find the following items:

- 1 x Bnnwa Wireless Keyboard
- 2 x AAA Batteries (included)
- 1 x 2.4G USB Receiver
- 1 x Instruction Manual

## 2 Typing Angles

Type in a comfortable position with less wrist stress

11.2inch



4.94inch



Image: Underside of the keyboard showing the battery compartment and the slot for the 2.4G USB receiver.

## SETUP GUIDE

### 1. Battery Installation

1. Locate the battery compartment on the underside of the keyboard.
2. Open the battery cover.
3. Insert the two included AAA batteries, ensuring correct polarity (+/-).
4. Close the battery cover securely.

### 2. Connecting Your Keyboard

Your Bnnwa keyboard supports dual-mode connectivity: 2.4G USB and Bluetooth. You can connect up to three devices simultaneously (one via 2.4G USB and two via Bluetooth).

# Easy Switch Between 3 Devices

Wireless connectivity to 3 devices via 2.4GHz and 2\*Bluetooth




Image: Visual representation of the keyboard connecting to a desktop, laptop, tablet, and smartphone, illustrating the 2.4G and Bluetooth connectivity options.

## 2.1. 2.4G USB Connection

1. Take out the 2.4G USB receiver from its storage slot on the keyboard's underside.
2. Plug the USB receiver into an available USB-A port on your computer or device.
3. Turn on the keyboard using the power switch (usually located on the side or back).
4. The keyboard should automatically connect to your device. The 2.4G connection uses AEC encryption for secure transmission.

## 2.2. Bluetooth Connection (BT1 / BT2)

1. Turn on the keyboard using the power switch.
2. Press and hold either the **BT1** or **BT2** button on the keyboard for 3-5 seconds until the corresponding indicator light flashes rapidly. This indicates pairing mode.
3. On your device (iPadOS, MacOS, Windows, Android, ChromeOS), go to Bluetooth settings.
4. Search for "Bnnwa Keyboard" or a similar name in the list of available devices.
5. Select the keyboard to pair. Follow any on-screen prompts if a pairing code is required.
6. Once paired, the indicator light will stop flashing and remain solid for a few seconds, then turn off.

7. Repeat these steps for a second Bluetooth device using the other BT button.

## OPERATING INSTRUCTIONS

---

### 1. Switching Between Devices

To switch between connected devices, simply press the corresponding connection button on the keyboard:

- Press the **2.4G** button to switch to the device connected via the USB receiver.
- Press the **BT1** button to switch to the first Bluetooth-connected device.
- Press the **BT2** button to switch to the second Bluetooth-connected device.

### 2. Using Shortcut Keys

The keyboard features 12 hotkeys for quick access to essential functions. These keys are typically located on the function (F1-F12) row and can be activated by pressing the **Fn** key simultaneously with the desired function key.



Image: Close-up of the keyboard highlighting the 12 shortcut keys and their respective functions, such as brightness control, media playback, and volume adjustment.

### Common Shortcut Key Functions

| Key Combination | Function                     |
|-----------------|------------------------------|
| Fn + F1         | Decrease Brightness          |
| Fn + F2         | Increase Brightness          |
| Fn + F3         | Open Mission Control (macOS) |
| Fn + F4         | Open Launchpad (macOS)       |
| Fn + F5         | Home                         |
| Fn + F6         | Print Screen                 |
| Fn + F7         | Previous Track               |
| Fn + F8         | Play/Pause                   |
| Fn + F9         | Next Track                   |
| Fn + F10        | Mute                         |
| Fn + F11        | Decrease Volume              |
| Fn + F12        | Increase Volume              |

### 3. Ergonomics and Typing Experience

The keyboard features a scissor-switch design for a smooth and comfortable typing experience, reducing fatigue during prolonged use. It also offers two adjustable typing angles to help you find the most comfortable position and reduce wrist stress.

# 12 Shortcut Keys

Enhance productivity and efficiency

|  |                      |   |                 |
|--|----------------------|---|-----------------|
|  F1 | Decrease Brightness  |  F7  | Prev Track      |
|  F2 | Increase Brightness  |  F8  | Play/pause      |
|  F3 | Open Mission Control |  F9  | Next Track      |
|  F4 | Open Launchpad       |  F10 | Mute            |
|  F5 | Home                 |  F11 | Decrease Volume |
|  F6 | Prtsc                |  F12 | Increase Volume |



Image: Detailed view of the keyboard keys, illustrating the scissor mechanism for quiet and comfortable typing.



Image: The keyboard positioned on a desk next to an iPad, demonstrating its slim and portable design.

## MAINTENANCE

---

### 1. Battery Life and Power Saving

The keyboard is powered by 2 AAA batteries, offering a long-lasting battery life of up to 12 months under normal usage conditions. To conserve power, the keyboard features an environmental-friendly auto-sleep mode. If inactive for 10 minutes, it will automatically enter sleep mode. To wake it up, simply click any key.

### 2. Cleaning

To maintain your keyboard's appearance and functionality, regularly clean it with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, ensuring no moisture enters the key switches or internal components. Avoid using harsh chemicals or abrasive materials.

## TROUBLESHOOTING

---

- **Keyboard not connecting:** Ensure the keyboard is turned on. For 2.4G connection, verify the USB receiver is properly inserted. For Bluetooth, ensure the keyboard is in pairing mode (indicator light flashing) and your device's Bluetooth is enabled and searching. Try re-pairing the device.
- **Low Battery Indication:** The low battery indicator on the device will flash red when the power is too low. Replace the AAA batteries promptly to ensure uninterrupted use.
- **Keys not responding:** Check battery level. Ensure the keyboard is connected to the correct device channel (2.4G, BT1, or BT2). Try restarting the keyboard and the connected device.
- **Interference:** If experiencing intermittent connection, try moving the keyboard closer to your device or away from other wireless devices that might cause interference.

## SPECIFICATIONS

| Feature                 | Detail  |
|-------------------------|---|
| Brand                   | Bnnwa   |
| Model Number            | D817  |
| Color                   | White   |
| Product Dimensions      | 11.2"L x 4.94"W x 0.8"H (28.45 x 12.55 x 2.03 cm)   |
| Item Weight             | 14 ounces (396.89 grams)  |
| Connectivity Technology | Bluetooth, 2.4G USB-A   |
| Number of Keys          | 81  |
| Compatible Devices      | Laptop, PC, Smartphone (iPadOS, MacOS, Windows, Android, ChromeOS)  |
| Special Feature         | Portable, Multi-Device Connectivity (up to 3 devices), Scissor-Switch Design, Adjustable Typing Angles, 12 Shortcut Keys, Auto-Sleep Mode |
| Batteries               | 2 AAA batteries required (included)   |

## WARRANTY AND SUPPORT

For information regarding warranty coverage and customer support, please refer to the product packaging or contact Bnnwa customer service directly. Details can often be found on the official Bnnwa website or the platform where the product was purchased.