

[Manuals.plus](#) /

› [Darkant](#) /

› Darkant K1 Mini Karaoke Machine User Manual

Darkant K1-2MIC

Darkant K1 Mini Karaoke Machine User Manual

Model: K1-2MIC-PINK

1. INTRODUCTION

Thank you for choosing the Darkant K1 Mini Karaoke Machine. This device combines a portable Bluetooth speaker with two wireless microphones and dynamic LED lights, designed to provide an enjoyable audio experience. This manual provides essential information for safe operation, setup, and maintenance of your karaoke machine.



Image: The Darkant K1 Mini Karaoke Machine in pink, featuring the main speaker unit and two wireless microphones.

2. PACKAGE CONTENTS

Please verify that all items are present in the package:

- 1 x Mini Karaoke Machine Speaker
- 2 x Wireless Microphones
- 1 x USB Charging Cable
- 1 x User Manual (this document)

3. PRODUCT OVERVIEW

3.1 Main Unit (Speaker)

The main unit houses the speaker, control buttons, LED lights, and various ports for connectivity and charging.

3.2 Wireless Microphones

Two wireless microphones are included for vocal input. Each microphone features power, volume, and voice effect controls.

CLEAR SOUND WITH LOUD VOLUME

HIFI sound quality

3D surround sound

no sound breaking



Image: Close-up view of the karaoke machine speaker and one wireless microphone, highlighting their respective control buttons.

3.3 Ports and Indicators

- **Type-C Charging Port:** For charging the speaker unit.
- **TF Card Slot:** For playing music directly from a micro-SD card.
- **Audio Port (Headphone Jack):** For private listening.
- **LED Indicators:** Display power and connection status.

EASY TO CONNECT AND SIMPLE TO OPERATE



Image: Diagram illustrating the location of the Type-C charging port, TF card slot, and audio port on the karaoke machine.

4. SETUP

4.1 Charging the Device

Before first use, fully charge the karaoke machine speaker and both microphones. Use the provided USB charging cable.

1. Connect the USB charging cable to the Type-C port on the speaker unit.
2. Connect the other end of the USB cable to a compatible 5V USB power adapter (not included).
3. The charging indicator light will illuminate. Once fully charged, the light may change color or turn off.
4. For microphones, connect the USB cable to their respective charging ports.

A full charge provides up to 6 hours of continuous playtime at maximum volume.

4.2 Powering On/Off

- **Speaker:** Press and hold the power button on the speaker unit until the LED lights illuminate.
- **Microphones:** Press and hold the power button on each microphone until the indicator light turns on.
- To power off, repeat the process for both the speaker and microphones.

5. OPERATING INSTRUCTIONS

5.1 Bluetooth Connection

The karaoke machine uses Bluetooth 5.0 for wireless audio streaming.

1. Ensure the speaker unit is powered on. It will automatically enter Bluetooth pairing mode.
2. On your smartphone, tablet, or other Bluetooth-enabled device, enable Bluetooth and search for available devices.
3. Select "Darkant K1" (or similar name) from the list to connect.
4. Once connected, a confirmation sound will play, and the speaker's indicator light will stabilize.

EASY TO CONNECT AND SIMPLE TO OPERATE



Image: Illustration of the karaoke machine connecting to a smartphone, tablet, laptop, and computer via Bluetooth.

5.2 TF Card Playback

Insert a micro-SD (TF) card with pre-loaded music files into the TF card slot on the speaker unit. The machine will automatically detect and begin playing music from the card.

5.3 Volume Control

- **Speaker Volume:** Use the volume buttons on the speaker unit to adjust the overall music playback volume.
- **Microphone Volume:** Use the volume buttons on each wireless microphone to adjust individual microphone output levels.

5.4 Voice Modulation Effects

The microphones feature 5 voice options:

- Original Sound
- Girl's Voice
- Boy's Voice

- Baby's Voice
- Monster Voice

Press the dedicated voice effect button on the microphone to cycle through these options.

FUNNY MAGIC SOUNDS MAKE KIDS LAUGH AND HAVE FUN

funny karaoke choice for kids 4 magic voice changing effect



Image: Two children enjoying the karaoke machine, demonstrating the voice changing effects with icons for female, male, baby, and monster voices.

5.5 Dynamic LED Lights

The speaker unit features dynamic LED lights that synchronize with the music's rhythm. These lights automatically activate when the speaker is powered on. There may be a button on the speaker to toggle the lights on or off.

6. MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- Keep the device away from water and excessive moisture.

- Store the karaoke machine and microphones in a cool, dry place when not in use.
- Avoid dropping the device or subjecting it to strong impacts.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from speaker	Speaker is off; Volume is too low; Not connected via Bluetooth/TF card.	Ensure speaker is on; Increase volume; Reconnect Bluetooth or check TF card.
Microphone not working	Microphone is off; Microphone battery is low; Microphone volume is too low.	Ensure microphone is on; Charge microphone; Increase microphone volume.
Bluetooth connection fails	Device is too far; Bluetooth is off on source device; Interference.	Move device closer; Enable Bluetooth on source; Restart both devices.
LED lights not working	Lights are turned off; Device malfunction.	Check if there's a button to toggle lights; Contact support if issue persists.

8. SPECIFICATIONS

Feature	Detail
Model	K1-2MIC-PINK
Brand	Darkant
Item Weight	1.12 pounds
Product Dimensions	3.3 x 3.3 x 2.9 inches
Batteries	1 Lithium Ion battery (included)
Compatible Devices	Smartphone
Connector Type	USB (Type-C for charging)
Speaker Count	1
Power Source	Battery Powered
Voltage	5 Volts
Special Feature	Volume Control, Voice Modulation, LED Lights
Recommended Uses	Indoor/Outdoor

9. SAFETY INFORMATION

- Do not disassemble, repair, or modify the device.
- Keep out of reach of small children to prevent choking hazards from small parts.
- Avoid exposing the device to extreme temperatures, direct sunlight, or open flames.

- Use only the provided charging cable or a certified equivalent.
- Dispose of batteries and electronic components responsibly according to local regulations.

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Darkant website. Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0CNW97S48>

More documents and user manuals: <https://manuals.plus/>