

[Manuals.plus](#) /

› [BEILIHART](#) /

› K29 Karaoke Machine (Black 2) User Manual

BEILIHART K29-L

BEILIHART K29 Portable Karaoke Machine

USER MANUAL

1. Introduction

Thank you for purchasing the BEILIHART K29 Portable Karaoke Machine. This compact and versatile system is designed to provide an enjoyable karaoke experience anywhere, anytime. Featuring high-quality sound, wireless microphones, and dynamic LED lights, it's perfect for home entertainment, parties, and gatherings. Please read this manual carefully before use to ensure proper operation and to maximize the lifespan of your device.



This image displays the BEILIHART K29 portable karaoke machine, featuring a compact speaker with a vibrant, multi-color LED light display on the front grille. Two wireless microphones are included, designed for comfortable handling and clear vocal pickup. The speaker has a sturdy handle for easy portability.

2. Package Contents

Please check the package contents upon unboxing to ensure all items are present and in good condition:

- 1 x BEILIHART K29 Karaoke Speaker
- 2 x Wireless Microphones
- 1 x USB Charging Cable
- 1 x User Manual

3. Key Features

- **Superior Sound Quality:** Equipped with a DSP chip for louder and clearer HIFI sound.
- **Dual Wireless Microphones:** Enjoy duets with two included wireless microphones.
- **Multiple Connectivity Options:** Seamlessly connect via Bluetooth, TF Card/USB, or AUX input.
- **Voice Changing Effects:** Five fun voice modes including Monster, Original, Male, Female, and Baby voice.
- **Long Battery Life:** Built-in 1500mAh battery provides 8+ hours of continuous playtime.
- **Dynamic LED Lights:** Controllable dancing lights enhance the party atmosphere.
- **Portable Design:** Compact and lightweight with a convenient handle for easy carrying.



This image provides a concise overview of the BEILIHART K29 Karaoke System's main features: superior sound quality, inclusion of two wireless microphones, fun voice change functions, over 8 hours of continuous playtime, and dynamic LED lights.

LOUDER AND CLEARER SOUND



DSP
Chip



Louder and
Clearer Sound



HIFI
Sound Quality

An exploded view diagram highlighting the advanced sound technology within the K29 karaoke machine. It features a DSP (Digital Signal Processor) chip for enhanced audio processing, ensuring louder and clearer sound output, and HIFI sound quality for an immersive audio experience.

HOME ADVENTURES AMPLIFIED

5 Voice Changes for Family-Friendly Fun!



This graphic highlights the five fun voice-changing effects available on the K29 karaoke machine: Monster Voice, Original Voice, Male Voice, Female Voice, and Baby Voice. These effects allow users to alter their singing voice for entertainment.

CONTROLLABLE DANCING LIGHTS

Singing and dancing under dynamic lights



An image demonstrating the controllable dancing LED lights feature of the K29 karaoke machine. The speaker's front grille illuminates with various colorful patterns that can synchronize with the music, enhancing the party atmosphere.

4. Setup Guide

4.1 Charging the Device

Before first use, fully charge the karaoke speaker and microphones. Connect the USB charging cable to the charging port on the speaker and a compatible USB power adapter (not included). The charging indicator will show the charging status. Do the same for the microphones.

4.2 Powering On/Off

- **Speaker:** Press and hold the power button on the speaker for a few seconds until the LED lights illuminate.
- **Microphones:** Press and hold the power button on each microphone until the indicator light turns on.

4.3 Connecting to Audio Source

The K29 offers multiple ways to connect to your audio source:

1. Bluetooth Connection:

- Turn on the K29 speaker. It will automatically enter Bluetooth pairing mode.
- On your device (smartphone, tablet, laptop), enable Bluetooth and search for "K29".
- Select "K29" from the list to pair. A confirmation sound will indicate successful connection.

2. AUX Input:

- Connect one end of a 3.5mm audio cable (not included) to the AUX port on the K29 speaker.
- Connect the other end to the headphone jack or audio output of your device.

3. TF Card/USB Playback:

- Insert a TF card or USB drive containing MP3 audio files into the respective slot on the speaker.
- The speaker will automatically detect and begin playing music from the storage device.



This image illustrates the versatile connectivity options of the K29 karaoke machine, including Bluetooth for wireless pairing, TF Card/USB

input for local media playback, and an AUX port for wired connections to devices like cellphones, laptops, or iPads. The image also indicates the compact dimensions of the speaker: 3.5 inches (length) x 3.5 inches (width) x 3.15 inches (height).

5. Operating Instructions

5.1 Speaker Controls

- **Power Button:** Long press to power on/off. Short press to switch modes (Bluetooth/AUX/TF/USB).
- **Volume Up (+):** Increase speaker volume.
- **Volume Down (-):** Decrease speaker volume.
- **Play/Pause (▶):** Play or pause music playback.
- **LED Light Button (M):** Short press to cycle through LED light modes or turn off lights.

5.2 Microphone Controls

- **Power Button:** Long press to power on/off.
- **Volume Up (+):** Increase microphone volume.
- **Volume Down (-):** Decrease microphone volume.
- **Voice Change Button (Microphone Icon):** Short press to cycle through the five voice changing effects.

5.3 Using Voice Changing Effects

With the microphone powered on, short press the Voice Change button (microphone icon) to cycle through the available voice effects: Original, Male, Female, Baby, and Monster. Select the desired effect for your performance.

6. Care and Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surface of the speaker and microphones. Do not use abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Water Exposure:** This device is not waterproof. Avoid exposure to water or high humidity.
- **Handling:** Handle the speaker and microphones with care. Avoid dropping or subjecting them to strong impacts.

7. Troubleshooting

Problem	Possible Cause	Solution
No sound from speaker.	Speaker is off; Volume is too low; Not connected to audio source; Audio source volume is low.	Ensure speaker is on; Increase speaker volume; Verify Bluetooth/AUX/TF/USB connection; Increase volume on connected device.
Microphone not working.	Microphone is off; Microphone battery is low; Microphone not paired with speaker.	Ensure microphone is on; Charge microphone; Microphones should automatically pair with the speaker when both are powered on. If not, power cycle both devices.
Cannot connect via Bluetooth.	Speaker not in pairing mode; Bluetooth disabled on device; Device too far from speaker.	Ensure speaker is in Bluetooth mode (blue indicator light); Enable Bluetooth on your device; Move device closer to speaker (within 10 meters).

Problem	Possible Cause	Solution
LED lights not working.	Lights turned off; Malfunction.	Press the 'M' button on the speaker to cycle through light modes or turn them on. If issue persists, contact support.

8. Specifications

Feature	Detail
Model Number	K29-L
Brand	BEILIHART
Dimensions (L x W x H)	8.9 x 8.9 x 8 centimeters (approx. 3.5 x 3.5 x 3.15 inches)
Color	Black (Marronea10201)
Power Source	Battery Powered
Number of Channels	2
Recommended Use	Home
Battery Capacity	1500mAh (Speaker)
Playtime	8+ hours
Connectivity	Bluetooth, TF Card, USB, AUX

ENJOY FAMILY PARTY ANYTIME, ANYWHERE



8H+
Using time

Easy
to carry

1500mAh



An image showcasing the K29 karaoke machine's portability and extended battery life. It features an 8+ hour usage time on a single charge, powered by a 1500mAh battery, making it ideal for parties and travel. The compact design ensures it is easy to carry.

9. Warranty and Support

Specific warranty information for the BEILIHART K29 Portable Karaoke Machine is not provided in this manual. Please refer to the product packaging, the retailer's return policy, or the official BEILIHART website for detailed warranty terms and conditions.

For technical support, troubleshooting assistance beyond what is covered in this manual, or inquiries about spare parts, please contact BEILIHART customer service through their official channels. Contact information is typically available on the product packaging or the manufacturer's website.

© 2023 BEILIHART. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CNX6MMK3>

More documents and user manuals: <https://manuals.plus/>