

Brookstone BSBTH22

Brookstone Wireless Silent Disco Headphones Instruction Manual

Model: BSBTH22

Brand: Brookstone

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Brookstone Wireless Silent Disco Headphones. Designed for a vibrant and immersive audio experience, these headphones feature multicolor LED lights, Bluetooth 5.0 connectivity, and up to 10 hours of playtime. Please read this manual thoroughly to ensure optimal performance and longevity of your device.

PRODUCT FEATURES

- **4 Pack of Wireless Bluetooth Headphones:** Each pack includes 4 headphones, allowing you to enjoy a private listening experience with friends.
- **Up to 100-Meter Range:** With a wireless range of up to 100 meters, you can move freely without worrying about signal loss.
- **Rainbow LED Lights:** The headphones feature vibrant rainbow LED lights that sync to the music, creating a fun and immersive party atmosphere.
- **Bluetooth Connectivity:** Easily connect your smartphone or other Bluetooth-enabled devices to the headphones for wireless streaming.
- **Up to 10 Hours of Playtime:** Enjoy uninterrupted music playback for up to 10 hours on a single charge.

PRODUCT OVERVIEW



Figure 1: Overview of the Brookstone Wireless Silent Disco Headphones, showcasing their vibrant LED lights.

MULTI-DEVICE CONNECTIVITY



Figure 2: Illustration of multi-device connectivity, where one master headset can broadcast audio to other headsets.

CREATE A SHARED AUDIO EXPERIENCE



Figure 3: A family enjoying a shared audio experience with the headphones, highlighting the "Create a Shared Audio Experience" feature.

MULTICOLORED AMBIENCE



The LED headsets glow with vibrant, color-changing lights, complemented by a beautiful metallic finish

Figure 4: Detailed view of the headphone's multicolored LED lights, illustrating the "Multicolored Ambience" feature.

LISTEN SIMULTANEOUSLY WITH FRIENDS

Connect with wireless Bluetooth technology to enjoy an intimate listening party with friends



Figure 5: Children using the headphones together, demonstrating the "Listen Simultaneously with Friends" capability.



SYNCHRONIZED LISTENING

Get together with a friend and enjoy your favorite music simultaneously, with 4 LED headsets included

Figure 6: Adults engaged in synchronized listening with the headphones, highlighting the shared experience.

SETUP GUIDE

1. Charging the Headphones

Before first use, fully charge your headphones. Connect the included USB charging cable to the charging port on the headphone and plug the other end into a USB power source (e.g., computer, wall adapter). The LED indicator will show charging status and turn off when fully charged.

2. Powering On/Off

To power on, press and hold the Power button until the LED lights illuminate. To power off, press and hold the Power button again until the lights turn off.

3. Bluetooth Pairing

1. Ensure the headphones are powered off.

2. Press and hold the Power button for approximately 5-7 seconds until the LED indicator flashes rapidly, indicating pairing mode.
3. On your Bluetooth-enabled device (smartphone, tablet, etc.), go to the Bluetooth settings and turn Bluetooth on.
4. Search for "Brookstone Headphones" (or similar name) in the list of available devices and select it to connect.
5. Once successfully paired, the LED indicator will stop flashing and remain solid or change to a different pattern.

4. Multi-Headphone Setup (Silent Disco Mode)

These headphones support multi-channel audio for silent disco events. One headphone acts as the master, broadcasting audio to other paired headphones. Refer to the specific instructions provided with your silent disco transmitter (sold separately) for detailed setup of multiple headphones on different channels.

OPERATING INSTRUCTIONS

1. Audio Playback

- **Play/Pause:** Press the Play/Pause button once.
- **Next Track:** Press and hold the Volume Up button.
- **Previous Track:** Press and hold the Volume Down button.

2. Volume Control

- **Increase Volume:** Press the Volume Up button.
- **Decrease Volume:** Press the Volume Down button.

3. LED Light Control

The headphones feature vibrant LED lights. Consult the specific button on your headphone (often labeled "Light" or a dedicated button) to cycle through different light modes or turn them off/on.

4. Making/Receiving Calls

With the built-in microphone, you can manage calls when connected to your smartphone.

- **Answer/End Call:** Press the Multi-function button (often the Play/Pause button) once.
- **Reject Call:** Press and hold the Multi-function button.
- **Redial Last Number:** Double-press the Multi-function button.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the Brookstone Silent Disco Wireless Headphones and their features.

MAINTENANCE AND CARE

- Keep the headphones dry. Do not expose them to moisture or extreme temperatures.
- Clean the earcups and headband with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store the headphones in a cool, dry place when not in use.
- Avoid dropping or subjecting the headphones to strong impacts.
- Do not attempt to disassemble or modify the headphones, as this will void the warranty.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones won't turn on.	Low battery.	Charge the headphones fully.
Cannot pair with device.	Bluetooth is off on device; headphones not in pairing mode; too far from device.	Ensure Bluetooth is on; put headphones in pairing mode; move closer to device (within 100m).
No sound or low volume.	Volume too low on headphones or device; not properly paired.	Increase volume on both headphones and device; re-pair the headphones.
LED lights not working.	Lights turned off; low battery.	Press the LED light control button; charge the headphones.

SPECIFICATIONS

Feature	Detail
Model Name	BSBTH22
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Age Range (Description)	Adult
Material	Plastic
Compatible Devices	Smartphones
Control Type	Volume Control
Cable Feature	Without Cable
Water Resistance Level	Not Water Resistant
Frequency Range	20 Hz to 20,000 Hz
Unit Count	4.0 Count
Control Method	App
Number of Items	4
Battery Life	10 Hours
Audio Driver Type	Dynamic Driver
Bluetooth Range	100 Meters
Bluetooth Version	5.0
Earpiece Shape	Round
Manufacturer	Southern Telecom Inc

Feature	Detail
Package Dimensions	17.24 x 14.53 x 8.74 inches
Item Weight	3.56 pounds
Color	Multi
Ear Placement	Over Ear
Form Factor	Over Ear
Noise Control	None

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official Brookstone website. Keep your purchase receipt as proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question