Baseus A00061900113-Z1

Baseus Bowie E16 True Wireless Bluetooth Headphones User Manual

Model: A00061900113-Z1

Introduction

Thank you for choosing the Baseus Bowie E16 True Wireless Bluetooth Headphones. These headphones are designed to provide a high-quality audio experience with advanced features such as low sound latency and extended battery life. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new device.



This image displays the Baseus Bowie E16 True Wireless Bluetooth Headphones. The black charging case is open, revealing both earbuds nestled inside. The left earbud is partially visible, while the right earbud is fully seated in its charging slot. The Baseus logo is visible on the left earbud stem. A small LED indicator light is visible on the front edge of the charging case, indicating its status.

Setup

1. Unboxing and Initial Charge

Carefully remove all components from the packaging. The package includes the Baseus Bowie E16 True Wireless Bluetooth Headphones and their Wireless Charging Case. Before first use, fully charge the charging case and earbuds.

- Place both earbuds into the charging case.
- Connect the charging case to a power source using a compatible USB cable (not included).
- The indicator light on the case will show charging status and turn off or change color when fully charged.

2. Pairing with Your Device

1. Ensure the earbuds are in the charging case and the case lid is open.

2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for new Bluetooth devices. The headphones will appear as "Baseus Bowie E16".
4. Select "Baseus Bowie E16" from the list to connect.
5. Once connected, a voice prompt will confirm successful pairing.

Operating Instructions

Power On/Off

- **Power On:** Open the charging case lid, or take the earbuds out of the case. They will automatically power on and attempt to reconnect to the last paired device.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically disconnect and power off.

Music Playback Controls

- **Play/Pause:** Double-tap either earbud.
- **Next Track:** Triple-tap the right earbud.
- **Previous Track:** Triple-tap the left earbud.
- **Volume Up:** Press and hold the right earbud.
- **Volume Down:** Press and hold the left earbud.

Call Management

- **Answer/End Call:** Double-tap either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.

Low Latency Mode

The Baseus Bowie E16 features a low latency mode, ideal for gaming or watching videos, to minimize audio delay.

- **Activate/Deactivate:** Refer to the Baseus app or specific product documentation for the exact gesture or setting to toggle low latency mode.

Maintenance

Cleaning

- Use a soft, dry, lint-free cloth to clean the earbuds and charging case.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Gently remove any earwax or debris from the earbud tips and speaker mesh using a small, soft brush or cotton swab.

Storage

- Store the headphones in their charging case when not in use to protect them and keep them charged.
- Avoid storing in extreme temperatures (hot or cold) or in highly humid environments.

Battery Care

- Charge the headphones regularly, even if not used frequently, to maintain battery health.
- Avoid fully discharging the battery for extended periods.

Troubleshooting

Cannot Pair with Device

- Ensure Bluetooth is enabled on your device.
- Make sure the earbuds are charged and out of the case, or the case lid is open.
- Move the headphones closer to your device.
- Forget "Baseus Bowie E16" from your device's Bluetooth settings and try pairing again.
- Restart both your device and the headphones (by placing them in the case and closing/opening the lid).

No Sound or Low Volume

- Check the volume level on both your device and the headphones.
- Ensure the headphones are properly connected to your device.
- Clean any debris from the earbud speaker mesh.
- Try playing audio from a different application or source.

Charging Issues

- Ensure the charging cable is securely connected to both the case and the power source.
- Try a different charging cable or power adapter.
- Make sure the charging contacts on the earbuds and inside the case are clean and free of debris.

Connection Drops Frequently

- Ensure there are no significant obstacles between the headphones and your device.
- Avoid strong electromagnetic interference from other devices.
- Keep the headphones within the effective Bluetooth range (typically 10 meters/33 feet).

Specifications

Brand	Baseus
Model Name	Baseus Bowie E16 True Wireless Bluetooth Headphones
Model Number	A00061900113-Z1
Connectivity Technology	Wireless (Bluetooth 5.3)
Form Factor	True Wireless
Color	Black
Special Features	Low Sound Latency, Noise Cancellation (as per product specifications)
Battery Life	Up to 30 Hours (with charging case)
Included Components	Wireless Charging Case
Item Weight	90 g
Package Dimensions	10.5 x 9.5 x 4.6 cm

Warranty and Support

Baseus products are covered by a limited warranty. For detailed warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Baseus website. Please retain your proof of purchase for warranty claims.
For further assistance, you may contact Baseus customer support through their official channels.

© 2024 Baseus. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question