

DOOGEE T30 Pro

DOOGEE T30 PRO Android Tablet User Manual

Model: T30 Pro

Brand: DOOGEE

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your DOOGEE T30 PRO Android Tablet. Please read this manual thoroughly before using the device and retain it for future reference. The DOOGEE T30 PRO is an advanced Android 13 tablet featuring an 11-inch 2.5K display, MediaTek Helio G99 Octa-Core processor, 15GB RAM, 256GB storage, Hi-Res quad speakers, and a 20MP camera. It is designed for both productivity and entertainment, with features like TÜV Low BlueLight certification for eye protection and Widevine L1 support for high-definition streaming.

2. WHAT'S IN THE BOX

Verify that all items are present in the package:

- Tablet
- Charger
- Data line
- Card removal needle
- Manual

3. PRODUCT OVERVIEW



Figure 3.1: Front and rear view of the DOOGEE T30 PRO tablet, highlighting its sleek design and camera module.

11" 2.5K Ultra-High Resolution Screen




2560*1600
WQHD Display



16.8
Million Colors



350nit
Peak brightness



2560*1600 VS 2000*1200

Figure 3.2: The 11-inch 2.5K (2560x1600) ultra-high resolution display, showcasing vibrant colors and sharp detail.

Monster Battery & Slim Body

8580mAh Long Battery Life

8580mAh



33w
Fast Charging



543g
Lightweight



7.6mm
Ultra-thin

Figure 3.3: Internal view illustrating the large 8580mAh battery, designed for extended usage and supported by 33W fast charging.

**Keep the focus on you
and your movements**

Be the center of attention
no matter where you are



20MP
Main Camera



8MP
Front Camera



Figure 3.4: Details of the 20MP main camera and 8MP front camera, suitable for capturing photos and video calls.

Brilliant Audio & Powerful Connectivity



2.4G/5G Wifi



Dual 4G Sim



Bluetooth 5.2



Quad Speakers




Figure 3.5: Overview of the Hi-Res quad speakers and connectivity features including 2.4G/5G WiFi, Dual 4G SIM, and Bluetooth 5.2.

4. SETUP

4.1 Initial Power On

1. Press and hold the power button located on the side of the tablet until the DOOGEE logo appears on the screen.
2. Follow the on-screen prompts to select your language, region, and connect to a Wi-Fi network.
3. Sign in with your Google account or create a new one to access the Google Play Store and other services.

4.2 Charging the Tablet

Before first use, fully charge the tablet. Use the provided charger and data cable.

1. Connect the USB Type-C end of the data cable to the tablet's charging port.
2. Connect the other end of the data cable to the charger.
3. Plug the charger into a power outlet. The charging indicator will appear on the screen.

The tablet supports 33W fast charging.

4.3 Inserting SIM/MicroSD Card

The tablet supports Dual 4G SIM and MicroSD card expansion up to 2TB.

1. Locate the SIM/MicroSD card tray on the side of the tablet.
2. Insert the card removal needle into the small hole next to the tray to eject it.
3. Place the SIM card(s) and/or MicroSD card into the tray with the gold contacts facing down, ensuring correct orientation.
4. Gently push the tray back into the slot until it clicks into place.

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation

- **Touch:** Tap icons or options to select.
- **Swipe:** Drag your finger across the screen to scroll or navigate between screens.
- **Pinch-to-Zoom:** Use two fingers to zoom in or out on images and web pages.

5.2 Split Screen Functionality

The DOOGEE T30 PRO supports split-screen mode for enhanced multitasking.

1. Open the first application you wish to use.
2. Swipe up from the bottom of the screen and hold to access recent apps.
3. Tap the app icon at the top of the first app's preview and select "Split screen".
4. Choose the second application from your recent apps or app drawer to open it in the other half of the screen.

Your browser does not support the video tag.

Video 5.1: Demonstration of the split-screen feature for improved productivity on the DOOGEE T30 PRO tablet.

5.3 Connecting a Magnetic Keyboard

Transform your tablet into a laptop with the optional magnetic keyboard.

1. Align the magnetic connectors on the tablet with those on the keyboard.
2. The tablet will automatically snap into place and connect to the keyboard.
3. No additional pairing is required.

5.4 Using the Sensitive Stylus

The tablet supports a sensitive stylus with 2048 pressure levels for drawing and writing.

- Simply touch the stylus to the screen to interact with compatible applications.
- Pressure sensitivity allows for varied line thickness and shading in drawing apps.

6. MAINTENANCE

6.1 Cleaning the Tablet

- Use a soft, lint-free cloth to wipe the screen and body of the tablet.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner.
- Avoid using harsh chemicals, abrasive materials, or aerosol sprays.

6.2 Battery Care

- Avoid exposing the tablet to extreme temperatures (hot or cold).
- Do not allow the battery to fully discharge frequently. Charge it before it drops below 20%.
- If storing the tablet for an extended period, charge it to about 50% and power it off.

6.3 Software Updates

Regularly check for and install software updates to ensure optimal performance and security.

1. Go to **Settings > System > System update**.
2. Follow the on-screen instructions to download and install any available updates.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Tablet does not power on.	Low battery; software crash.	Charge the tablet for at least 30 minutes. Press and hold the power button for 10-15 seconds to force restart.
Screen is unresponsive.	Temporary software glitch.	Force restart the tablet. If issue persists, perform a factory reset (data will be lost).
Wi-Fi connection issues.	Incorrect password; router issue; tablet Wi-Fi module issue.	Forget the network and reconnect. Restart your Wi-Fi router. Ensure tablet is within range.
Apps are crashing or freezing.	Insufficient RAM; app bug; outdated software.	Close background apps. Clear app cache/data. Update the app or tablet software.

8. SPECIFICATIONS

Feature	Detail
Model	T30 Pro
Operating System	Android 13
Display Size	11 Inches
Screen Resolution	2560 x 1600 pixels (2.5K)
Processor	MediaTek Helio G99 Octa-Core (2.2 GHz)
RAM	15 GB (8GB physical + 7GB expandable virtual RAM)
Internal Storage	256 GB (Expandable up to 2TB via MicroSD)
Rear Camera	20 MP
Front Camera	8 MP
Battery Capacity	8580 mAh
Charging	33W Fast Charging
Audio	Hi-Res Quad Speakers
Connectivity	2.4G/5G WiFi, Dual 4G SIM, Bluetooth 5.2
Eye Protection	TÜV SÜD Certified Low BlueLight
Dimensions (LxWxH)	10.2 x 3 x 6.7 inches
Item Weight	1.19 pounds

9. WARRANTY AND SUPPORT

DOOGEE provides the following support for your T30 PRO tablet:

- **30-Days Money Back Guarantee and Free Return:**For initial purchase satisfaction.
- **2-Years Limited Warranty:** Covers manufacturing defects and hardware malfunctions under normal use.
- **24/7 One-on-One Online Support:** For technical assistance and inquiries.

For detailed warranty terms and to contact support, please visit the official DOOGEE website or refer to the warranty card included in your package.


[illegible]

[\[pdf\]](#) User Manual Specifications Dimension Guide Accessories

T30 Pro P3Pro Specification 20230616 Global Sources PRO TABLET PC · TÜV SÜD blue light certification -Conforms to High Resolution Audio standards defined by the Japan Association Docking plug in K1202249169 p globalsources IMAGES PDT SPEC 169 |||

DOOGEE **T30 PRO** TABLET PC TV SD blue light certification Conforms to High-Resolution Audio standards ... t Charger Data line Card removal needle Manual TPU leather case Space Gray / Mint Green / Ice Blue **T30 Pro** Android 13.0 Grey / Green / Blue N/A 257*168.7*7.6mm IPS 2.5K 11 inchs 1600*2560 374 Full an...


lang:en score:20 filesize: 85.73 K page_count: 1 document date: 2023-06-16



[DOOGEE T30 PRO Tablet User Manual](#)

Comprehensive user manual for the DOOGEE T30 PRO tablet, covering setup, basic operations, safety guidelines, and maintenance. Includes instructions in multiple languages.

lang:en **score:17** filesize: 2.07 M page_count: 14 document date: 2023-04-11




[\[pdf\]](#)

Náhled * souboru s návodem k obsluze NÁVOD K OBSLUZE Dotykový tablet Doogee T30 Pro LTE
Databáze návodů v češtině dotykovy doogee t30 pro lite 8 gb 256 sedy 117935 locked navod cz preview
118 |||

T30 Series English 04 03 05 06 07 08 09 10 02 11 12 13 01 14 16 15 01: Speaker 02: Speaker 03: Power Button 04: Restart Button 05: Volume Button 06: Main Microphone 07: Front Camera 08: Light Sensor 09: Charging Indicator 10: 3.5 Headphone Jack 11: Speaker 12: SIM/TF Card 13: Type-C P...

lang:en **score:13** filesize: 566.41 K page_count: 4 document date: 2023-08-16



[DOOGEE Tablet User Manual](#)

User manual for the DOOGEE tablet, covering setup, messaging, language settings, safety, and maintenance.

lang:en **score:13** filesize: 1.7 M page_count: 12 document date: 2023-04-06



[SonarPen: Guida alla Compatibilità con Dispositivi Apple, Android, Windows, Chromebook e Nintendo Switch](#)

Scopri quali dispositivi Apple, Android, Windows, Chromebook e Nintendo Switch sono compatibili con SonarPen. Trova le informazioni necessarie per utilizzare la tua penna stylus su diverse piattaforme.

lang:it **score:12** filesize: 938.5 K page_count: 24 document date: 2024-01-10



[SonarPen Device Compatibility Guide - Apple, Android, Windows, Chromebook, Nintendo Switch](#)

Comprehensive guide to SonarPen compatibility across Apple iOS/iPadOS, Android OS, Windows 10/11, Chromebook, and Nintendo Switch devices. Learn about required adapters and calibration for optimal performance.

lang:en score:12 filesize: 936.89 K page_count: 24 document date: 2024-01-10



[SonarPen Compatible Devices List](#)

A comprehensive list of devices compatible with SonarPen, including Apple, Android, and Nintendo Switch devices. Find the right SonarPen model for your device.

lang:de score:12 filesize: 941.43 K page_count: 24 document date: 2024-01-10



[SonarPen Compatible Devices: A Comprehensive Guide](#)

Discover which Apple, Android, Windows, and Chromebook devices are compatible with the SonarPen stylus. This guide lists supported models across numerous brands, ensuring you find the perfect match for your digital drawing and note-taking needs.

lang:es score:12 filesize: 939.47 K page_count: 24 document date: 2024-01-10



[SonarPen Compatible Devices Guide](#)

Discover the full range of devices compatible with SonarPen, including Apple, Android, and Windows devices. Learn how to connect and use your SonarPen for an enhanced digital art experience.

lang:fr score:12 filesize: 941.02 K page_count: 24 document date: 2024-01-10

