Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SteFik zhangmeifengf

SteFik Vacuum Docking Station User Manual

Comprehensive guide for your Roborock S7, S70, S75, S8 series vacuum cleaner docking station.

Product Overview

This document provides instructions for the SteFik Vacuum Docking Station, designed specifically for Roborock S7, S70, S75, and S8 series robotic vacuum cleaners. This docking station serves as a charging base and a home for your robotic vacuum.

Key features of this docking station include:

- Compatibility with Roborock S7, S70, S75, S8 robotic vacuums.
- Designed for efficient and stable charging.
- Integrated design for neat storage of the vacuum cleaner.
- Safety mechanisms including overcharge and short circuit protection.



Image: The SteFik Vacuum Docking Station in white, showcasing its compact design and the included power cord. This is the primary component for charging and housing your compatible Roborock vacuum.

Setup

Follow these steps to set up your new vacuum docking station:

1. **Choose a Location:** Select a flat, stable surface against a wall with clear space around it. Ensure there are no obstacles within 1.5 meters (5 feet) in front of the dock and 0.5 meters (1.6 feet) on either side to allow the robot vacuum to easily return for charging.
2. **Connect Power:** Plug the power adapter (if separate) into the docking station's power input port. Then, plug the power cord into a standard electrical outlet. Ensure the power cord is neatly tucked away to prevent entanglement.



Image: An angled view of the white SteFik Vacuum Docking Station, highlighting its sleek design and the charging contact points. This view helps in understanding the physical layout for placement.

3. **Position the Dock:** Place the docking station firmly against the wall. The station should not be moved frequently once set up.
4. **Initial Charging:** Place your compatible Roborock S7/S8 series vacuum cleaner onto the docking station. Ensure the charging contacts on the vacuum align with those on the dock. The vacuum should indicate that it is charging. Allow for a full charge before initial use.




Image: A close-up view of the charging contacts and a small brush on the white docking station. This detail shows the precise points where the robot vacuum connects for charging and potential debris removal.

Operating the Docking Station

The SteFik Vacuum Docking Station operates automatically once properly set up with your Roborock vacuum cleaner.

- **Automatic Return:** Your Roborock vacuum cleaner is programmed to automatically return to the docking station when its battery is low or after completing a cleaning cycle.
- **Charging Indicator:** Refer to your Roborock vacuum cleaner's user manual for specific charging indicator lights or sounds, as the docking station itself does not have external indicators.
- **Continuous Power:** Keep the docking station plugged into a power outlet at all times to ensure the vacuum can charge whenever it returns.



Image: A direct front view of the black SteFik Vacuum Docking Station, showing the charging bay and contact points. This perspective is useful for understanding how the vacuum aligns with the dock.

Maintenance

Regular maintenance ensures optimal performance and longevity of your docking station.

- **Cleaning the Charging Contacts:** Periodically inspect the metal charging contacts on the docking station and on the robot vacuum. Use a clean, dry cloth to wipe away any dust or debris that may accumulate. Do not use water or cleaning solutions directly on the contacts.
- **Cleaning the Docking Station:** Wipe the exterior of the docking station with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Power Cord Inspection:** Regularly check the power cord for any signs of damage, fraying, or kinks. If any damage is found, discontinue use and contact the seller for assistance.




Image: A detailed close-up of the charging contacts and the small cleaning brush on the black version of the docking station. This highlights the areas that require periodic cleaning to ensure proper electrical connection.

Troubleshooting

If you encounter issues with your docking station, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Robot vacuum not charging when docked.	Docking station not powered. Charging contacts are dirty. Robot vacuum not properly aligned.	Ensure the power cord is securely plugged into the wall outlet and the docking station. Clean the charging contacts on both the dock and the robot vacuum with a dry cloth. Manually place the robot vacuum onto the dock, ensuring proper alignment.
Robot vacuum cannot find the docking station.	Docking station location is obstructed. Docking station moved from its original position.	Clear any obstacles around the docking station (1.5m in front, 0.5m on sides). Ensure the docking station is placed against a wall and has not been moved.
Docking station appears damaged.	Physical damage or wear.	Discontinue use immediately. Contact the seller or manufacturer for repair or replacement options.

For further assistance, please refer to your Roborock vacuum cleaner's user manual or contact SteFik customer support.

Specifications

Feature	Detail
Product Name	Vacuum Docking Station
Brand	SteFik
Model Compatibility	Roborock S7, S70, S75, S8 Robotic Vacuums
Rated Power	28W
Rated Input	100-240VAC
Rated Output	20VDC 1.2A
Dimensions (Package)	1.18 x 0.79 x 0.39 inches
Item Weight	1.76 ounces
Assembly Required	No
Certifications	CE

Warranty and Support

For warranty information, please refer to the documentation provided at the time of purchase or contact the seller directly. SteFik aims to provide high-quality products and customer satisfaction.
If you have any questions, require technical support, or need assistance with your SteFik Vacuum Docking Station, please contact the seller through the platform where the purchase was made. They are equipped to help you with any issues or inquiries.

© 2024 SteFik. All rights reserved. Roborock is a registered trademark of its respective owners.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CNZ29FJV

More documents and user manuals: **https://manuals.plus/**