

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DOOGEE](#) /

› [DOOGEE U7 Kids Tablet User Manual](#)

## DOOGEE U7

# DOOGEE U7 Kids Tablet User Manual

Model: U7 | Brand: DOOGEE

## 1. INTRODUCTION

---

Welcome to the DOOGEE U7 Kids Tablet user manual. This guide provides essential information on setting up, operating, maintaining, and troubleshooting your new tablet. Designed specifically for children, the DOOGEE U7 combines educational and entertainment features with robust parental controls and a durable, child-friendly design.

Please read this manual thoroughly to ensure safe and optimal use of your device.

## 2. PACKAGE CONTENTS

---

Upon opening the package, please verify that all the following items are included:

- 1 x DOOGEE U7 Kids Tablet (with pre-applied anti-explosion film)
- 1 x Protective Shockproof Case
- 1 x Charger
- 1 x Data Cable (USB)
- 1 x User Manual
- 1 x Capacitive Pen



*Image: The DOOGEE U7 Kids Tablet, charger, data cable, and capacitive pen as included in the package.*

### 3. PRODUCT OVERVIEW

---

The DOOGEE U7 Kids Tablet features a 7-inch display housed within a durable, shockproof case designed to withstand daily use by children. The case includes integrated handles for easy carrying and a built-in kickstand for hands-free viewing.

#### 3.1 Front View

# DOOGEE Kids Tablet 7 Inch IPS HD Screen

Comes with an 7-inch tablet. Provides better viewing for watching TV or playing games.




*Image: Front view of the DOOGEE U7 Kids Tablet, showcasing the 7-inch screen and the protective pink case with handles.*

## 3.2 Rear View and Ports

The tablet is equipped with dual cameras (front and rear) for photos and video calls. Essential ports, including the charging port and microSD card slot, are located on the sides, often protected by the case design.

# Google GMS Certified



*Image: Rear view of the DOOGEE U7 Kids Tablet, highlighting the rear camera, kickstand, and port locations within the protective case.*

## 4. SETUP

### 4.1 Initial Charging

Before first use, fully charge the tablet. Connect the provided data cable to the tablet's charging port and the charger to a power outlet. The battery indicator on the screen will show charging status.

### 4.2 Power On/Off

- **To Power On:** Press and hold the Power button (usually on the side) until the screen lights up.
- **To Power Off:** Press and hold the Power button until a power-off menu appears. Select 'Power off' or 'Shut down'.

### 4.3 Initial Configuration

Upon first power-on, you will be guided through the initial setup process:

1. Select your preferred language.

2. Connect to a Wi-Fi network. This is crucial for downloading apps and updates.
3. Follow the on-screen prompts to set up your Google account or create a new one. This is necessary for accessing the Google Play Store.
4. Review and accept the terms and conditions.

For a visual guide on the tablet's features and setup, please refer to the video below:

*Video: An overview of a DOOGEE kids tablet, demonstrating its physical features like the kickstand, camera, and ports. While the video refers to a Q8K model, the features shown are representative of the DOOGEE U7 Kids Tablet's design and functionality.*

## 5. OPERATING THE TABLET

### 5.1 Parental Control Setup

The DOOGEE U7 features a dedicated parental control mode to ensure a safe and educational environment for children. This mode allows you to:

- Create and manage profiles for each child.
- Select and filter content appropriate for their age.
- Control screen time and set usage limits.
- Restrict access to unsafe websites and applications.

Access parental controls through the dedicated app or settings menu to customize these features.



*Image: A mother and child interacting with the DOOGEE U7 Kids Tablet, illustrating the ease of use for parental control features.*

### 5.2 Navigating the Interface

The tablet runs on Android 10 (Go Edition), offering a user-friendly interface. Use touch gestures to navigate:

- **Tap:** To select an item or open an app.
- **Swipe:** To scroll through pages or menus.
- **Pinch:** To zoom in or out on images and web pages.

### 5.3 Installing and Managing Apps

The tablet comes with various preloaded educational and entertainment apps. You can download more

applications from the Google Play Store. Ensure parental controls are configured to manage app access and purchases.

## 4GB RAM+32GB ROM (Up to 1TB)

Fun with 32GB for more photos, files, movies, and games with RAM expansion technology

4GB RAM

32GB ROM

Android 10



*Image: The DOOGEE U7 Kids Tablet screen showing a selection of pre-installed applications, including drawing, coloring, and album apps.*

### 5.4 Storage Management

The tablet includes 32GB of internal storage. You can expand this storage up to 128GB using a microSD card (not included) to store more photos, videos, and games.

### 5.5 Camera Usage

The tablet features dual cameras. Open the Camera app to take photos or record videos. The front camera is suitable for video calls, while the rear camera can be used for capturing moments.

# 3400mAh Long Battery Life



*Image: A child engaged with the DOOGEE U7 Kids Tablet, demonstrating its use for educational and entertainment purposes.*

## 6. MAINTENANCE

---

### 6.1 Cleaning

To clean the tablet screen, use a soft, lint-free cloth. For the protective case, a damp cloth with mild soap can be used. Avoid harsh chemicals or abrasive materials.

### 6.2 Battery Care

To prolong battery life:

- Avoid extreme temperatures.
- Do not let the battery fully drain frequently.
- Charge the tablet using the provided charger and cable.

### 6.3 Software Updates

Periodically check for software updates in the tablet's settings menu (System > System update). Updates

can improve performance, add new features, and enhance security.

## 7. TROUBLESHOOTING

---

If you encounter issues with your DOOGEE U7 Kids Tablet, refer to the following common solutions:

- **Tablet not turning on:** Ensure the tablet is charged. Connect it to the charger for at least 30 minutes, then try powering it on again.
- **Screen frozen or unresponsive:** Press and hold the Power button for about 10-15 seconds to force a restart.
- **Wi-Fi connection issues:** Check if other devices can connect to the Wi-Fi network. Restart your router and the tablet. Re-enter the Wi-Fi password.
- **Apps crashing or not loading:** Clear the app's cache and data in Settings > Apps. If the issue persists, uninstall and reinstall the app.
- **Slow performance:** Close unused apps, clear cache, and consider removing unnecessary files or apps to free up storage.

If problems persist, contact customer support for further assistance.

## 8. SPECIFICATIONS

---

Key technical specifications for the DOOGEE U7 Kids Tablet:

Feature	Specification
Display Size	7 Inches
Screen Resolution	1024x600 IPS FHD
Operating System	Android 10
Processor Brand	Unisoc
RAM	4GB (includes RAM expansion technology)
Internal Storage	32GB (expandable up to 128GB via microSD card)
Rear Camera	2 MP
Battery Capacity	3400mAh
Connectivity	Wi-Fi (802.11g), Bluetooth
Item Weight	1.76 pounds
Product Dimensions	10 x 2 x 7 inches

# DOOGEE U7 Kids Tablet



4(2+2)GB  
32GB

7 Inch  
1024\*600

32GB ROM / UFS  
Storage Expansion 1 TB

3400mAh  
Large Battery


*Image: Visual representation of key specifications for the DOOGEE U7 Kids Tablet, including screen size, resolution, battery, and storage.*

## 9. WARRANTY AND SUPPORT

The DOOGEE U7 Kids Tablet comes with a **1-year warranty** from the date of purchase. Additionally, DOOGEE offers **lifetime customer service** to assist you with any questions or issues you may encounter. For warranty claims, technical support, or any other inquiries, please refer to the contact information provided on the DOOGEE official website or your purchase documentation. Our customer service team aims to respond to all questions within 24 hours.

### Related Documents - U7

 <a href="#">User Manual</a> Scan the QR code for more function information	<a href="#">DOOGEE U10 Series Tablet User Manual and Safety Guide</a> Comprehensive user manual for the DOOGEE U10 Series tablet, covering essential operations, safety guidelines, maintenance tips, and FCC compliance information. Learn how to set up your device, send messages, manage settings, and ensure safe usage.
 <a href="#">User Manual</a> Scan the QR code for more function information	<a href="#">DOOGEE U10 Series Tablet User Manual and Safety Guide</a> Comprehensive user manual for the DOOGEE U10 Series tablet, covering device overview, TF card insertion, booting, SMS/MMS, language settings, SAR information, safety guidelines, and maintenance tips to ensure safe and effective use.
 <a href="#">User Manual</a> Scan the QR code for more function information	<a href="#">DOOGEE TABE3MAX User Manual</a> Comprehensive user manual for the DOOGEE TABE3MAX tablet, covering setup, basic operations, safety precautions, maintenance, and technical specifications.

	<p><b><a href="#">DOOGEE T30 PRO Tablet User Manual</a></b></p> <p>Comprehensive user manual for the DOOGEE T30 PRO tablet, covering setup, basic operations, safety guidelines, and maintenance. Includes instructions in multiple languages.</p>
	<p><b><a href="#">DOOGEE T10 User Manual</a></b></p> <p>User manual for the DOOGEE T10 tablet, providing instructions on SIM card insertion, device startup, messaging, language settings, safety precautions, and maintenance.</p>
	<p><b><a href="#">DOOGEE Shoot 1 Smartphone Overview and Specifications</a></b></p> <p>A comprehensive overview of the DOOGEE Shoot 1 smartphone, detailing its key specifications, camera features, connectivity options, dimensions, and package contents. Includes essential battery safety warnings.</p>