

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hatteker](#) /

› [Hatteker RFC-695 Digital Display IPX7 Full Waterproof Hair Clipper User Manual](#)

## Hatteker RFC-695

# Hatteker RFC-695 Digital Display IPX7 Full Waterproof Hair Clipper User Manual

Model: RFC-695

## INTRODUCTION

Thank you for choosing the Hatteker RFC-695 Digital Display IPX7 Full Waterproof Hair Clipper. This manual provides essential information for the safe operation, maintenance, and care of your device. Please read these instructions thoroughly before first use and retain them for future reference.

## SAFETY INFORMATION

- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Do not immerse the charging adapter in water or other liquids.
- Always check the appliance for damage before use. Do not use if damaged.
- Keep the appliance away from heat sources and direct sunlight.
- Only use the original charging adapter provided with the device.
- Ensure the appliance is switched off before cleaning or maintenance.

## SETUP

### Unboxing and Initial Charge

Upon unboxing, ensure all components are present: the hair clipper, four guide combs, cleaning brush, oil bottle, and USB charging cable. Before first use, fully charge the clipper for approximately 4 hours. The digital display will indicate the battery percentage.



Image: The Hatteker RFC-695 hair clipper connected to a USB charging cable, illustrating the 4-hour charging time required for 300 minutes of cordless operation.

### Attaching Guide Combs

The clipper comes with 4 attachment combs (3mm, 4-6mm, 7-9mm, 10-12mm, 16-18mm). To attach a comb, align its grooves with the clipper blade and push it firmly until it clicks into place. To remove, gently pull the comb away from the blade.

# FOUR KINDS OF LIMIT COMBS

Adapted to all lengths



16-18mm



10-12mm



7-9mm



4-6mm



3mm



Make the caliper thin

Image: A display of the four guide combs included with the Hatteker RFC-695, showing various cutting lengths from 3mm to 18mm.

## OPERATING INSTRUCTIONS

### Powering On/Off and Speed Settings

Press the power button to turn the clipper on. The digital display will show the current speed (RPM) and battery level. The clipper features a 3-speed motor (5000/6000/7000 RPM). Press the '+' or '-' buttons to adjust the motor speed according to your preference and hair type. Press the power button again to turn the clipper off.

# LCD DIGITAL DISPLAY BODY WASH

## ELECTRIC HAIR CLIPPER

Full body wash, ceramic blade, Powder metallurgy blade,



Image: The Hatteker RFC-695 hair clipper highlighting its LCD digital display, which shows battery percentage, speed, and other operational indicators.

### Adjusting Cutting Lengths

The clipper offers two methods for adjusting cutting length:

- **Adjustable Taper Lever:** Use the lever on the side of the clipper to fine-tune the cutting length from 0.5mm to 2.5mm without a guide comb. Rotate the lever to select the desired setting.
- **Guide Combs:** For longer lengths, attach one of the four guide combs (3mm, 4-6mm, 7-9mm, 10-12mm, 16-18mm).




Image: A detailed view of the clipper's adjustable taper lever, indicating the five fine-tuning settings from 0.5mm to 2.5mm for precise cutting length control.

## Corded/Cordless Use

The Hatteker RFC-695 can be used both cordlessly, providing up to 300 minutes of runtime on a full charge, or while plugged into a power source for continuous operation.

## MAINTENANCE

### Cleaning the Clipper

The Hatteker RFC-695 is IPX7 waterproof, allowing for easy cleaning. After each use:

1. Switch off the clipper and disconnect it from the power source if charging.
2. Remove any attached guide comb.
3. Rinse the blades and the clipper head under running water to remove hair clippings.
4. Use the provided cleaning brush to remove stubborn hair particles from the blades.

5. Allow the clipper to air dry completely before storing or recharging.

# 100% BODY WASH IT'S EASIER TO CLEAN



Image: The Hatteker RFC-695 hair clipper being cleaned under a running faucet, illustrating its 100% body wash capability for easy maintenance.

## Blade Care

The clipper features self-sharpening stainless steel blades designed for long-lasting sharpness. For optimal performance and longevity, apply a small drop of lubricating oil (included) to the blades after every few uses, especially after cleaning with water. Turn the clipper on for a few seconds to distribute the oil evenly.

## Storage

Store the clipper in a dry, cool place, away from direct sunlight and out of reach of children.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Clipper does not turn on.	Low battery or no charge.	Charge the clipper for 4 hours. Ensure the charging cable is properly connected.
Poor cutting performance or pulling hair.	Blades are dirty or not lubricated.	Clean the blades thoroughly and apply lubricating oil.
Clipper makes unusual noise.	Blades may be misaligned or require lubrication.	Ensure blades are clean and lubricated. If the issue persists, contact customer support.
Digital display not working.	Device malfunction.	Ensure the device is charged. If the problem continues, contact customer support.

## SPECIFICATIONS

- Model:** RFC-695
- Power Source:** Battery Powered (Cordless/Corded operation)
- Battery Type:** 1 x Lithium-Ion (included)
- Battery Capacity:** 1000mAh
- Charging Time:** Approximately 4 hours
- Runtime:** Up to 300 minutes
- Motor:** 8W Heavy-duty Magnetic Motor with 3 Speeds (5000/6000/7000 RPM)
- Blade Material:** Stainless Steel (Self-sharpening, zero-gapped, R-angle processing)
- Cutting Length Adjustment:** Adjustable Taper Lever (0.5mm - 2.5mm), 4 Guide Combs (3mm, 4-6mm, 7-9mm, 10-12mm, 16-18mm)
- Waterproof Rating:** IPX7 (Full body washable)
- Noise Level:** < 60 dB
- Product Dimensions:** 22 x 13 x 7 cm
- Item Weight:** 600 g
- Included Components:** Hair Trimmer, 4 Guide Combs, Cleaning Brush, Oil Bottle, USB Charging Cable
- Country of Origin:** China
- Manufacturer:** Yiwu Hatteker Electrical Appliance Co., Ltd

## WARRANTY AND SUPPORT

The Hatteker RFC-695 Hair Clipper comes with a **12-month quality warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

For warranty claims, technical support, or any inquiries regarding your product, please contact Hatteker customer service. Refer to your purchase documentation for specific contact details or visit the official Hatteker website.

