

[Manuals.plus](#) /

› [Paladone](#) /

› Paladone Xbox LED Neon Light Instruction Manual - Model 12715

Paladone 12715

Paladone Xbox LED Neon Light Instruction Manual

Model: 12715

INTRODUCTION

Thank you for purchasing the Paladone Xbox LED Neon Light. This product is designed to add a vibrant green glow to your gaming setup, suitable for both free-standing display and wall mounting. This manual provides essential information for the safe and proper use of your new LED light.

SAFETY INFORMATION

- Read all instructions before use.
- Keep away from water and moisture. This product is for indoor use only.
- Do not attempt to open or modify the product. There are no user-serviceable parts inside.
- Use only the provided USB cable for power.
- Ensure the product is placed on a stable surface or securely mounted to a wall to prevent falling.
- Keep out of reach of children and pets.

PACKAGE CONTENTS

- Paladone Xbox LED Neon Light (Model 12715)
- USB Power Cable

SETUP

1. **Unpacking:** Carefully remove the Xbox LED Neon Light and its USB cable from the packaging.
2. **Placement:**
 - **Free-standing:** Place the light on a flat, stable surface such as a desk or shelf.
 - **Wall Mounting:** The light features pre-drilled holes for wall mounting. Use appropriate hardware (not included) for your wall type to securely hang the light. Ensure the mounting location is clear of electrical wires or pipes.

3. **Power Connection:** Insert the small end of the included USB cable into the USB port on the back of the light. Connect the larger end of the USB cable to a compatible USB power source (e.g., USB wall adapter, computer USB port, gaming console USB port).



Image: The Paladone Xbox LED Neon Light unlit, highlighting its clear casing and the USB port for power connection.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Locate the power button on the USB cable. Press the button once to turn the light on. Press it again to turn the light off.
2. The light will emit a vibrant green glow when powered on.




Image: The Paladone Xbox LED Neon Light displaying its vibrant green illumination.

Product Demonstration Video

Your browser does not support the video tag.

Video: A demonstration of the Paladone Xbox LED Neon Light, showcasing its green illumination and ease of use. This video is provided by a seller.

MAINTENANCE

- **Cleaning:** To clean the light, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners or solvents.

- **Storage:** When not in use for extended periods, disconnect the power cable and store the light in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power connection or faulty USB cable/power source.	Ensure the USB cable is securely connected to both the light and a working USB power source. Try a different USB port or power adapter.
Light flickers or is dim.	Insufficient power supply or loose connection.	Verify the USB power source provides adequate power. Check all connections for tightness.

If you experience issues not listed here, please refer to the Support section.

SPECIFICATIONS

Brand	Paladone
Model Number	12715
Item Type	LED Light
Light Type	LED
Material	Plastic
Color	Green (Xbox style)
Dimensions (L x W)	Approx. 12.01 inches (30.5 cm) L x 2.17 inches (5.5 cm) W
Mounting Type	Freestanding or Wall Mountable
Power Source	USB (Cable Included)

WARRANTY

This Paladone product comes with a 30-day warranty from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, or unauthorized modifications.

SUPPORT

For further assistance or inquiries regarding your Paladone Xbox LED Neon Light, please visit the official Paladone website or contact their customer support. Contact details can typically be found on the product packaging or the brand's official website.



