Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ThunderX3 EAZE (TEGC-2058104.43)

ThunderX3 EAZE Gaming Chair User Manual

Model: EAZE (TEGC-2058104.43)

1. Product Overview

The ThunderX3 EAZE Gaming Chair is designed to provide ergonomic support and comfort for extended periods of use. It features a SYNC4 multi-functional mechanism for synchronous tilt, memory foam lumbar support, a neck pillow, and adjustable armrests. This manual provides instructions for assembly, operation, maintenance, and troubleshooting.




Image: The ThunderX3 EAZE Gaming Chair in Loft Light Grey, showcasing its ergonomic design and features in a modern office setting.

2. Setup and Assembly

Carefully unpack all components and ensure all parts are present before beginning assembly. It is recommended to

assemble the chair on a soft, clean surface to prevent damage.

2.1. Component Checklist

- Backrest
- Seat Base
- Armrests (2)
- Gas Lift Cylinder
- Star Base
- Casters (5)
- SYNC4 Mechanism
- Lumbar Support Cushion
- Neck Pillow
- Hardware Kit (screws, Allen key)

2.2. Assembly Steps

1. **Attach Casters to Star Base:** Insert each caster into the holes at the end of each leg of the star base until it clicks securely into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the assembled star base.
3. **Mount Mechanism to Seat Base:** Align the SYNC4 mechanism with the pre-drilled holes on the underside of the seat base. Secure it using the provided screws and Allen key. Ensure the front of the mechanism faces the front of the seat.
4. **Attach Armrests:** Secure the armrests to the seat base using the designated screws. Do not overtighten initially to allow for minor adjustments.
5. **Connect Backrest to Seat Base:** Align the backrest with the mounting brackets on the seat base and secure it with screws.
6. **Assemble Chair onto Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring it is centered and stable.
7. **Attach Lumbar Support and Neck Pillow:** Position the lumbar support cushion and neck pillow as desired for comfort. The neck pillow typically attaches over the top of the backrest.



Image: An assembled ThunderX3 EAZE Gaming Chair, ready for use, highlighting its overall structure and components.

3. Operating Instructions

The ThunderX3 EAZE chair offers several adjustment features to customize your seating experience for optimal comfort and support.

3.1. Chair Height Adjustment

To adjust the chair's height, locate the lever on the right side, beneath the seat. Pull the lever up while seated to lower the chair, or pull the lever up while standing to raise the chair. Release the lever at the desired height.

3.2. SYNC4 Multi-Functional Mechanism (Synchronous Tilt)

The SYNC4 mechanism allows the backrest and seat to recline together at an optimal ratio, providing continuous ergonomic support. This mechanism also includes multi-angle locking and adjustable backrest resistance.

- **Activating Tilt:** Pull the main lever (often the same as height adjustment, or a separate one) outwards to enable the

synchronous tilt function.

- **Locking Tilt:** Push the lever inwards to lock the chair in an upright or reclined position.
- **Adjusting Tilt Tension:** Rotate the knob located under the seat, usually at the front, to increase or decrease the resistance of the tilt mechanism. Turn clockwise to increase tension, counter-clockwise to decrease.




Image: A user demonstrating the synchronous tilt feature of the ThunderX3 EAZE chair, showing how the seat and backrest move together for a relaxed posture.

3.3. Adjustable Armrests

The cushioned armrests are two-directional, allowing for height and angle adjustments to support your arms and shoulders.

- **Height Adjustment:** Locate the button or lever on the side of each armrest. Press it and move the armrest up or down to your desired height. Release the button to lock.
- **Angle Adjustment:** Some armrests allow rotation inwards or outwards. Gently twist the armrest pad to adjust its angle.



Image: A close-up view of the fully adjustable cushioned armrests, illustrating their height and rotational adjustment capabilities.

3.4. Memory Foam Neck Pillow

The memory foam neck pillow provides superior neck and side support. It can be adjusted by sliding it up or down along the backrest to find the most comfortable position for your head and neck.




Image: A detailed view of the memory foam headrest, highlighting its contoured design for superior neck and side support.

3.5. Adjustable Lumbar Support Cushion

The lumbar support cushion is designed to provide optimal lower back comfort and promote healthy posture. It can be positioned vertically along the backrest to target the specific curve of your lower back.



Image: A close-up of the adjustable lumbar support cushion, demonstrating its placement for optimal lower back comfort and support.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your ThunderX3 EAZE Gaming Chair.

4.1. Cleaning Instructions

- **Fabric Surfaces:** For general cleaning, wipe the fabric surfaces with a clean, damp cloth. For tougher stains, use a mild fabric cleaner and follow the product instructions. Test any cleaning solution on an inconspicuous area first.
- **Plastic and Metal Parts:** Wipe plastic and metal components with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Casters:** Periodically clean the casters to remove dust, hair, and debris that can impede smooth movement.

4.2. General Care

- Regularly check all screws and bolts to ensure they are tight. Retighten as necessary to maintain stability.
- Avoid exposing the chair to direct sunlight for prolonged periods, as this can cause fading or material degradation.
- Do not stand on the chair or use it for purposes other than its intended use.

5. Troubleshooting

If you encounter any issues with your ThunderX3 EAZE Gaming Chair, refer to the following common problems and solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Chair does not adjust height	Gas lift cylinder malfunction or lever not engaged.	Ensure the height adjustment lever is fully engaged. If the problem persists, the gas lift may need replacement. Contact support.
Chair is wobbly or unstable	Loose screws or improper assembly.	Check all assembly screws (seat to mechanism, backrest to seat, armrests) and tighten them securely. Ensure casters are fully inserted into the star base.
Casters do not roll smoothly	Debris caught in casters or damaged casters.	Turn the chair over and remove any hair, dust, or debris from the caster wheels. If casters are damaged, they may need replacement.
Squeaking noises	Loose connections or friction between components.	Tighten all screws. Apply a small amount of silicone-based lubricant to moving parts or connection points if the noise persists. Avoid oil-based lubricants on plastic.
Tilt function not working	Mechanism locked or tension too high.	Ensure the tilt lock lever is disengaged. Adjust the tilt tension knob counter-clockwise to reduce resistance.

6. Specifications

Detailed specifications for the ThunderX3 EAZE Gaming Chair (Model TEGC-2058104.43).

Brand: ThunderX3

Model Name: EAZE

Item Model Number: TEGC-2058104.43

ASIN: B0CP18SYN8

Color: Fabric, Loft Light Grey

Product Dimensions: 27.6"D x 28.3"W x 47.6"H (70.1cm D x 71.9cm W x 120.9cm H)

Seat Depth: 19.7 inches (50 cm)

Item Weight: 44.5 pounds (20.18 kg)

Material: Polyethylene (frame/base), Foam (fill material), Fabric (upholstery)

Form Factor: Recliner

Recommended Uses: Gaming, Office

Included Components: Caster

Product Care Instructions: Wipe Clean

Date First Available: December 1, 2023

7. Warranty and Support

For warranty information and customer support, please refer to the official ThunderX3 website or contact your retailer. Keep your proof of purchase for any warranty claims.
Manufacturer: THUNDERX3
Website: www.thunderx3.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CP18SYN8

More documents and user manuals: **https://manuals.plus/**