

[Manuals.plus](#) /

› [ELENKER](#) /

› ELENKER KLD-3328 Sliding Shower Chair Instruction Manual

ELENKER KLD-3328

ELENKER KLD-3328 Sliding Shower Chair Instruction Manual

Model: KLD-3328

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your ELENKER Heavy Duty Sliding Shower Chair with Swivel Seat, Model KLD-3328. This product is designed to assist individuals with limited mobility in safely transferring into and out of a bathtub or shower, offering enhanced stability and ease of use.

Key features include a 360° swivel seat, smooth sliding mechanism, robust aluminum frame, and non-slip suction cup feet for secure placement. Please read this manual thoroughly before initial use to ensure proper setup and safe operation.

SAFETY INFORMATION

WARNING: Failure to follow these safety instructions could result in serious injury or damage to the product.

- Always ensure all components are securely fastened before each use.
- Verify that the shower chair is placed on a flat, stable surface. The non-slip suction cups must be firmly attached to the shower or bathtub floor.
- Do not exceed the maximum weight capacity of 350 pounds (158 kg).
- Measure your bathroom area and bathtub size accurately to ensure the product fits properly and allows for safe transfer. The chair measures 40" (W) x 16.5" (D) and may be unsuitable for small bathrooms or direct installation into certain bathtubs.
- Always engage the seat lock mechanism before transferring weight onto or off the chair.
- Use the safety belt provided to secure the user during transfer and showering, if applicable.
- Do not stand on the shower chair.
- Regularly inspect the chair for any signs of wear, damage, or loose components. Discontinue use if any damage is found.
- Keep children away from the shower chair during assembly and use.

PACKAGE CONTENTS

Please refer to the packaging for a complete and detailed list of all included components. Ensure all parts are present and undamaged before proceeding with assembly.

ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your ELENKER Sliding Shower Chair. It is recommended to assemble the chair in the area where it will be used, or a spacious, flat surface.

1. **Attach the Legs:** Securely attach the four adjustable legs to the main frame of the shower chair. Ensure the height adjustment pins click into place at the desired height. The legs with suction cups are typically for the wet area (inside the tub/shower), and the standard feet for the dry area.



Figure 1: Attaching the adjustable legs to the main frame.

2. **Install the Seat Frame:** Position the sliding seat frame onto the main support rails. Ensure it moves smoothly along the rails.



Figure 2: Installing the sliding seat frame.

3. **Attach the Seat and Backrest:** Secure the swivel seat and backrest to the sliding seat frame using the provided hardware. Ensure the seat can swivel freely and locks into position.




Figure 3: Attaching the swivel seat and backrest.

4. **Install Armrests and Accessories:** Attach the armrests, shower bracket, and soap box as indicated in the product diagram.



Figure 4: Installing armrests and accessories.

5. **Final Check:** Before first use, ensure all bolts, screws, and connections are tight and secure. Test the sliding and swivel mechanisms to confirm smooth operation and proper locking.

OPERATING INSTRUCTIONS

This section details how to safely and effectively use your ELENKER Sliding Shower Chair.

1. Positioning the Chair

- Place the shower chair with one side inside the bathtub/shower and the other side outside, ensuring the non-slip suction cups are firmly pressed onto the wet surface.
- Ensure the chair is stable and does not wobble before use.

2. Using the Sliding Function

- To slide the seat, locate the orange knob or lever beneath the seat. Pull or press it to release the lock.
- Gently slide the seat along the rails to transfer the user into or out of the bathing area.
- Once in the desired position, release the knob/lever to lock the seat in place. Always ensure the seat is securely

locked before transferring weight.

Smooth and Effortless Sliding




Figure 5: Demonstrating the sliding mechanism.

3. Utilizing the Swivel Seat

- The seat allows for a 360° rotation, swiveling 90° at a time and locking automatically.
- To swivel, pull up the handle located on the side of the seat. Rotate the seat to the desired angle.
- Release the handle to lock the seat in the new position. Ensure it is fully locked before use.

360° Swivle Seat



Figure 6: Demonstrating the swivel seat.

4. Using the Safety Belt and Suction Cups

- The integrated safety belt provides additional security during transfers and showering. Fasten the belt securely around the user.
- The large suction cups on the legs are designed to prevent slipping on wet surfaces. Ensure they are firmly pressed down before use.

More Stable & Safe



Figure 7: Safety belt and suction cup features.

5. Official Product Video

Your browser does not support the video tag.

Video 1: ELENKER Sliding Transfer Bench with Swivel Seat. This video demonstrates the key features and operation of the shower chair, including the sliding and swivel functions, and highlights its stability.

MAINTENANCE AND CARE

- **Cleaning:** Clean the shower chair regularly with mild soap and water. Avoid abrasive cleaners or harsh chemicals that could damage the plastic or aluminum components.
- **Drying:** After each use, allow the chair to air dry completely to prevent mildew and maintain hygiene. The seat with drainage holes facilitates quick drying.
- **Inspection:** Periodically check all nuts, bolts, and connections to ensure they remain tight. Inspect the frame for any cracks or bends, and the seat for any damage. Ensure the suction cups are intact and provide adequate grip.
- **Storage:** Store the chair in a dry place when not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Seat does not slide smoothly or hangs up.	◦ Rails are dirty or obstructed. ◦ Bolts on wheel assembly are too tight.	◦ Clean the sliding rails and remove any debris. ◦ Using a 10mm socket and hex wrench, slightly loosen the three bolts on the four steel wheel assemblies. Test for smooth sliding and adjust as needed.
Seat does not lock into position after sliding or swiveling.	◦ Locking mechanism is obstructed or misaligned. ◦ Handle/lever not fully released.	◦ Inspect the locking mechanism for any debris or damage. ◦ Ensure the handle or lever is fully released after positioning the seat. If the issue persists, contact customer support.
Chair feels unstable or wobbles.	◦ Legs are not evenly adjusted. ◦ Suction cups not properly engaged. ◦ Loose connections.	◦ Ensure all four legs are adjusted to the same height and are firmly on the ground. ◦ Press down firmly on the chair to engage the suction cups on the wet surface. ◦ Check all assembly connections and tighten any loose bolts.

SPECIFICATIONS

Feature	Detail
Brand	ELENKER
Model Number	KLD-3328
Material	Aluminum frame, Plastic seat
Color	Blue and White
Maximum Weight Recommendation	350 Pounds (158 kg)
Minimum Height	15.4 Inches
Seat Depth	17.7 inches
Overall Dimensions (W x D)	Approximately 40" x 16.5" (101.6 cm x 41.9 cm)
Seat Dimensions (W x D)	21.7" x 17.7" (55.1 cm x 45 cm)




Figure 8: Product Dimensions.

WARRANTY AND SUPPORT

For warranty information or technical support regarding your ELENKER KLD-3328 Sliding Shower Chair, please refer to the warranty card included with your product or contact ELENKER customer service directly. Contact details can typically be found on the product packaging or the official ELENKER website.

When contacting support, please have your model number (KLD-3328) and purchase date available.

