

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ciciglow](#) /

› [ciciglow Voice Translator Device \(Model ciciglowm7df4h50rx\) User Manual](#)

**ciciglow ciciglowm7df4h50rx**

# ciciglow Voice Translator Device

Model: ciciglowm7df4h50rx

## INTRODUCTION

---

Thank you for choosing the ciciglow Voice Translator Device. This device is designed to facilitate communication across language barriers with its advanced translation capabilities, supporting numerous online and offline languages, as well as photo translation. Please read this manual carefully to ensure proper use and optimal performance of your device.



Image: Front view of the ciciglow Voice Translator Device, highlighting its loudspeaker and noise-reduction microphone with sound wave graphics.

## PACKAGE CONTENTS

Please check the package for the following items:

- 1 x ciciglow Voice Translator Device
- 1 x Charging Cable
- 1 x Instruction Manual (this document)
- 1 x Card Removal Pin

## PRODUCT OVERVIEW

The ciciglow Voice Translator is a versatile 4G translation device featuring a 3.1-inch HD screen. It is equipped with 1GB RAM and 16GB ROM, and a 2000mAh battery for extended use.

### Key Features:

- **Multi-Language Support:** Supports 142 online languages, 19 offline languages, and 57 languages for photo translation.
- **High Accuracy:** Sound recording to text with up to 98% accuracy.
- **Noise Reduction:** Dual microphone noise reduction for clearer voice recognition.
- **HD Screen:** 3.1-inch HD screen for easy operation and clear display of translation status.
- **Photo Translation:** 5MP recognition camera for translating text from images.
- **Long Battery Life:** Built-in 2000mAh battery provides 8 to 12 hours of continuous playback.



Image: Angled view of the Ciciglow Voice Translator Device, showing its sleek design and screen.



Image: Back view of the ciciglow Voice Translator Device, highlighting the 5MP photo translation camera and 4G network capabilities.

## SETUP

### 1. Charging the Device

Before first use, fully charge the device using the provided charging cable and a compatible USB power adapter (not included). The charging indicator on the screen will show the charging status.

### 2. Powering On/Off

- **To Power On:** Press and hold the power button (usually located on the side) until the screen lights up.
- **To Power Off:** Press and hold the power button, then select 'Power Off' on the screen.

### 3. Network Connection

For online translation features, the device requires an internet connection. You can connect via Wi-Fi or 4G network.

- **Wi-Fi Connection:** Go to 'Settings' > 'Wi-Fi', select your desired network, and enter the password if prompted.
- **4G Connection:** Insert a compatible 4G SIM card (not included) into the designated slot using the card removal pin. Ensure the device is powered off before inserting or removing the SIM card.

FOR MOBILE PHONES, TABLETS, LAPTOPS  
PROVIDE WIFI UNLIMITED FLOW, NECESSARY FOR  
OVERSEAS TRAVEL AND BUSINESS




Image: The ciciglow Voice Translator Device displaying a WiFi connection, indicating its ability to connect to wireless networks for online services.

## OPERATING INSTRUCTIONS

### 1. Basic Navigation

The device features a 3.1-inch HD touchscreen. Navigate through menus and options by tapping and swiping on the screen.

### 2. Online Voice Translation (142 Languages)

1. Ensure the device is connected to Wi-Fi or 4G.
2. From the main menu, select 'Voice Translation'.
3. Tap on the language icons to select your source language and target language.
4. Press and hold the corresponding microphone button (usually indicated by colors or symbols) and speak clearly into the device.
5. Release the button, and the translated text will appear on the screen and be spoken aloud.

### 3. Offline Voice Translation (19 Languages)

The device supports offline translation for 19 languages, allowing use without an internet connection. Ensure the required offline language packs are downloaded in advance via a Wi-Fi connection.



Image: The ciciglow Voice Translator Device displaying text related to its 19 accurate offline translation languages, including Simplified Chinese, English, German, Spanish, French, Japanese, Korean, Russian, and Thai.

#### **4. Photo Translation (57 Languages)**

1. From the main menu, select 'Photo Translation'.
2. Point the 5MP camera at the text you wish to translate (e.g., menus, signs, documents).
3. Tap the capture button on the screen.
4. The device will recognize the text and display the translation.

#### **5. Sound Recording to Text**

The device can record spoken language and convert it into text with high accuracy.

1. Select the 'Recording' or 'Text Conversion' feature from the menu.
2. Start recording your speech.
3. The device will transcribe the audio into text, which can then be translated or saved.

## 6. Language Practice

Utilize the device for language learning and pronunciation practice. The device may offer features for oral practice and evaluation to improve communicative English and test pronunciation accuracy.



Image: The ciciglow Voice Translator Device displaying text related to oral practice and evaluation, indicating its utility for improving English pronunciation and communication skills.

## MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the device. Do not use liquid cleaners or aerosols.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Software Updates:** Periodically check for and install software updates to ensure optimal performance and access to new features.

## TROUBLESHOOTING

---

## Device Not Turning On:

- Ensure the device is fully charged. Connect it to a power source and try again.
- Press and hold the power button for at least 10-15 seconds to perform a forced restart.

## Translation Inaccuracy:

- Speak clearly and at a moderate pace.
- Ensure the correct source and target languages are selected.
- Check your internet connection for online translation. A stable connection is crucial for accuracy.
- For photo translation, ensure the text is well-lit and clearly visible to the camera.

## Connectivity Issues (Wi-Fi/4G):

- **Wi-Fi:** Verify your Wi-Fi password and ensure the network is active. Try restarting your router.
- **4G:** Check if the SIM card is correctly inserted and activated. Ensure you have a data plan.

## SPECIFICATIONS

Feature	Specification
Model Number	ciciglowm7df4h50rx
Screen	3.1 Inch Full Viewing Angle Screen
Camera Pixels	5MP
Network Format	GSM, WCDMA, TD SCDMA, TDD, FDD
Frequency	1.5GHz
4G Band	FDD:1 3 7 8 20 28A TDD:38 39 40 41
3G Band	WCDMA: 1 2 5 8 TD SCDMA:34 39
Product Memory (RAM)	1GB
Product Memory (ROM)	16GB
Battery Type	Lithium Battery
Battery Capacity	2000mAh
Online Languages Supported	142
Offline Languages Supported	19
Photo Translation Languages Supported	57

## WARRANTY INFORMATION

This product is typically covered by a standard manufacturer's warranty. Please refer to the warranty card included in your package or contact the seller/manufacturer directly for specific warranty terms and conditions, including duration and coverage details. Keep your purchase receipt as proof of purchase for any warranty claims.

## SUPPORT

---

For further assistance, technical support, or inquiries regarding your ciciglow Voice Translator Device, please contact the seller through the platform where you purchased the product. You may also visit the official ciciglow brand store for additional resources or contact information.