

Replacement Remote Control for Kingsdown Comfort Base (OKIN Compatible)

Generic Replacement Remote Control for Kingsdown Comfort Base Electric Adjustable Bed (OKIN Compatible) User Manual

IMPORTANT COMPATIBILITY NOTES

This replacement remote control is designed for specific Kingsdown Comfort Base electric adjustable beds. Please review the following critical compatibility information before use:

- **Control Box Compatibility:** This remote is compatible only with adjustable beds that utilize an **OKIN brand control box**. If your bed uses a different brand control box, this remote will not function.
- **Remote Type:** Adjustable bed remotes typically use either 'Dip Switches' or a 'Pair Button' for connection. You must verify which type your original remote control uses. This remote may not be compatible with all original remote types.
- **Pairing Requirement:** The remote control requires pairing with your adjustable bed's control box before use. The specific pairing method varies by bed model. Refer to the original instruction manual for your adjustable bed for detailed pairing instructions. Ensure you can perform the pairing process before attempting to use this replacement remote.
- **Model Verification:** Many remote controls appear similar but are not universally compatible. Confirm that your original remote control is identical in appearance and button layout to the images provided in this manual. If your bed model number is not explicitly listed or you are unsure, contact the seller with your bed's control box details and model number for assistance.
- **Functionality:** While designed as a replacement, this remote may not offer every function identical to your original remote. Core adjustable bed functions are supported.

PRODUCT OVERVIEW

This section provides an overview of the Generic replacement remote control, highlighting its design and key features.

Important Note:

- 1: Dip switches are not compatible with Pair button models, Peel off the yellow label and make sure your old remote control is a Dip switch or Pair button.
- 2: Many remote controls look the same but are not universal, our remote control only fits for the brand and model we listed if you are not sure, please send us the control box and the model no. of the bed to find the correct remote control for you
- 3: The remote control needs to be paired before use, and the pairing method is not the same for different models, so please make sure you can pair it before you buy it (the pairing method is on the manual of your adjustable bed)
- 4: If your model number is not in our title, please provide us with the exact and detailed information, such as : model number and Clear photos of the front & back of your old remote control

Figure 1: Angled view of the remote control, displaying its ergonomic design and button layout.

The remote control features an ergonomic design for comfortable handling and intuitive button placement for easy operation of your adjustable bed. It is black in color.



Figure 2: Front view of the remote control, detailing the various function buttons.



Figure 3: Back view of the remote control with the battery cover installed.

SETUP

1. Battery Installation

The remote control requires one (1) AAA battery (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to remove it.



Figure 4: Battery compartment with cover removed.

3. Insert one (1) AAA battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

2. Pairing the Remote Control

This remote control must be paired with your adjustable bed's control box to function. The pairing process is specific to your bed model and control box. Refer to your original Kingsdown Comfort Base adjustable bed manual for precise pairing instructions.

General Pairing Information:

- Some control boxes use **dip switches** for pairing. If your original remote or control box has dip switches, ensure the settings on the replacement remote (if applicable) match.



Figure 5: Example of dip switches inside the battery compartment (if present).

- Other control boxes use a **pair button**, often located on the control box itself. You typically press this button, then a button on the remote to establish a connection.

Note: If you do not have your original bed manual, contact Kingsdown support or the seller for guidance on pairing your specific adjustable bed model with a new remote.

OPERATION

Once paired, the remote control allows you to adjust your Kingsdown Comfort Base adjustable bed. The buttons are generally intuitive:

- **Position Buttons (Arrows):** Adjust the head and foot sections of the bed up or down.
- **FLAT:** Returns the bed to a completely flat position.
- **ZG (Zero Gravity):** Activates the pre-programmed Zero Gravity position, which elevates the head and foot to a position that may relieve pressure on the back.
- **ANTI-SNORE:** Activates a pre-programmed position designed to help reduce snoring.
- **MEMORY (1, 2):** Allows you to save and recall your favorite bed positions. Consult your bed's original manual for instructions on setting memory positions.
- **SLEEP ENHANCEMENT (10min, 20min, 30min):** Activates a timed massage or gentle movement program for the specified duration.

- **TIMER / ALL OFF:** May function as a timer for certain features or to turn off all active functions.
- **WAVE (+ / -):** Adjusts the intensity or pattern of the wave massage function.
- **INTENSITY (+ / -):** Adjusts the intensity of the massage function.

Note: The exact functionality of some buttons may depend on your specific adjustable bed model and its features. Not all beds support all functions listed.

MAINTENANCE

To ensure the longevity and proper functioning of your remote control:

- **Cleaning:** Wipe the remote with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace the AAA battery when the remote's response becomes sluggish or it stops functioning. Always use a fresh, high-quality AAA battery.
- **Storage:** Store the remote in a dry place, away from extreme temperatures and direct sunlight.
- **Avoid Damage:** Do not drop the remote or expose it to water or other liquids.

TROUBLESHOOTING

If your remote control is not functioning as expected, try the following steps:

- **Check Batteries:** Ensure the AAA battery is inserted correctly with the correct polarity and is not depleted. Replace with a new battery if necessary.
- **Re-Pair Remote:** If the remote stops responding, try re-pairing it with your adjustable bed's control box. Refer to the 'Pairing the Remote Control' section and your bed's original manual.
- **Obstructions:** Ensure there are no obstructions between the remote control and the bed's control box. The remote operates using infrared (IR) signals, which require a clear line of sight.
- **Control Box Power:** Verify that your adjustable bed's control box is powered on and receiving electricity. Check the power cord connection to the wall outlet and the bed.
- **Original Remote Test:** If you have your original remote, test it to determine if the issue is with the replacement remote or the bed's control box.

If these steps do not resolve the issue, contact the seller or a qualified service technician for further assistance.

SPECIFICATIONS

- **Product Type:** Replacement Remote Control

- **Brand:** Generic
- **Compatible Devices:** Kingsdown Comfort Base Electric Adjustable Beds (with OKIN brand control box)
- **Power Source:** 1 x AAA Battery (not included)
- **Color:** Black
- **Special Features:** Ergonomic design, Infrared (IR) communication
- **Max Number of Supported Devices:** 1

WARRANTY AND SUPPORT

Specific warranty information for this Generic replacement remote control is not provided in the product details. For any warranty claims, technical support, or further inquiries, please contact the seller directly through your purchase platform.

Always retain your proof of purchase for any support requests.