

GAOMON LZW20220923

7-in-1 Toddler Slide and Swing Set Instruction Manual

Model: LZW20220923 | Brand: GAOMON

1. INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your GAOMON 7-in-1 Toddler Slide and Swing Set. This versatile playset is designed to provide a fun and engaging environment for toddlers, combining multiple activities in one compact unit.



Figure 1.1: Overview of the 7-in-1 Toddler Slide and Swing Set.

The set includes a freestanding slide, an adjustable swing, a basketball hoop, a soccer goal, a golf playset, and accessories for ring toss. Please read this manual thoroughly before assembly and use to ensure proper setup and safety.

2. SAFETY INFORMATION

Your child's safety is paramount. Adhere to all safety guidelines to prevent injury.

- **Adult Supervision Required:** Always supervise children when they are using the playset. Never leave children unattended.
- **Age and Weight Limit:** This playset is designed for toddlers aged 1-3 years. The maximum weight recommendation is 66 pounds (30 kg). Do not exceed this limit.
- **Proper Assembly:** Ensure all parts are correctly assembled and securely fastened according to the instructions. Regularly check for loose parts.
- **Stable Surface:** Place the playset on a flat, level, and stable surface. For added stability, the swing base can be filled with water or sand.
- **Material Safety:** The playset is made of eco-friendly HDPE material, which is odorless and certified by ASTM and CPSIA standards for child safety.
- **Clearance Area:** Ensure adequate clear space around the playset, especially around the slide exit and swing area, to prevent collisions.
- **Weather Conditions:** If used outdoors, protect the playset from extreme weather conditions. Prolonged exposure to direct sunlight may cause color fading.
- **No Sharp Objects:** Keep sharp objects or tools away from the playset and children during play.



Figure 2.1: Stability and Safety Features (Water/Sand Injection, Front Fence, Seat Belt).

3. ASSEMBLY INSTRUCTIONS

Assembly of the GAOMON 7-in-1 Toddler Slide and Swing Set is designed to be straightforward. Follow these steps carefully.

3.1. Unpacking and Component Check

- Carefully unpack all components from the box.
- Verify that all parts listed in the packaging contents are present and undamaged.

3.2. Assembling the Slide

- Attach the slide panels to the main support structure. Ensure all connections are secure.
- Install the anti-slip steps onto the climbing ladder. The steps are designed for secure footing.



Figure 3.1: Anti-slip steps for safe climbing.

3.3. Assembling the Swing

- Connect the swing frame components.
- Attach the swing seat to the frame. Ensure the safety front fence and seat belt are correctly installed and functional.

- For enhanced stability, fill the base of the swing with water or sand through the designated opening.

3.4. Assembling the Basketball Hoop, Soccer Goal, and Golf Set

- Assemble the basketball hoop stand and attach the hoop.
- Assemble the soccer goal frame and attach the net.
- Set up the golf playset components as indicated.

Once all sections are assembled, double-check all connections to ensure they are tight and secure before allowing children to use the playset.

4. OPERATING INSTRUCTIONS

This playset offers multiple activities for engaging play.

4.1. Slide Usage

- Children should climb the anti-slip steps to the waiting area at the top of the slide.
- Ensure the child slides down feet first, one at a time.
- The slide features an acceleration zone, deceleration zone, and a buffer zone with a thick buffer bottom plate for a safe and smooth landing.




Figure 4.1: Slide design for safe play.

4.2. Swing Usage

- Place the child securely in the swing seat, ensuring the front fence is closed and the seat belt is fastened.
- The swing seat height is adjustable to three levels: 15.35 inches, 13.00 inches, and 11.02 inches from the ground. Adjust as needed for the child's comfort and safety.
- Gently push the swing, maintaining a safe and controlled motion.

3 LEVELS OF HEIGHT ADJUSTABLE



Figure 4.2: Adjustable swing seat height.

4.3. Basketball Hoop, Soccer Goal, Golf, and Ring Toss

- The basketball hoop is height adjustable to accommodate growing toddlers.
- Use the provided balls for basketball, soccer, and golf activities.
- Utilize the three rings for the ring toss game, aiming for the designated targets.



Figure 4.3: Multi-sport features including basketball, soccer, golf, and ring toss.

5. MAINTENANCE AND CARE

Regular maintenance will extend the life of your playset and ensure continued safety.

- **Cleaning:** The smooth plastic surfaces are easy to clean. Use a damp cloth with mild soap and water. Avoid abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically inspect all nuts, bolts, and connections to ensure they are tight. Tighten any loose fasteners immediately.
- **Damage Check:** Check for any cracks, breaks, or sharp edges on the plastic components. Discontinue use if significant damage is found and contact customer support.
- **Storage:** If used outdoors, consider covering the playset during prolonged periods of non-use or extreme weather to prevent wear and color fading.

6. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Playset feels unstable:** Ensure the playset is on a flat, level surface. Fill the swing base with water or sand for added stability. Check all assembly connections for tightness.
- **Parts are loose after assembly:** Re-check all screws and fasteners. Tighten them firmly, but do not overtighten to avoid damaging the plastic.
- **Color fading (if used outdoors):** This is a natural process for plastic exposed to UV light over time. To minimize fading, store the playset indoors or cover it when not in use for extended periods.
- **Difficulty with assembly:** Refer back to the assembly instructions and diagrams. Ensure you have all components and are following the steps in the correct order. If issues persist, contact customer support.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	GAOMON
Model Number	LZW20220923
Material	Plastic (HDPE)
Color	Green
Product Dimensions (L x W x H)	76" x 76.4" x 49.2" (193 cm x 194 cm x 125 cm)
Item Weight	45.6 Pounds (20.7 kg)
Maximum Weight Recommendation	66 Pounds (30 kg)
Age Range (Description)	Toddler (1-3 years)
Assembly Required	Yes
UPC	196336918123



Figure 7.1: Product Dimensions.

8. WARRANTY INFORMATION

For information regarding the product warranty, please refer to the warranty card included with your purchase or contact GAOMON customer support directly. Keep your proof of purchase for any warranty claims.

9. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a damaged part, please contact GAOMON customer support. Refer to the contact information provided on the product packaging or the official GAOMON website.