

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Amazon](#) /

› [Amazon Kindle 16 GB \(Latest Model\) User Manual](#)

### Amazon Kindle (11th Generation) - Matcha (B0CP31QS6R)

## Amazon Kindle (11th Generation) User Manual

Model: Kindle (11th Generation) - Matcha (B0CP31QS6R)

### INTRODUCTION

Welcome to your new Amazon Kindle (11th Generation). This device is designed to provide an unparalleled reading experience, offering a lightweight and compact design with enhanced display features. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your Kindle.

For optimal performance and longevity of your device, please read this manual thoroughly and retain it for future reference.

### PRODUCT OVERVIEW AND FEATURES

The Amazon Kindle (11th Generation) is engineered for dedicated reading, minimizing distractions and maximizing comfort. Key features include:

- **Lightest and Most Compact Kindle:** Designed for portability and comfortable holding during extended reading sessions.
- **Improved Display:** Features a brighter front light at maximum setting, higher contrast, and faster page turns for a superior reading experience.
- **Glare-Free Screen:** A 6-inch display that reads like real paper, even in direct sunlight.
- **Adjustable Front Light & Dark Mode:** Read comfortably in any lighting condition, day or night.
- **Distraction-Free Reading:** Disconnect from messages, emails, and social media to immerse yourself in your books.
- **Extended Battery Life:** Enjoy up to six weeks of battery life on a single charge.
- **Ample Storage:** 16 GB of storage capacity, enough to hold thousands of books.
- **Kindle Unlimited Access:** Discover new stories with unlimited access to over 4 million titles and thousands of audiobooks (subscription required).
- **Sustainable Design:** Constructed with 75% recycled plastics and 90% recycled magnesium.

### Product Visuals



Kindle device displaying various book covers, highlighting the improved screen features and compact design.



Close-up of the Kindle screen displaying text, demonstrating the clear e-ink display for comfortable reading.



Ahora con una luz frontal un 25% más brillante en el ajuste máximo y una mayor relación de contraste

A hand holding the Kindle, illustrating the brighter front light and improved contrast for comfortable reading in various conditions.



Ahora con paso de  
página más rápido

A user holding the Kindle, demonstrating the faster page-turning capability for a smoother reading flow.



Pantalla de 6" sin reflejos, sin  
distracciones y hasta 6 semanas  
de duración de la batería

A user reading the Kindle while relaxing in a hammock, emphasizing the long battery life and glare-free screen for outdoor reading.



16 GB de almacenamiento  
para guardar miles de libros

A collection of book covers, representing the 16 GB storage capacity for thousands of books on your device.



Accede a más de 4 millones de títulos con una suscripción a Kindle Unlimited

A user holding the Kindle, showcasing access to millions of titles through a Kindle Unlimited subscription.

## SETUP

### Initial Setup

Follow these steps to set up your Kindle for the first time:

- Power On:** Press and hold the power button located on the bottom edge of your Kindle until the screen lights up.
- Select Language:** Choose your preferred language from the list.
- Connect to Wi-Fi:** Select your Wi-Fi network from the available list and enter the password if prompted. Your Kindle supports 2.4 GHz and 5.0 GHz networks with WEP, WPA, WPA2, and OWE security.
- Register Your Kindle:** Sign in with your existing Amazon account or create a new one. This links your Kindle to your content library.
- Tutorial:** Follow the on-screen tutorial to familiarize yourself with basic navigation and features.

### Charging Your Kindle

Your Kindle comes with a USB-C charging cable. To charge your device:

- Connect the USB-C end of the cable to your Kindle's charging port.
- Connect the USB-A end to a computer's USB port or a 9W USB power adapter (not included).
- A full charge takes approximately 4 hours via USB from a computer, or about 2 hours with a 9W USB power adapter.

## OPERATING YOUR KINDLE

### Navigating the Interface

The Kindle features a touch-sensitive screen for easy navigation:

- Home Screen:** Displays your current reads, recommended books, and quick access to your library and the Kindle Store.
- Library:** Tap "Library" to view all your downloaded books and content.
- Kindle Store:** Tap "Store" to browse, purchase, and download new books.

- **Settings:** Swipe down from the top of the screen to access quick settings like Wi-Fi, Airplane Mode, and screen brightness.

## Reading Books

To begin reading:

1. Tap on a book cover from your Home screen or Library to open it.
2. Tap the right side of the screen to turn to the next page, or the left side to go back.
3. Tap the top of the screen to bring up the reading toolbar, allowing you to adjust font size, font type, line spacing, margins, and access other reading options.

## Downloading Content

With your Kindle connected to Wi-Fi, you can easily download new content:

- Navigate to the Kindle Store from your device.
- Browse or search for titles.
- Select a book and choose to buy it or download it if it's part of your Kindle Unlimited subscription.
- Downloaded content will automatically appear in your Library.

## Accessibility Features

The Kindle includes several accessibility features to enhance the reading experience for all users:

- **VoiceView Screen Reader:** Available via Bluetooth audio, VoiceView provides audio descriptions to navigate your device and read books with text-to-speech (English only).
- **Invert Black and White:** Change the display to white text on a black background for reduced eye strain in low light.
- **Adjustable Text:** Customize font size, font type, line spacing, and margins to your preference.

## MAINTENANCE

---

### Cleaning Your Kindle

To keep your Kindle clean and in good condition:

- Use a soft, lint-free cloth to gently wipe the screen and body of the device.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Avoid getting moisture into any openings.

### Battery Care

To maximize your Kindle's battery life:

- Keep Wi-Fi turned off when not actively downloading content.
- Adjust the front light to a comfortable level; higher brightness consumes more power.
- Avoid extreme temperatures.
- Note that using Audible audiobooks via Bluetooth will reduce battery life.

## TROUBLESHOOTING

---

## Common Issues and Solutions

Issue	Solution
Device is unresponsive or frozen.	Press and hold the power button for 40 seconds until the device restarts.
Cannot connect to Wi-Fi.	Ensure your Wi-Fi password is correct. Restart your Kindle and your Wi-Fi router. Verify your network is 2.4 GHz or 5.0 GHz and not an ad-hoc network.
Books are not downloading.	Check your Wi-Fi connection. Ensure your Amazon account is properly registered and your payment method is up to date.
Battery drains quickly.	Reduce screen brightness. Turn off Wi-Fi when not in use. Avoid using Bluetooth audio for extended periods.

If you encounter issues not listed here or if the suggested solutions do not resolve your problem, please refer to the "Further Assistance" section for support options.

## SPECIFICATIONS

---

Feature	Description
<b>Display</b>	6-inch Amazon display with built-in reading light, 300 ppi, optimized font technology, 16-level grayscale.
<b>Size</b>	157.8 x 108.6 x 8.0 mm (6.2" x 4.3" x 0.32"). Actual size may vary by configuration and manufacturing process.
<b>Weight</b>	158 g (5.56 oz). Actual weight may vary by configuration and manufacturing process.
<b>System Requirements</b>	None; fully wireless and does not require a computer to download content.
<b>On-Device Storage</b>	16 GB; holds thousands of books.
<b>Cloud Storage</b>	Free cloud storage for all Amazon content.
<b>Battery Life</b>	A single charge lasts up to six (6) weeks, based on half an hour of reading per day with wireless off and light setting at 13. Battery life may vary based on usage. Audible audiobook reception via Bluetooth will reduce battery life.
<b>Charge Time</b>	Fully charges in approximately 4 hours via USB from a computer; and in approximately 2 hours with a 9W USB power adapter.
<b>Wi-Fi Connectivity</b>	Supports 2.4 GHz and 5.0 GHz networks with WEP, WPA, WPA2, and OWE security via password authentication or Wi-Fi Protected Setup (WPS). Does not support connection to ad-hoc (or peer-to-peer) Wi-Fi networks.

Feature	Description
<b>Accessibility Features</b>	VoiceView screen reader (via Bluetooth audio), invert black and white, adjustable font size, font type, line spacing, and margins.
<b>Supported Content Formats</b>	Kindle Format 8 (AZW3), Kindle (AZW), TXT, PDF, unprotected MOBI, PRC natively; PDF, DOCX, DOC, HTML, EPUB, TXT, RTF, JPEG, GIF, PNG, BMP through conversion; Audible audio format (AAC).
<b>Included in the Box</b>	Kindle device, USB-C charging cable, and Quick Start Guide.
<b>Generation</b>	Kindle (11th Generation): 2024 version.

## WARRANTY AND SUPPORT

---

### Warranty Information

Your Kindle includes a 1-year limited warranty and service. Use of the Kindle is subject to the Amazon Conditions of Use.

### Software Updates

This device receives guaranteed software security updates for at least four years after it is last available for purchase as a new unit on our websites. For specific information about your device, visit [Manage Your Content and Devices](#).

### Further Assistance

For more information about Kindle devices, refer to the [Quick Start Guide](#) and the [Kindle User Guide](#) available online. You can also visit Amazon's customer support website for additional help.

## SAFETY INFORMATION

---

Please read the following safety information before using your Kindle:


- Do not expose your Kindle to extreme temperatures, direct sunlight for prolonged periods, or excessive moisture.
- Avoid dropping or subjecting the device to severe impact.
- Only use approved accessories, such as the included USB-C cable, for charging.
- Do not attempt to disassemble, repair, or modify your Kindle. This will void the warranty and could cause injury.
- Keep the device away from small children and pets.

---

© 2024 Amazon. All rights reserved.

---

### Related Documents - Kindle (11th Generation) - Matcha (B0CP31QS6R)

 	<p><a href="#"><b>Amazon Kindle Oasis Quick Start Guide and Information</b></a></p> <p>Concise guide for the Amazon Kindle Oasis e-reader, covering device overview, multilingual support information, and links to further resources. Optimized for accessibility and SEO.</p>
 <p><b>amazon</b> Amazon Fire Tablet and Kindle E-Reader Quick Setup Guide</p>	<p><a href="#"><b>Amazon Fire Tablet and Kindle E-Reader Quick Setup Guide</b></a></p> <p>A quick setup guide for Amazon Fire tablets and Kindle e-readers, covering battery charging, Wi-Fi connection, account registration, payment settings, content download, and sharing features like Family Library.</p>
 <p>Learn more about your Kindle by selecting the Kindle User's Guide in the Library on your device. For general Amazon Customer Service, visit <a href="http://www.amazon.com/gp/help/contact">www.amazon.com/gp/help/contact</a></p>	<p><a href="#"><b>Amazon Kindle E-Reader Quick Start and Support</b></a></p> <p>Get started with your Amazon Kindle e-reader. Find information on device usage, access the Kindle User's Guide, and contact Amazon Customer Service for support.</p>
 <p>getting to know your kindle</p> <p>To charge your Kindle, connect the USB charging cable to the Kindle and the other end to a computer, power outlet, or other power adapter (charging accessory sold separately). For other charging options, visit <a href="http://www.kindle.com/support/charging">www.kindle.com/support/charging</a>.</p> <p>To start your Kindle, press the power button. To unlock your Kindle, press the power button and the volume up button at the same time. To learn more about your Kindle, open the Help &amp; feedback app. For Kindle customer support, visit <a href="http://www.kindle.com/support">www.kindle.com/support</a></p>	<p><a href="#"><b>Amazon Kindle Fire HD Quick User Guide</b></a></p> <p>A quick user guide for the Amazon Kindle Fire HD, detailing device features, charging, unlocking, and important product information including terms, policies, and warranty.</p>
	<p><a href="#"><b>Kindle Kids Edition Quick Start Guide</b></a></p> <p>Get started with your Amazon Kindle Kids Edition. This guide covers what's included in the box and the initial setup process, including registration and claiming your 1-year Amazon FreeTime Unlimited subscription.</p>
 <p>Kindle User's Guide</p>	<p><a href="#"><b>Kindle User's Guide: Navigate and Master Your Amazon E-reader</b></a></p> <p>Comprehensive guide to using your Amazon Kindle e-reader. Learn about setup, content acquisition, reading features, settings, and product information.</p>