

**Absima 2000012**

# Absima CR9T RC Pistol Transmitter

## INSTRUCTION MANUAL

### Important Safety Information

**Read this instruction manual carefully before use to ensure safe operation and prevent damage to the product or injury.**

This product is not a toy and should be operated with caution. Keep out of reach of small children. Always ensure proper battery installation and disposal. Do not expose the device to moisture or extreme temperatures.

### Product Overview



An image showing the Absima CR9T RC Pistol Transmitter, a black and grey device with a screen displaying numerical information and a large steering wheel on the right side. The handle is ergonomically designed for grip.

The Absima CR9T is a 2.4 GHz 9-channel RC pistol transmitter designed for precise control of remote-controlled vehicles. It features an ergonomic design, a clear display for settings, and intuitive controls for an enhanced user experience.

### Setup

- Battery Installation:** Open the battery compartment cover located at the bottom of the transmitter. Insert the required batteries (not included) according to the polarity indicators. Close the cover securely.
- Receiver Binding:** Refer to your receiver's manual for specific binding instructions. Generally, power on the receiver in binding mode, then power on the transmitter while holding the bind button (if applicable).
- Initial Calibration:** After binding, perform a basic calibration of the steering and throttle channels to ensure proper response.

### Operating Instructions

- Power On/Off:** Press and hold the power button until the display illuminates/shuts off.
- Steering Control:** Use the steering wheel on the right side to control the vehicle's direction.
- Throttle Control:** Use the trigger for forward and reverse movement. Pull for forward, push for reverse.
- Channel Assignment:** Utilize the various switches and knobs on the transmitter to control auxiliary channels (e.g., lights, winches) as configured on your receiver.
- Display Navigation:** Use the navigation buttons around the screen to access and adjust settings such as trim, EPA (End Point Adjustment), D/R (Dual Rate), and model memory.

### Maintenance

- Cleaning:** Use a soft, dry cloth to clean the transmitter. Do not use harsh chemicals or solvents.
- Storage:** Store the transmitter in a cool, dry place away from direct sunlight and extreme temperatures. Remove batteries if storing for extended periods.
- Battery Care:** Always use fresh batteries of the recommended type. Do not mix old and new batteries or different battery types.

### Troubleshooting

Problem	Possible Cause	Solution
Transmitter does not power on	Dead or incorrectly installed batteries	Replace batteries; check polarity
No control response from vehicle	Not bound to receiver; receiver not powered; out of range	Re-bind transmitter and receiver; check receiver power; move closer to vehicle
Erratic control	Interference; low battery on transmitter/receiver	Move to a different location; replace batteries

## Specifications


Feature	Detail
Product Dimensions	14 x 10 x 18.5 cm
Weight	320 g
Item Model Number	2000012
Number of Items	1
Batteries Required?	No (for product, but required for operation)
Batteries Included?	No
ASIN	B0CP34F5K2
First Available Date	April 24, 2024

## Warranty and Support

We understand that it can be frustrating if a product does not work properly or becomes defective. Fortunately, we provide a warranty for a period of at least 2 years after purchase. For technical support, warranty claims, or further assistance, please refer to the contact information provided with your purchase or visit the official Absima website. Please have your model number (2000012) and proof of purchase ready when contacting support.

© 2024 Absima. All rights reserved.

Documents - Absima – 2000012



### [Absima CR9T Remote Control Quick Start Guide](#)

A quick start guide for the Absima CR9T 9-channel remote control system, including setup, operation, product parameters, and warranty information.

lang:de score:21 filesize: 43.65 M page\_count: 5 document date: 2023-10-10

Catalogue	
Before Use	3
Product safety precautions	3
Safety instructions	4
Package content	6
How to use the transmitter	7
Power on and off	8
Description of the remote control	9
Low voltage warning	9
Steering and throttle operation methods	10
How to operate the digital trim	10
How to adjust the trigger position	11
Wheel Angle adjustment	12
Charging function	12
How to replace the battery	13
Trigger wheel tightness adjustment method	13
How to operate a transmitter antenna	14
How to connect receiver and servo	15
Setup procedure for the model	17
Product feature	22
Base setting	23
Dual rate	23
Speed	24
Curve	27
Fail safe	33
Channel reverse	35
Sub trim	36
Trim setting	37
End point	37
Channel limit	39
Throttle function	40
A.B.S	40
Throttle idle	44
Throttle mode	45
Timer	47
Model timer	49

[\[pdf\]](#) User Manual Instructions Catalog

X9è%±æCE/è`ç»fè´æY ä! 2022 8 13 cdr Administrator Bedienungsanleitung eng CR10P Absima 10

Kanal Fernsteuerung günstig online kaufen 2000012 cr9t radio full manual 81284 mih toys de mediafiles

|||

Catalogue Before Use -----

----- 3 Product safety precautions-----

3 Safety Instructions -----...

lang:en score:18 filesize: 17.13 M page\_count: 101 document date: 2024-03-11