Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ANNFUZ 6206C

ANNFUZ Mechanical Keyless Keypad Entry Door Lock (Model 6206C)

Instruction Manual

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your ANNFUZ Mechanical Keyless Keypad Entry Door Lock, Model 6206C. This single-sided, manually locking door handle lever set offers a secure and convenient keyless entry solution without the need for batteries or electronic components. Please read these instructions carefully before installation and use to ensure proper function and longevity of the product.

2. What's in the Box

Verify that all components listed below are included in your package:

- 1x Exterior Panel with Lever
- 1x Interior Panel with Lever
- 1x Spindle
- 1x 60mm Latch
- 1x Strike Plate
- 1x Strike Box
- 2x Brass Keys
- 2x Rubber Seals
- 1x Instruction Manual (this document)
- 1x Screw Pack



Image: All components included in the ANNFUZ Mechanical Keyless Keypad Entry Door Lock package.

3. Product Dimensions

The ANNFUZ Mechanical Keyless Keypad Entry Door Lock is designed for specific door dimensions. Please ensure your door meets these requirements for proper installation.

- **Item Dimensions (L x W x H):** 3.3 x 5.5 x 5.5 inches
- **Applicable Door Thickness:** 1-3/8" to 2" (35 mm - 50 mm)
- **Applicable Backset:** 60 mm (2.36") only. **Not compatible with 70 mm (2.75") backset.**



Image: Detailed product dimensions and compatible door specifications.

4. Key Features

- **Full Mechanical Operation:** No batteries, power, or wiring required, ensuring reliability and eliminating concerns about power failure or battery replacement.
- **Manually Locked:** This lock requires manual locking and unlocking. It does not automatically engage.
- **Single-Sided Keypad:** The keypad is on the exterior side. The interior side allows unlocking without a code, ideal for frequently accessed doors.
- **Adjustable Handle:** Works with both left and right-handed doors.
- **Passage Mode:** Allows the lock to function as an ordinary door handle, bypassing the code requirement for temporary frequent access.
- **Customizable Passcode:** Set a 4-7 digit code using numbers or letters (excluding 'C' for repeats). Always press 'C' before entering the code.
- **Durable Construction:** Made from solid zinc alloy with long-lasting plating, suitable for outdoor use.

5. Setup and Installation

Before beginning installation, ensure your door meets the specified thickness and backset requirements (refer to Section 3). This lock is not suitable for glass doors.

5.1. Adjusting Latch Direction

The latch direction may need to be adjusted to match your door's opening direction. Follow the steps in the video below to change the latch orientation.

Your browser does not support the video tag.

Video: Instructions on how to change the direction of the latch on the ANNFUZ Mechanical Keyless Keypad Entry Door Lock.

5.2. Setting Exterior Keypad Panel Orientation (Left or Right)

The exterior keypad panel needs to be set for either left or right-hand opening. Refer to the video for detailed instructions on how to adjust this setting.

Your browser does not support the video tag.

Video: Guide to setting the left or right-hand opening for the exterior keypad panel of the ANNFUZ Mechanical Keyless Keypad Entry Door Lock.

5.3. General Installation Steps

1. Prepare the door: Drill necessary holes according to the provided template (if applicable) and ensure the existing backset is 60mm.
2. Install the latch: Insert the 60mm latch into the door edge and secure it with screws.
3. Assemble the panels: Connect the exterior and interior panels with the spindle, ensuring correct orientation as per the videos above.
4. Secure the lock: Fasten the panels to the door using the provided screws.
5. Install strike plate and box: Attach the strike plate and strike box to the door frame, aligning them with the latch.
6. Test operation: Before fully tightening, test the lock's function with the default code or your newly set code.

6. Operating Instructions

6.1. Setting/Changing the Passcode

The passcode can be 4-7 digits long, composed of numbers or letters. The 'C' button cannot be part of the code combination. Codes can be pressed in any order to unlock the lock.

1. Locate the code setting mechanism on the back of the exterior panel.
2. Using a flathead screwdriver, rotate the small screws corresponding to your desired code digits outwards (towards 'C').
3. For digits not part of your code, rotate their screws inwards (away from 'C').
4. Ensure the 'C' button's screw is always rotated inwards.
5. Test the new code before reassembling the lock.



Image: Guide to setting the lock's combination code.

6.2. Unlocking the Door

From the exterior:

1. Press the 'C' button.
2. Enter your passcode (digits can be pressed in any order).
3. Turn the handle to open the door.

From the interior: Simply turn the handle to open the door.

6.3. Engaging Passage Mode

Passage mode allows the door to be opened without a code, functioning as a standard handle. This is useful for periods of high traffic.

Your browser does not support the video tag.

Video: Instructions on how to activate and deactivate "passage mode" on the ANNFUZ Mechanical Keyless Keypad Entry Door Lock.

To activate Passage Mode:

1. Press 'C' and enter your passcode.
2. While holding the handle down, press the 'Y' button.
3. Release the handle. The lock is now in passage mode.

To deactivate Passage Mode:

1. While holding the handle down, press the 'C' button.
2. Release the handle. The lock will resume normal locking operation.

7. Maintenance

To ensure the long-term performance and appearance of your ANNFUZ door lock, follow these maintenance guidelines:

- **Cleaning:** Wipe the lock surface regularly with a soft, damp cloth. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Lubrication:** Periodically apply a small amount of graphite lubricant to the internal mechanisms (keyhole and latch bolt) to ensure smooth operation. Do not use oil-based lubricants, as they can attract dust and debris.
- **Screw Check:** Periodically check all mounting screws and tighten them if necessary to prevent looseness and ensure security.
- **Environmental Protection:** While designed for outdoor use, extreme weather conditions can affect performance. Consider adding a protective overhang for locks exposed to direct, heavy rain or prolonged sunlight.

8. Troubleshooting

If you encounter issues with your ANNFUZ Mechanical Keyless Keypad Entry Door Lock, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lock does not open with correct code.	Incorrect code entry sequence; internal mechanism issue; passage mode active.	Ensure 'C' is pressed first, then the code digits in any order. Verify internal code settings (Section 6.1). Check if passage mode is engaged (Section 6.3).
Handle is loose or wobbly.	Mounting screws are loose.	Tighten all mounting screws on both interior and exterior panels.
Latch does not retract or extend smoothly.	Misalignment; debris in mechanism; lack of lubrication.	Check alignment of strike plate and box. Clean any debris. Apply graphite lubricant (Section 7).
Lock does not engage (door remains unlocked).	Passage mode is active; latch not fully extending.	Deactivate passage mode (Section 6.3). Check for obstructions preventing the latch from fully extending.

9. Specifications

- **Brand:** ANNFUZ
- **Model Number:** 6206C
- **UPC:** 717023009759
- **Material:** Zinc Alloy
- **Color:** Pearl Chrome
- **Finish Type:** Brushed
- **Lock Type:** Combination Lock, Keypad
- **Special Features:** Adjustable, Lockable, Rustproof
- **Item Dimensions (L x W x H):** 3.3 x 5.5 x 5.5 inches
- **Item Weight:** 2.6 Pounds
- **Recommended Door Thickness:** 1-3/8" to 2" (35 mm - 50 mm)
- **Backset:** 60 mm (2.36")

10. Warranty Information

For specific warranty details regarding your ANNFUZ Mechanical Keyless Keypad Entry Door Lock, please refer to the warranty card included with your product or contact ANNFUZ customer support directly. Warranty coverage typically includes defects in materials and workmanship under normal use.

11. Support

If you require further assistance, have questions not covered in this manual, or need to report a product issue, please contact ANNFUZ customer support through the following channels:

- **Online:** Visit the official ANNFUZ website or the product page on Amazon for FAQs and contact information.
- **Email:** Refer to your product packaging or the ANNFUZ website for the customer service email address.
- **Phone:** Check the ANNFUZ website for available customer service phone numbers.

When contacting support, please have your product model number (6206C) and purchase information readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CP36WQ7X

More documents and user manuals: **https://manuals.plus/**