Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GAOMON GAOMON

GAOMON Kitchen Dining Room Table Set for 2 - Assembly and Care Manual

Model: GAOMON



Figure 1.0: GAOMON Kitchen Dining Room Table Set for 2.

1. Important Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Ensure all parts are present and undamaged before beginning assembly.
- Assemble on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly to avoid damaging components.
- Periodically check and retighten all fasteners to ensure stability.
- Do not stand on the table or chairs.
- Distribute weight evenly on the table surface.
- Keep small parts away from children during assembly.
- Maximum weight capacity for the table is **150 lbs (68 kg)**.

- Maximum weight capacity for each chair is **300 lbs (136 kg)**.

2. Package Contents

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer service.

- 1 x Dining Table
- 2 x Dining Chairs
- 1 x Accessory Bag (containing screws, bolts, and tools)
- 1 x Instruction Manual (this document)



Figure 2.1: Product dimensions and weight capacities. Table: 29.1" L x 29.1" W x 30" H, 150 lbs capacity. Chair: 17.7" L x 17.7" W x 35" H, 300 lbs capacity.

3. Assembly Instructions

Follow these steps carefully to assemble your GAOMON dining table set. It is recommended to have two people for assembly.

3.1. Chair Assembly

1. Unpack all chair components and lay them out on a protected surface.
2. Attach the chair backrest to the seat frame using the provided screws. Do not fully tighten yet.
3. Attach the front legs to the seat frame.
4. Attach the rear legs to the seat frame and backrest.
5. Once all screws are in place, gradually tighten them evenly until secure.



Figure 3.1: Assembled chair detail, showing the metal frame and rustic brown seat.

3.2. Table Assembly

1. Unpack all table components and lay them out on a protected surface.
2. Attach the table legs to the tabletop frame using the provided screws. Do not fully tighten yet.
3. Attach the crossbars or support structures between the legs for added stability.

4. Once all screws are in place, gradually tighten them evenly until secure.
5. Carefully flip the table upright.



Figure 3.2: Detail of the sturdy tabletop, showcasing its rustic brown finish.



Figure 3.3: The table features round corners for safety and aesthetics.

4. Usage and Space-Saving Features

This dining set is designed for small spaces, offering both functionality and a compact footprint.

- The chairs can be neatly tucked under the table when not in use, maximizing floor space.
- Ideal for apartments, kitchens, studios, or small dining areas.



Figure 4.1: Space-saving configuration with chairs stored under the table.

5. Maintenance and Care

Proper care will ensure the longevity and appearance of your dining set.

- **Cleaning:** Wipe with a damp cloth. The surface has a waterproof and anti-corrosion coating, making it easy to clean spills like soup or sauce.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or strong chemicals, as these can damage the finish.
- **Protection:** Use placemats or coasters to protect the tabletop from hot items or scratches.
- **Regular Inspection:** Periodically check all screws and bolts and tighten them if necessary to maintain structural integrity.

6. Troubleshooting

If you encounter any issues, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Table/Chair wobbles	Loose screws or uneven assembly.	Ensure all screws are tightened evenly. Check if the floor is level.
Difficulty assembling parts	Incorrect orientation of parts or overtightened screws.	Review the assembly instructions. Loosen screws slightly before aligning parts, then retighten.
Scratches on surface	Improper handling during assembly or use.	While the surface is scratch-resistant, avoid dragging sharp objects. For minor scratches, touch-up pens matching the rustic brown color may be used.

7. Specifications

Feature	Detail
Brand	GAOMON
Model Number	GAOMON
Color	Rustic Brown
Material	Metal, Engineered Wood (MDF)
Table Dimensions (L x W x H)	29.2" x 29.2" x 30" (74.2 x 74.2 x 76.2 cm)
Chair Dimensions (L x W x H)	17.6" x 15.4" x 34.9" (approx. 44.7 x 39.1 x 88.6 cm)
Item Weight	19.05 kg (approx. 42 lbs)
Table Weight Capacity	150 lbs (68 kg)
Chair Weight Capacity	300 lbs (136 kg)
Included Components	1 Table, 2 Chairs, Accessory Bag, Instruction Manual
Product Care Instructions	Wipe with Damp Cloth

8. Warranty and Customer Support

GAOMON is committed to providing high-quality products. While specific warranty details are not provided in this manual, please retain your proof of purchase.
If you have any questions regarding assembly, missing parts, or product issues, please contact GAOMON customer service. Refer to the contact information provided at the point of purchase or on the GAOMON brand website.
For more information, you may visit the GAOMON Store on Amazon.

© 2024 GAOMON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CP3D8TKQ

More documents and user manuals: **https://manuals.plus/**