

CAPHAUS POFCHF-CH001-BG@CH

CAPHAUS Zero Gravity Reclining Lounge Chair Instruction Manual

Brand: CAPHAUS

Model: POFCHF-CH001-BG@CH

INTRODUCTION

Thank you for choosing the CAPHAUS Zero Gravity Reclining Lounge Chair. This chair is designed to provide ultimate comfort and relaxation in various settings, from your garden to your living room. Its versatile design and durable construction ensure a comfortable and long-lasting experience.

Key features include:

- **Versatile Comfort:** Wide-angle adjustment for finding the perfect position.
- **Convenient Side Tray:** Detachable tray with cup holders, phone holder, and tablet holder.
- **Enhanced Comfort and Safety:** High-elastic bungee ropes, L-shaped non-slip foot covers, and breathable Teslin fabric for stability and comfort.
- **Wide Angle Adjustment:** 150° adjustment range for various reclining positions.
- **Easy to Store:** Foldable design for compact storage and portability.

SAFETY INFORMATION

Please read and understand all safety information before using the chair.

- Do not exceed the maximum recommended user weight of **300 pounds**. While the chair has a maximum static weight capacity of 350 pounds, for optimal relaxation and peace of mind, adhere to the recommended user weight.
- Ensure proper assembly and use the chair on a stable, level surface to prevent tipping.
- Keep fingers and hands clear of moving parts during adjustment and folding to avoid pinching.
- Do not allow children to play on or around the chair unsupervised.

PARTS LIST

The CAPHAUS Zero Gravity Reclining Lounge Chair comes pre-assembled in a foldable state. The main components include:

- Chair Frame (Black metal frame)
- Teslin Fabric Seating and Backrest (Beige)
- Adjustable Headrest/Lumbar Pillow
- Detachable Side Tray (with 2 cup holders, phone holder, tablet holder)
- High-elastic Bungee Ropes (connecting fabric to frame)
- L-typed Non-slip Foot Covers



Figure 1: Fully assembled CAPHAUS Zero Gravity Reclining Lounge Chair in beige.

SETUP

The CAPHAUS Zero Gravity Reclining Lounge Chair is designed for quick and easy setup. It arrives folded for compact storage.

1. **Unfolding the Chair:** Carefully remove the chair from its packaging. Hold the top and bottom sections of the chair and gently pull them apart until the chair fully extends and locks into an upright position. Ensure all legs are firmly on the ground.
2. **Attaching the Side Tray:** Locate the detachable side tray. Align the tray's attachment mechanism with the designated slot on the chair's armrest. Push firmly until it clicks securely into place.
3. **Adjusting the Headrest/Lumbar Pillow:** The pillow can be slid up or down the backrest to serve as a headrest or lumbar support, depending on your preference.



Figure 2: The chair is foldable for easy transport and storage, making setup straightforward.

OPERATING INSTRUCTIONS

The zero gravity chair offers a wide range of reclining positions for optimal comfort.

1. **Reclining:** To recline, gently push back on the armrests while leaning your body backward. The chair will smoothly glide into a reclined position.

2. **Locking Position:** Once you find your desired angle, locate the locking knobs on both armrests (typically below the armrest). Turn these knobs clockwise to tighten and secure the chair in that position.
3. **Returning to Upright Position:** To return to an upright position, unlock the knobs by turning them counter-clockwise. Then, gently push forward on the armrests and lean your body forward. The chair will return to its upright state.
4. **Using the Side Tray:** The detachable side tray provides convenient access to your items. Place beverages in the cup holders, and use the dedicated slots for your phone or tablet.



150° WIDE-ANGLE ADJUSTMENT

WAYS TO USE BY LOSING AND LOCKING





Figure 3: The chair features a 150-degree wide-angle adjustment for personalized comfort.



DETACHABLE SIDE TRAY

ENJOY YOUR RELAXATION WITH ALL YOUR
GADGETS AND ESSENTIALS CONVENIENTLY
CLOSE AT HAND.



TABLET REST



2 CUP HOLDERS



PHONE MOUNT

Figure 4: The convenient detachable side tray keeps your essentials within reach.

MAINTENANCE

To ensure the longevity and appearance of your CAPHAUS Zero Gravity Reclining Lounge Chair, follow these simple maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. For stubborn stains on the Teslin fabric, use a mild soap solution and rinse thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, especially during inclement weather or off-season, fold the chair for compact storage. Storing it indoors or under a protective cover will extend its lifespan.
- **Inspection:** Periodically check all bolts, screws, and bungee ropes to ensure they are secure and in good condition. Tighten any loose fasteners.



Figure 5: Features like breathable Teslin fabric and high-elastic bungee ropes are designed for durability and easy maintenance.

TROUBLESHOOTING

If you encounter any issues with your chair, please refer to the following common solutions:

- **Chair does not recline smoothly:** Ensure the locking knobs on the armrests are fully loosened. Check for any obstructions in the reclining mechanism.
- **Chair feels unstable:** Verify that the chair is fully unfolded and all legs are on a flat, stable surface. Check all bungee ropes for proper tension and ensure they are not damaged.
- **Side tray is loose:** Re-attach the side tray, ensuring it clicks firmly into place. If it continues to be loose, inspect the attachment points for any damage.

For issues not covered here, please contact CAPHAUS customer support.

SPECIFICATIONS

Feature	Detail
Brand	CAPHAUS
Model Name	CH POFCHF
Product Dimensions (Upright)	35.4"D x 25.6"W x 43.3"H
Product Dimensions (Fully Reclined)	60.6"D x 25.6"W x 33.5"H
Folded Dimensions	34.1" x 25.4" x 4.3"
Color	Beige
Back Style	Mesh
Special Features	Arm Rest, Ergonomic, Seat Lock, Head Support
Product Care Instructions	Wipe Clean
Recommended Uses	Relaxing, Reading
Maximum Weight Recommendation	300 Pounds
Included Components	Side Tray
Reclining Position Count	>2 (Multiple positions)
Number of Cup Holders	2
Item Weight	16.28 pounds
Manufacturer	SCR HOLDING CO. INC



DIMENSION

Compact to Unwind :

Tailored Sizes for Your Perfect Escape!



Figure 6: Detailed dimensions for both upright and folded configurations, along with side tray dimensions.



RECOMMENDED USER WEIGHT 300 LB

MAXIMUM STATIC WEIGHT CAPACITY **350** LB

CAPHAUS®

Figure 7: Important information regarding the chair's weight capacity.

WARRANTY AND SUPPORT

For any questions, concerns, or warranty inquiries regarding your CAPHAUS Zero Gravity Reclining Lounge Chair, please contact the manufacturer, SCR HOLDING CO. INC, or refer to the seller's return policy on the purchase platform.

Seller: WF Athletic Supply

Return Policy: 30-day refund/replacement (as per Amazon's buybox winner information).

© 2025 CAPHAUS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CP3G7C7N>

More documents and user manuals: <https://manuals.plus/>