Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YAMAZAKI 4810

YAMAZAKI Home 2-Tier Hideaway Storage Cart

Model: 4810

Introduction

This manual provides instructions for the assembly, operation, and maintenance of your YAMAZAKI Home 2-Tier Hideaway Storage Cart. Designed to relieve clutter, this cart features a height-adjustable top shelf and a rolling design for easy access. Its sleek front panel offers concealed storage, making it ideal for organizing pantry items, cleaning products, and other essentials.

Safety Information

Please read all safety warnings before assembly and use.

- Do not exceed the weight capacity of**22 lbs (10 kg)** on the upper shelf.
- Do not exceed the weight capacity of**44 lbs (20 kg)** on the lower shelf.
- Ensure all parts are properly secured before placing items on the cart or moving it.
- Do not allow children to play on, with, or around the cart.
- Use on a flat, stable surface to prevent tipping.

Package Contents

Verify that all components are present before beginning assembly:

- Storage Cart Frame
- Upper Shelf Board
- Lower Shelf Board
- Casters (4x)
- Handles (2x)
- Front Panel
- Hooks (4x)
- Assembly Hardware (screws, nuts, etc.)
- Wrench (1x)

Setup and Assembly

Follow these steps to assemble your storage cart:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Casters:** Securely attach the four casters to the bottom of the cart frame. Ensure they are tightened with the provided wrench.
3. **Assemble Frame:** Connect the vertical frame pieces to the horizontal supports using the provided hardware. Do not fully tighten screws until all parts are aligned.
4. **Install Shelf Boards:** Place the lower shelf board onto its designated supports. For the upper shelf, adjust its height as desired before securing it. Ensure both shelves are level and firmly attached.
5. **Attach Handles and Front Panel:** Secure the handles to the top sides of the cart. Attach the front panel to the designated side, ensuring it aligns correctly for concealed storage.
6. **Attach Hooks:** The four hooks can be attached to the side rails of the cart for additional hanging storage.
7. **Final Tightening:** Once all components are in place and aligned, fully tighten all screws and fasteners.


Hero.
CLEAR

The YAMAZAKI Home 2-Tier Hideaway Storage Cart fully assembled.

Operating Instructions

Mobility and Placement

The cart is equipped with smooth-rolling casters and integrated handles for easy movement. Simply push or pull the cart to reposition it as needed. Its compact design allows it to be tucked away under counters or into narrow spaces, minimizing visual clutter.



The cart features casters and handles for convenient movement.

Adjustable Shelf

The upper shelf board can be adjusted to different heights to accommodate various item sizes. To adjust, loosen the fasteners holding the upper shelf, reposition it to the desired height, and then securely tighten the fasteners. This

feature allows for efficient storage of bulky items like large food containers, bottles, or pet supplies.



The adjustable shelf allows for flexible storage configurations.


Concealed Storage and Hooks

The cart's solid front panel helps to conceal contents, maintaining a tidy appearance. Utilize the included hooks for hanging smaller items, such as kitchen utensils, towels, or pet leashes, adding to the cart's versatile storage capabilities.



Multi-functional design makes this wagon ideal for organizing everything from kitchen supplies to toys.

The front panel provides concealed storage for a neat look.



Hooks provide additional hanging storage options.

Product in Use

Your browser does not support the video tag.

Video demonstrating the YAMAZAKI Home 2-Tier Hideaway Storage Cart's mobility and storage capabilities, showing it being pushed and rotated for access.

Your browser does not support the video tag.

Video showcasing the YAMAZAKI Home 2-Tier Hideaway Storage Cart's design, highlighting its handle and rolling features for easy access and storage.

Maintenance

To keep your storage cart in optimal condition:

- **Cleaning:** Wipe clean with a soft, damp cloth. Immediately wipe dry to prevent water spots or rust.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Tighten if necessary.
- **Caster Care:** Keep casters free of debris to ensure smooth rolling.


Troubleshooting

If you encounter issues with your storage cart, consider the following:


- **Instability:** Ensure all assembly hardware is fully tightened. Verify the cart is on a flat, level surface. Do not exceed stated weight capacities.
- **Difficulty Rolling:** Check casters for any trapped debris (hair, lint, etc.) and clean if necessary. Ensure casters are securely attached.
- **Shelf Not Holding:** Re-check that the adjustable shelf's fasteners are securely tightened after positioning.

Specifications

Feature	Detail
Model Number	4810
Product Dimensions (L x W x H)	12.6" x 16.54" x 23.62" (32cm x 42cm x 60cm)
Item Weight	15.7 lbs (7.1 kg)
Material	Alloy Steel
Number of Shelves	2
Upper Shelf Weight Capacity	22 lbs (10 kg)
Lower Shelf Weight Capacity	44 lbs (20 kg)
Included Components	Wrench, Hooks (4x)



Imperial dimensions of the storage cart.



Metric dimensions of the storage cart.

Warranty and Support

Warranty: Manufacturer warranty information is not specified in the product details. Please refer to your purchase documentation or contact the retailer for specific warranty terms.
Customer Support: For further assistance, missing parts, or inquiries, please contact YAMAZAKI Home customer service through their official website or the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CP3GRMGH

More documents and user manuals: **https://manuals.plus/**