

Beautyrest BR55-4071

Beautyrest Heated Mattress Pad Twin (Model BR55-4071) - Instruction Manual

INTRODUCTION

Welcome to your new Beautyrest Heated Mattress Pad. This manual provides essential information for the safe and effective use of your product.

This mattress pad features a cool-to-the-touch fabric for warmer nights and a controller with 5 heat settings for colder nights. Soft, flexible wires ensure even heat distribution, and overheating technology provides safety. The cooling material and heating function make this machine washable pad suitable for all seasons.

IMPORTANT SAFETY INFORMATION

- This product is UL certified and independently tested to meet high safety standards.
- Do not leave the controller covered when in use to avoid overheating.
- Do not use this heated product on waterbeds, bunk beds, adjustable mechanical beds, or children's cribs and beds.
- Ensure the heating element is laid flat and not bunched or pinched. Manually twist any twisted wires back into place.
- The control may feel warm (not hot) to the touch during operation. If it becomes hot, discontinue use and contact customer service.

PACKAGE CONTENTS

- 1 Beautyrest Heated Mattress Pad (Twin size: 39"W x 75"L + 15"D)
- 1 Controller with 12.5ft cord
- 1 Power Cord (6ft)

SETUP INSTRUCTIONS

1. **Unpack the Mattress Pad:** Carefully remove the heated mattress pad from its packaging.
2. **Position on Bed:** Place the mattress pad directly on your mattress, ensuring it lies flat and smooth. The deep pocket design with all-around elastic will fit mattresses up to 18 inches thick.



Image: The Beautyrest Heated Mattress Pad shown on a bed, highlighting its deep pocket design and 360-degree elastic for a secure fit on mattresses up to 18 inches deep.

3. **Connect Controller:** Locate the connector on the mattress pad. Plug the controller cord firmly into this connector. For Twin size, there is one controller.
4. **Plug into Power:** Plug the power cord into a standard 120V/60Hz electrical outlet. Ensure the cord is not pinched or covered.

OPERATING INSTRUCTIONS

Your Beautyrest Heated Mattress Pad is designed for easy operation with its intuitive controller.



Image: Close-up of the Beautyrest controller, showing the 5 heat level settings, preheat button, and power button.

1. **Power On/Off:** Press the **Power** button on the controller to turn the mattress pad on or off.
2. **Select Heat Level:** Use the **UP** and **DOWN** buttons to choose from 5 heat settings. The selected level will be displayed on the controller.
3. **Pre-Heat Function:** Press the **PREHEAT** button for a 1-hour boost to quickly warm your bed before use.
4. **Automatic Shut-Off:** The mattress pad features a 10-hour automatic shut-off for safety and energy conservation.
5. **Smart Home Compatibility:** This mattress pad is compatible with smart home outlets and automatic timers for scheduled control.

CARE AND MAINTENANCE

Proper care ensures the longevity and performance of your heated mattress pad. Always disconnect the power cord from the wall outlet and the controller from the mattress pad before cleaning.



Image: Visual guide illustrating the steps for washing and drying the heated mattress pad, including hand wash/delicate cycle, cold water, minimal detergent, immediate removal after spin, tumble dry low for 5 minutes, gentle stretch, and hang dry.

Washing Instructions:

- **Machine Wash:** Use a delicate cycle with cold water and minimal detergent.
- **Hand Wash:** If preferred, wash by hand in cold water with minimal detergent.
- **Rinse:** Rinse thoroughly in cold water.
- **Spin Cycle:** Remove immediately after the spin cycle to prevent creasing.
- **Do Not Bleach.**

Drying Instructions:

- **Tumble Dry:** Tumble dry on low or medium heat for no more than 5 minutes.
- **Hang Dry:** Gently stretch the damp bedding and hang to finish drying.
- **Do Not Iron.**
- **Do Not Hang with Clothespins:** This can damage the internal wires.
- **Check Wires:** Periodically check and straighten any bent or twisted wires to preserve shape and functionality.

TROUBLESHOOTING

Q: Why is my light blinking?

A: If an ERROR is detected, the controller display will show an "E" followed by a number, and the power to the heating element will not be turned on. If you encounter this "ERROR" condition, refer to the instructions in your manual for specific troubleshooting steps or contact customer support.

Q: Only parts of my heated mattress pad are getting warm.

A: This is typically caused by a bunched or pinched heating element. Ensure the heated mattress pad is laid flat and not tucked in, and that nothing heavy is on it. Lay the mattress pad flat and run your fingers along the wire paths, paying special attention to the top and bottom edges where wires might bend. Manually twist any twisted wires back into place.

Q: My controller feels warm to the touch. Is this a problem?

A: No. The control will feel warm (not hot) to the touch when functioning properly. Even when the controller is on, small amounts of electricity will cycle through it, which may make the controller warm. If the controller

gets hot to the touch, discontinue use and contact customer service immediately.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Beautyrest
Model Number	BR55-4071
Size	Twin (39"W x 75"L + 15"D)
Color	White
Fabric Type	67% Olefin, 33% Polyester
Special Feature	Washable, Cool-to-Touch Fabric, 5 Heat Settings, Auto Shut-Off, Deep Pocket
Power Input	120V/60Hz
Certifications	UL Certified
Item Weight	2.46 pounds

WARRANTY AND SUPPORT

Warranty Information:

Your Beautyrest Heated Mattress Pad is backed by a **5-year warranty**. Please retain your proof of purchase for warranty claims.

Customer Support:

For any questions, assistance, or to report issues, please contact Beautyrest customer service. Refer to the product packaging or the official Beautyrest website for current contact information.

Online Support: [Visit the Beautyrest Store on Amazon](#)