Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOGOKIDS HG-FC3324

HOGOKIDS City Passenger Airplane Building Set Instruction Manual

Model: HG-FC3324

Brand: HOGOKIDS

Introduction

The HOGOKIDS City Passenger Airplane Building Set is a comprehensive 3-in-1 STEM toy designed to foster creativity, imagination, logic thinking, communication, and cooperation. This set allows for the construction of three distinct airport-themed models: a passenger airplane with ground vehicles, a helicopter with a control tower, or a different configuration of the passenger airplane with a radar tower and shuttle bus. Comprising 711 pieces, this building block set provides an engaging and educational experience for children and adults aged 6 and above.



Image: The HOGOKIDS City Passenger Airplane Building Set, illustrating its 3-in-1 capability with the main airplane, a helicopter, and a control tower, along with smaller ground vehicles.

Safety Information

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

This toy must be used under the direct supervision of an adult. Recommended age for assembly and play is 6 years and older.



Image: Product warning label indicating choking hazard for children under 3 years and recommended age of 6+.

Setup and Assembly

This building set includes detailed, step-by-step instructions to guide you through the assembly of each model. Please refer to the included instruction booklet for specific building sequences. The set offers three primary building configurations:

1. **Mode A: Passenger Airplane with Control Tower and Baggage Truck.** This configuration focuses on a large passenger aircraft and a detailed air traffic control tower, accompanied by a baggage handling vehicle.
2. **Mode B: Helicopter with Airport Building.** This mode allows for the construction of a rescue helicopter and a multi-story airport terminal building.
3. **Mode C: Passenger Airplane with Radar Tower and Shuttle Bus.** An alternative airplane configuration featuring a radar tower and a shuttle bus for passenger transport.

Ensure all pieces are securely connected during assembly to maintain structural integrity. While the set is designed for 3-in-1 building, only one model can be constructed at a time using the provided pieces.



Image: Visual guide displaying the three different building modes (A, B, C) with their respective components and approximate dimensions.



Image: Two children engaged in assembling the building set, with the partially built airplane and control tower visible on the table.

Operating and Play Features

Once assembled, the HOGOKIDS City Passenger Airplane Building Set offers various interactive features for enhanced play:

- **Rotating Propellers:** The airplane and helicopter models feature propellers that can be manually rotated, simulating flight.
- **Opening Doors/Hatches:** The airplane includes opening doors and cargo hatches, allowing for imaginative loading and unloading scenarios.
- **Movable Ground Vehicles:** The baggage truck and shuttle bus are designed with rolling wheels for dynamic play on flat surfaces.

- **Detailed Control Tower:** The control tower model includes multiple levels and details for realistic airport operations.



Image: A collage of close-up images highlighting the interactive elements of the set, including a rotating propeller, opening passenger doors, a movable cargo hatch, and spinning helicopter blades.



Image: The fully assembled passenger airplane, control tower, baggage truck, and shuttle bus arranged on a simulated airport runway, ready for play.

Maintenance

To ensure the longevity and cleanliness of your HOGOKIDS building set, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to gently wipe dust from the building blocks. For more thorough cleaning, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the building blocks in a cool, dry place away from direct sunlight to prevent discoloration or warping. Keep them in their original box or a dedicated storage container to prevent loss of pieces.
- **Handling:** Handle pieces with care to avoid breakage. While durable, excessive force can damage the connections.

Troubleshooting

If you encounter any issues during assembly or play, consider the following common solutions:

Problem	Possible Cause	Solution
Pieces do not fit together tightly.	Incorrect piece orientation or slight manufacturing variation.	Ensure pieces are aligned correctly. Apply firm, even pressure. If a piece consistently does not fit, check the instruction manual for the correct part number.
Model breaks apart easily during play.	Pieces not fully pressed together during assembly, or excessive force applied during play.	Re-assemble the affected sections, ensuring each block is firmly clicked into place. Encourage gentle play.
Missing pieces.	Pieces may have been overlooked during unboxing or misplaced.	Carefully check all packaging materials and the play area. If pieces are genuinely missing, contact HOGOKIDS customer support.

Specifications

Product Name: City Passenger Airplane Building Set

Model Number: HG-FC3324

Number of Pieces: 711 PCS

Material: ABS Plastic

Recommended Age: 6+ Years Old

Product Dimensions: 10 x 10 x 10 inches (approximate assembled size, varies by model)

Item Weight: 10.4 ounces

Manufacturer: HOGOKIDS

Warranty and Support

HOGOKIDS is committed to providing high-quality building blocks and customer satisfaction. For any inquiries regarding missing parts, damaged components, or assembly assistance, please contact HOGOKIDS customer support.

Official Website: www.hogokidstoys.com

Email: info@hogokids.com

Please retain your purchase receipt as proof of purchase for any warranty claims or support requests.

© 2025 HOGOKIDS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CP3NBHBN

More documents and user manuals: **https://manuals.plus/**