



[Manuals.plus](#) /

> [HP](#) /

> HP 15.6-inch Laptop User Manual

## HP 15-fd0083wm

# HP 15.6-inch Laptop User Manual

Model: 15-fd0083wm

## INTRODUCTION

---

Welcome to your new HP 15.6-inch Laptop. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read this manual thoroughly to ensure optimal performance and longevity of your laptop.

This laptop features an Intel Pentium Processor, 4GB of RAM, and 128GB UFS storage, running on Windows 11 Home.

## Package Contents

- HP 15.6-inch Laptop
- Charger
- User Manual (this document)

## SETUP

---

### Initial Power-On

1. Connect the provided charger to the laptop's power port and a wall outlet.
2. Open the laptop lid. The laptop may power on automatically. If not, press the power button located on the keyboard deck.
3. Follow the on-screen instructions to complete the Windows 11 setup process, including language selection, network connection, and user account creation.

### Connecting Peripherals

Your HP laptop includes various ports for connecting external devices:

- **USB Ports:** Connect USB devices such as mice, keyboards, or external storage drives.
- **Audio Jack:** Connect headphones or external speakers.
- **Power Port:** For connecting the charger.



*Image: The HP 15.6-inch laptop in Scarlet Red, viewed from the side with the lid open, showcasing the keyboard and the vibrant red exterior.*

## OPERATING YOUR LAPTOP

---

### Keyboard and Touchpad

The laptop features a full-size keyboard and a precision touchpad.

- **Keyboard:** Standard QWERTY layout with function keys (F1-F12) for quick access to system controls like volume, brightness, and Wi-Fi.
- **Touchpad:** Supports multi-touch gestures for navigation, scrolling, and zooming. Refer to Windows 11 settings for customizing touchpad gestures.

### Display

The 15.6-inch HD display offers a resolution of 1366 x 768 pixels. Adjust brightness using the function keys or through Windows display settings.

### Power Management

To conserve battery life and manage performance:

- **Sleep Mode:** Close the lid or select "Sleep" from the Start menu.
- **Shut Down:** Select "Shut down" from the Start menu to completely power off the device.
- **Restart:** Select "Restart" from the Start menu to reboot the system.

## MAINTENANCE

---

### Cleaning

To keep your laptop in optimal condition:

- Use a soft, lint-free cloth to clean the screen and exterior.
- For stubborn marks, dampen the cloth with water or a non-abrasive screen cleaner.
- Avoid spraying liquids directly onto the laptop.

### Software Updates

Regularly update your Windows 11 operating system and drivers to ensure security and performance.

- Go to **Settings > Windows Update** to check for and install updates.

### Storage Management

The 128GB UFS storage can fill up quickly. Regularly manage your files:

- Delete unnecessary files.
- Uninstall unused applications.
- Utilize cloud storage or external drives for large files.

## TROUBLESHOOTING

---

This section addresses common issues you might encounter.

### Power Issues

Problem	Solution
Laptop does not turn on	Ensure the charger is securely connected and the power outlet is functional. Try a different outlet.
Battery not charging	Verify charger connection. Check for any damage to the charger cable or port.

### Performance Issues

Problem	Solution
Laptop is slow	Close unnecessary applications. Check for background processes. Ensure sufficient free storage space.
Applications freezing	End task via Task Manager (Ctrl+Shift+Esc). Update the application or reinstall it.

### Connectivity Issues

Problem	Solution
Wi-Fi not connecting	Restart the laptop and router. Check Wi-Fi settings and ensure airplane mode is off.

## SPECIFICATIONS

Feature	Detail
Model	HP 15.6 (15-fd0083wm)
Display Size	15.6 Inches
Screen Resolution	1366 x 768 pixels
Processor	Intel Pentium Processor (1.1 GHz)
RAM	4 GB DDR4
Hard Drive	128 GB UFS (Solid State)
Graphics Coprocessor	Intel UHD Graphics 605 (Integrated)
Operating System	Windows 11 Home
Wireless Type	802.11ac
Item Weight	3.53 pounds
Product Dimensions	14.17 x 9.29 x 0.73 inches
Color	Scarlet Red

## WARRANTY AND SUPPORT

This product is sold as "Renewed." Please refer to the seller's specific warranty and return policy for details.

For technical support, visit the official HP support website or contact their customer service.

**Return Policy:** The buybox winner indicates a 90-day return policy for refund/replacement.

**Protection Plans:** Additional protection plans may be available for purchase.