

PHILIPS BHD500/00

Philips BHD500/00 Series 5000 Hair Dryer User Manual

Model: BHD500/00

1. INTRODUCTION

Thank you for choosing the Philips BHD500/00 Series 5000 Hair Dryer. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your hair dryer. Please read these instructions carefully before first use and retain them for future reference.

2. SAFETY INFORMATION

To reduce the risk of electric shock, burns, fire, or injury, always follow these basic safety precautions:

- Do not use this appliance near water, such as in a bathtub, washbasin, or other vessels containing water.
- Always unplug the appliance immediately after use.
- Do not use the appliance if the cord or plug is damaged.
- Keep the appliance away from children.
- Do not block the air inlets or outlets during operation.
- If the appliance overheats, it will automatically switch off. Unplug it and let it cool down for a few minutes before restarting.

3. PRODUCT OVERVIEW

The Philips BHD500/00 Series 5000 Hair Dryer is designed for efficient hair drying with ThermoProtect Technology to help prevent heat damage.

Components

- Hair Dryer Unit
- Concentrator Nozzle (14mm)



Image: Philips BHD500/00 Series 5000 Hair Dryer packaging, showing the hair dryer and concentrator nozzle.



Image: The Philips BHD500/00 Hair Dryer in white, with the transparent concentrator nozzle detached.







Image: A close-up of the control panel on the hair dryer handle, showing buttons for heat, speed, and cool shot.

4. SETUP

Follow these steps to prepare your hair dryer for first use:

1. **Unpack:** Carefully remove the hair dryer and all accessories from the packaging.
2. **Inspect:** Check the appliance for any visible damage. Do not use if damaged.
3. **Attach Nozzle (Optional):** If desired, attach the concentrator nozzle to the front of the hair dryer by aligning it and pushing it firmly into place.
4. **Connect to Power:** Plug the power cord into a suitable electrical outlet. Ensure the voltage matches the specifications of the appliance.

5. OPERATING INSTRUCTIONS

The Philips BHD500/00 offers various settings for customized drying and styling.

Powering On/Off

To turn the hair dryer on, slide the main power switch to your desired speed setting. To turn it off, slide the switch to the '0' position.

Adjusting Heat and Speed

The hair dryer features 6 flexible heat and speed combinations. Use the respective switches on the handle to select your preferred settings:

- **Speed Settings:** Controls the airflow intensity.
- **Heat Settings:** Controls the temperature of the airflow. The ThermoProtect setting provides optimal drying temperature while protecting against overheating.

Using the Cool Shot Function

Press and hold the cool shot button to deliver a burst of cool air. This helps to set your hairstyle and add shine after drying.

Using the Concentrator Nozzle

The slim 14mm concentrator nozzle directs airflow for precise styling. Use it with a brush to shape specific sections of your hair.



Image: A woman holding the Philips BHD500/00 Hair Dryer, illustrating its comfortable grip and balanced design.



Image: A woman drying her hair with the Philips BHD500/00 Hair Dryer, showing the airflow directed towards her hair.



Image: A woman using the concentrator nozzle on the Philips BHD500/00 Hair Dryer with a round brush to style her hair.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your hair dryer.

- **Always unplug** the appliance before cleaning.
- **Clean the Air Inlet Filter:** Periodically remove any dust or hair accumulated on the rear air inlet grille using a soft brush or cloth. A clogged filter can reduce airflow and cause overheating.
- **Clean the Exterior:** Wipe the exterior of the hair dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the appliance in a dry place, away from moisture and direct sunlight. Use the hanging loop for convenient storage.



Image: The Philips BHD500/00 Hair Dryer resting on a wooden table, showcasing its compact design.

7. TROUBLESHOOTING

If you encounter issues with your hair dryer, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Hair dryer does not turn on.	No power supply.	Check if the plug is securely inserted into the outlet. Test the outlet with another appliance.
Hair dryer stops during use.	Overheating protection activated.	Unplug the appliance and let it cool down for several minutes. Clean the air inlet filter.
Weak airflow.	Clogged air inlet filter.	Clean the air inlet filter to remove dust and hair.
Unusual noise.	Debris in the fan.	Unplug the appliance. If accessible, carefully remove any debris. If not, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model	BHD500/00



Feature	Detail
Brand	PHILIPS
Wattage	2100 watts
Technology	ThermoProtect, Ionic Care
Number of Heat/Speed Settings	6
Cool Shot	Yes
Concentrator Nozzle	14mm slim styling nozzle
Power Source	Corded Electric
Cord Length	1.8m
Color	White
Material	Plastic
Package Dimensions	31 x 23 x 11.7 cm
Weight	850 g





9. WARRANTY AND SUPPORT

This Philips appliance comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.

For product support, service, or further information, please visit the official Philips website or contact your local Philips customer service center. Contact details can typically be found in the warranty documentation or on the Philips website.

Related Documents - BHD500/00

	<p>Philips DryCare Pro Hair Dryer BHD272/00 - Professional Performance</p> <p>Discover the Philips DryCare Pro hair dryer (BHD272/00) with a powerful 2100W AC motor, 130 km/h air speed, ThermoProtect technology, ionic conditioning, and 6 heat/speed settings for fast, professional styling.</p>
	<p>Philips Series 5000 Hair Dryer User Manual - Safety and Usage Guide</p> <p>Comprehensive user manual for the Philips Series 5000 Hair Dryer, covering important safety instructions, usage guidelines, electromagnetic field information, and recycling instructions.</p>

	<p>Philips Hair Dryer 8000 Series User Guide</p> <p>Comprehensive user guide for the Philips Hair Dryer 8000 Series (models BHD837, BHD839), detailing features, usage, troubleshooting, and maintenance for optimal hair care and styling.</p>
	<p>Philips BHD290 Hair Dryer User Manual</p> <p>User manual for the Philips BHD290 hair dryer. Learn about its features, including ionic technology for reduced frizz and enhanced shine, the styling nozzle for concentrated airflow and precise styling, and the volume diffuser for gentle drying and added volume. The manual emphasizes safe usage, maintenance, and warranty information, guiding users on how to best utilize their Philips hair dryer.</p>
	<p>Philips 5000 Series Hair Dryer User Manual & Safety Guide</p> <p>Comprehensive safety instructions, warnings, and usage guidelines for the Philips 5000 Series Hair Dryer (models BHD500, BHD501, BHD504). Learn how to use the appliance safely, avoid hazards, and understand recycling information.</p>
	<p>Машинка для стрижки волоса Philips серії 5000 HC5610/15: Точність, Довговічність та Легкість</p> <p>Огляд машинки для стрижки волоса Philips серії 5000 HC5610/15. Дізнайтеся про технології Trim-and-Flow, DuraPower, 28 налаштувань довжини, самозаточувані леза та легке обслуговування.</p>