

[Manuals.plus](#) /

- › [DELSEY PARIS](#) /
- › DELSEY PARIS Chatelet Air 2.0 Hardside Luggage Instruction Manual

DELSEY PARIS Chatelet Air 2.0

DELSEY PARIS Chatelet Air 2.0 Hardside Luggage Instruction Manual

Model: Chatelet Air 2.0 - 3 Piece Set (20/28/Crossbody)

INTRODUCTION

Thank you for choosing DELSEY PARIS Chatelet Air 2.0 Hardside Luggage. This manual provides essential information for the proper setup, operation, maintenance, and care of your luggage set. Designed for durability and convenience, your Chatelet Air 2.0 luggage features a lightweight polycarbonate shell, spinner wheels, and a secure closing system.



Image: The DELSEY PARIS Chatelet Air 2.0 Hardside Luggage 3 Piece Set in Chocolate Brown, showing the carry-on, large checked bag, and crossbody bag.

SETUP INSTRUCTIONS

1. Unpacking

Carefully remove all luggage pieces from their packaging. Inspect each item for any signs of damage. Retain packaging for future storage or returns if necessary.

2. Setting the TSA Combination Lock

Your luggage is equipped with a recessed 3-dial TSA accepted combination lock. The default combination is 0-0-0.

1. Open the lock by sliding the button (A) to the side.
2. With the lock open, use a pen or pointed object to press the reset button (B) until you hear a click.
3. Set your desired 3-digit combination by turning the dials (C).
4. Slide the button (A) again. The reset button (B) will pop back up, and your new combination is set.
5. Test your new combination to ensure it works correctly before scrambling the dials.



Image: A close-up view of the recessed 3-dial TSA combination lock, showing the dials and reset button for setting a personal code.

3. USB Port Usage (20-inch Carry-on only)

The 20-inch carry-on features an integrated USB port for convenient charging of your electronic devices. To use this feature:

- Locate the internal pocket designed to hold a power bank (not included).
- Connect your power bank to the internal USB cable.
- Connect your device's charging cable to the external USB port on the luggage.

Note: A power bank is not supplied with the luggage and must be purchased separately.

OPERATING INSTRUCTIONS

1. Using the Spinner Wheels

Your Chatelet Air 2.0 luggage is equipped with dual-density, double-spinner wheels designed for smooth, multi-directional rolling. This allows you to push or pull your luggage with minimal effort, reducing strain on your arm and shoulder.

- For optimal maneuverability, keep the luggage upright and push it alongside you.
- The wheels are designed to glide over various surfaces, but exercise caution on uneven terrain.



Image: A detailed view of the luggage's dual-density double-spinner wheels, highlighting their robust construction for smooth movement.

2. SECURITECH® Zip System

The patented SECURITECH® zip is designed to be three times more resistant to intrusion than conventional zippers, enhancing the security of your belongings.

- Ensure the zipper pullers are fully engaged in the lock mechanism when securing your luggage.
- When closing, pull the zipper smoothly around the perimeter of the luggage.

3. Internal Organization

The Chatelet Air 2.0 features a deluxe, soft-touch interior with various compartments for efficient packing:

- **Main Compartments:** Use the adjustable compression straps to secure your clothing and prevent shifting during transit.
- **Mesh Zippered Pockets:** Ideal for smaller items, accessories, or toiletries.
- **Laundry and Shoe Bags:** Utilize the included bags to keep dirty laundry or shoes separate from clean items.
- **Crossbody Handbag:** The smallest piece in the set can be used as a clutch or a crossbody bag thanks to its removable, adjustable straps and multiple pockets.



Image: The interior of the luggage, showcasing the SILVADUR-coated lining for odor control, and the included laundry and shoe bags.



Image: The versatile crossbody handbag, part of the 3-piece set, featuring its design and strap.

4. Ergonomic Handles

The luggage features an ergonomical handle for easy maneuverability and soft-grip side and top carrying handles for comfortable lifting. Extend the telescopic handle to your preferred height for pushing or pulling.

MAINTENANCE

1. Cleaning the Exterior

The 100% polycarbonate shell is resilient. To clean:

- Wipe the surface with a soft cloth dampened with mild soap and water.
- Avoid abrasive cleaners or solvents, as these can damage the finish.
- For faux leather accents and corner protectors, use a damp cloth and dry immediately.



Image: A close-up of the luggage's corner protector, designed to absorb shock and enhance durability.

2. Interior Care (SILVADUR™ Technology)

The lining is coated with SILVADUR™ technology to provide effective odor control. To maintain its effectiveness:

- Spot clean the interior lining with a damp cloth and mild detergent if necessary.
- Allow the interior to air dry completely before closing the luggage or storing it.

3. Wheel and Zipper Maintenance

- Periodically check wheels for debris and clean as needed.
- If zippers become stiff, apply a small amount of zipper lubricant or wax to the teeth.

TROUBLESHOOTING

Problem	Possible Cause	Solution
TSA Lock will not open/close	Incorrect combination; reset button not fully engaged/disengaged.	Ensure the correct 3-digit combination is set. Re-follow the lock setting instructions carefully.
Zippers are stiff or difficult to move	New zippers may be stiff; dirt or debris in zipper teeth.	Operate zippers several times to loosen them. Clean zipper teeth with a small brush. Apply a small amount of zipper lubricant or wax.
Wheels are not rolling smoothly	Debris caught in wheels; worn wheels.	Inspect wheels for hair, lint, or other debris and remove. If wheels are worn, contact customer support for assistance.
USB port not charging device	Power bank not connected or discharged; faulty cable.	Ensure a charged power bank is correctly connected inside the luggage. Test with a different charging cable or power bank.

SPECIFICATIONS

- **Product Dimensions:** 20.75 x 12.75 x 30 inches (for the largest piece)
- **Item Weight:** 20 pounds (for the largest piece)
- **Capacity:** 154 Liters (total for the set, or for the largest piece if specified)
- **Material:** 100% Polycarbonate shell with faux leather accents
- **Wheels:** Dual Density, double-spinner wheels
- **Security:** Recessed 3-dial TSA accepted combination lock, Patented SECURITECH® zip
- **Interior:** SILVADUR™ technology coated lining, soft-touch interior, mesh zippered pockets, compression straps, laundry bag, shoe bag

- **Additional Features:** USB port on 20-inch carry-on (power bank not included), ergonomic handle, soft-grip carrying handles, shock-absorbing corner protectors
- **Model Number:** 40167696706

Dimensions Overview



Image: Dimensions for the Carry-On Spinner (approx. 22.75" H x 15" W x 10" D).



Image: Dimensions for the Large Checked Luggage (approx. 30" H x 20.75" W x 12.75" D).

WARRANTY AND SUPPORT

DELSEY PARIS products are known for their quality and durability. This Chatelet Air 2.0 luggage set typically comes with a 10-year global warranty, covering manufacturing defects. Please refer to the warranty card included with your purchase for specific terms and conditions.

For warranty claims, spare parts, or technical support, please visit the official DELSEY PARIS website or contact their customer service department. Keep your proof of purchase for any warranty-related inquiries.

You can find more information and contact details on the [DELSEY PARIS Store on Amazon](#).