

[Manuals.plus](#) /

› [Krüger&Matz](#) /

› Krüger&Matz GX-150 LED Gaming Chair User Manual

Krüger&Matz KM0790

Krüger&Matz GX-150 LED Gaming Chair User Manual

Model: KM0790-BLED

1. INTRODUCTION

Thank you for choosing the Krüger&Matz GX-150 LED Gaming Chair. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new gaming chair. Please read these instructions carefully before use and retain them for future reference.



Figure 1: Overview of the Krüger&Matz GX-150 LED Gaming Chair.

2. SAFETY INFORMATION

- Ensure all components are securely fastened before use.
- Do not stand on the chair or use it as a step stool.

- Keep children away from moving parts during assembly and adjustment.
- Do not exceed the maximum weight capacity of 150 kg (330 lbs).
- Avoid exposing the chair to direct sunlight or extreme temperatures.
- Disconnect the USB power for LED lighting and massage function when not in use or during cleaning.

3. PACKAGE CONTENTS

Please check the package to ensure all parts are present and undamaged. If any parts are missing or damaged, contact customer support.

- Backrest
- Seat Base with Armrests and Footrest
- Star Base
- Casters (5x)
- Gas Lift Cylinder with Cover
- Mechanism Plate
- Lumbar Cushion (with massage function)
- Headrest Cushion
- LED Remote Control
- Assembly Hardware (screws, washers, Allen key)

4. ASSEMBLY INSTRUCTIONS

Assembly of the Kruger&Matz GX-150 gaming chair is designed to be a do-it-yourself process. Follow these general steps:

1. **Attach Casters to Star Base:** Insert the five casters into the holes on the star base until they click securely into place.
2. **Install Gas Lift:** Place the gas lift cylinder into the center hole of the star base. Cover it with the telescopic plastic cover.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the screw holes on the underside of the seat base. Secure it with the provided screws, ensuring the front of the mechanism faces the front of the seat.
4. **Connect Seat to Gas Lift:** Carefully place the assembled seat onto the gas lift cylinder, ensuring it is centered and stable.
5. **Attach Backrest to Seat:** Align the backrest brackets with the corresponding holes on the seat base. Secure with screws.
6. **Install Cushions:** Attach the headrest and lumbar support cushions using their straps. The lumbar cushion has a USB cable for the massage function; connect it to a USB power source (e.g., power bank, computer USB port).
7. **Connect LED Lighting:** Locate the USB cable for the LED lighting on the chair. Connect it to a USB power source.




Figure 2: Illustration of the chair base and casters.

5. OPERATING INSTRUCTIONS

5.1. Height Adjustment

To adjust the seat height, pull the lever located on the right side of the seat upwards. To raise the seat, lift the lever while taking your weight off the chair. To lower the seat, lift the lever while seated.



Figure 3: Seat height adjustment lever.

5.2. Backrest Recline

To recline the backrest, pull the lever on the left side of the seat upwards. Lean back to your desired angle (up to 145°) and release the lever to lock it in place. To return to an upright position, pull the lever and lean forward.



Figure 4: Backrest recline mechanism.

5.3. Retractable Footrest

To extend the footrest, pull it out from underneath the seat. To retract it, push it back in until it is fully stored.



Figure 5: Chair with footrest in extended position.

5.4. LED Lighting Control

The chair features integrated LED lighting. Connect the LED USB cable to a power source. Use the provided RF wireless remote control to manage the lighting effects.

- **Power Button:** Turn LEDs On/Off.
- **MODE +/-:** Cycle through different lighting modes and patterns.
- **SPEED +/-:** Adjust the speed of dynamic lighting effects.
- **AUTO:** Activate automatic mode cycling through all effects.
- **Brightness/Color Buttons:** Adjust brightness or select static colors (R, G, B, W, Y, C, P).



Figure 6: RF Wireless Remote Control for LED lighting.

5.5. Massage Function

The lumbar cushion includes a massage function. Connect the lumbar cushion's USB cable to a power source (e.g., a power bank or computer USB port) to activate the massage feature.



Figure 7: Lumbar cushion with adjustable position and massage function.

6. MAINTENANCE

- **Cleaning:** Wipe the eco-leather surfaces with a soft, damp cloth. For stubborn stains, use a mild soap solution and dry immediately. Do not use harsh chemicals or abrasive cleaners.
- **Casters:** Periodically check and clean the casters to ensure smooth movement. Remove any hair or debris that may accumulate.
- **Fasteners:** Regularly check all screws and bolts to ensure they are tight. Retighten if necessary to maintain stability.
- **LED/Massage Cables:** Ensure USB cables are not pinched or damaged. Disconnect when not in use.

7. TROUBLESHOOTING

- **Chair does not adjust height:** Ensure the gas lift lever is fully engaged. Check if the gas lift cylinder is properly installed and not damaged.
- **Backrest does not recline:** Verify the recline lever is functioning correctly and not obstructed.
- **LED lights not working:** Ensure the USB cable for the LED lights is securely connected to a working power source. Check the remote control battery.
- **Massage function not working:** Confirm the lumbar cushion's USB cable is properly connected to a power source.
- **Chair is wobbly:** Check all assembly screws and bolts, and tighten them if loose. Ensure the star base and casters are securely attached.

8. SPECIFICATIONS

Feature	Specification
Model Number	KM0790-BLED
Material (Seat & Backrest)	Eco-leather
Base Material	PVC
Wheel Material	PU, Nylon
Backrest Recline Angle	Up to 145°
Adjustable Seat Height	42-52 cm
Backrest Width	54 cm
Backrest Height	81 cm
Seat Width	52 cm
Seat Depth	48 cm
Armrest Height	28 cm
Maximum User Weight	150 kg (330 lbs)
Net Weight	15 kg
Special Features	LED Lighting, Massage Function (lumbar cushion), Retractable Footrest



T



130cm

48cm

54cm



Figure 8: Product dimensions of the GX-150 LED Gaming Chair.

9. WARRANTY AND SUPPORT

The Kruger&Matz GX-150 LED Gaming Chair comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, replacement parts, or any inquiries, please contact your retailer or the official Kruger&Matz customer service.

You can find more information and support on the official Krüger&Matz website: www.krugermatz.com

© 2023 Krüger&Matz. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0CP5T8491>

More documents and user manuals: <https://manuals.plus/>