

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Pamapic](#) /

› [Pamapic 8-Piece Patio Dining Set Instruction Manual](#)

## Pamapic 8824

# Pamapic 8-Piece Patio Dining Set Instruction Manual

Model: 8824 | Brand: Pamapic

## INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Pamapic 8-Piece Patio Dining Set. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of the product.

## SAFETY INFORMATION

For your safety and to prevent damage to the product, please observe the following weight capacities:

- Chair weight capacity: **220 lbs**
- Dining table weight capacity: **66 lbs**
- Coffee table weight capacity: **44 lbs**

Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

## PACKAGE CONTENTS

Your Pamapic 8-Piece Patio Dining Set is delivered in two boxes. Please ensure all components are present before beginning assembly.

- **Box 1:** 6 x Stackable Aluminum Chairs
- **Box 2:** 1 x Dining Table, 1 x Coffee Table
- **Hardware:** All necessary screws, washers, and wrenches are included.



Enjoy comfortable Outdoor life




Figure 1: Overview of the Pamapic 8-Piece Patio Dining Set components and packaging.

## ASSEMBLY INSTRUCTIONS

Please assemble the items on a soft, non-abrasive surface such as carpeting to avoid damage. Refer to the video for visual guidance.

Video 1: Comprehensive assembly guide for the Pamapic Patio Dining Set.

### 1. Chair Assembly (Refer to Video 1: 0:09 - 1:28)

1. Attach the armrests (C1, C2) and backrest (C3) to the seat (C4) using the provided M6\*25 screws (a2) and Stell Washers (a3).
2. Ensure all connections are secure but do not fully tighten until all parts are aligned.
3. Once all components are in place, fully tighten all screws with the included wrench (a4).



Figure 2: Assembled chairs are stackable for convenient storage.

## 2. Dining Table Assembly (Refer to Video 1: 1:33 - 2:02)

1. Place the dining table top (A1) upside down on a soft surface.
2. Attach the four table legs (A2) to the corners of the table top using the M6\*20 screws (a1) and Stell Washers (a3).
3. Tighten all screws securely with the wrench (a4).
4. Carefully flip the table upright.



Figure 3: Dining table featuring a durable wood-plastic top.

### 3. Coffee Table Assembly (Refer to Video 1: 2:08 - 2:46)

1. Place the coffee table top (B1) upside down on a soft surface.
2. Attach the four coffee table legs (B2) to the underside of the table top using the M6\*20 screws (a1) and Stell Washers (a3).
3. Connect the frame (B3) to the legs, ensuring proper alignment.
4. Tighten all screws securely with the wrench (a4).
5. Carefully flip the coffee table upright.



Figure 4: The complete Pamapic 8-Piece Patio Dining Set.

## OPERATING INSTRUCTIONS

---

- **Chair Usage:** The chairs are designed for comfortable outdoor seating. Their lightweight aluminum construction allows for easy repositioning.
- **Space-Saving Storage:** When not in use, the chairs can be conveniently stacked to maximize your outdoor space. Refer to Figure 2 for visual reference.
- **Umbrella Hole:** The dining table includes a center hole (1.77 inches diameter) for an umbrella stand, allowing for shaded outdoor dining during warmer months.

## MAINTENANCE

---

To ensure the longevity and appearance of your Pamapic Patio Dining Set, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly.
- **Frame Care:** The aluminum frame is resistant to rust and weather. Regular cleaning will help maintain its finish.

- **Plastic-Wood Surfaces:** The plastic-wood table top and chair slats are designed for outdoor use and are easy to clean and maintain. Avoid harsh chemicals or abrasive cleaners that could damage the surface.
- **Storage:** During prolonged periods of non-use or harsh weather conditions, it is recommended to cover the furniture or store it in a sheltered area to protect it from the elements.

## TROUBLESHOOTING

If you encounter any issues during assembly or use, please refer to the following common solutions:

- **Missing or Damaged Parts:** If any parts are missing or damaged upon arrival, please contact Pamapic customer service immediately. Provide pictures of the damaged parts and the name or model number of your product.
- **Assembly Difficulties:** Ensure all screws are loosely fitted before tightening any completely. This allows for proper alignment of all components. Refer to the assembly video (Video 1) for step-by-step visual guidance.
- **Wobbly Furniture:** Check that all screws are fully tightened. Ensure the furniture is placed on a flat, even surface.

## SPECIFICATIONS

Feature	Detail
<b>Brand</b>	Pamapic
<b>Model Number</b>	8824
<b>Material</b>	Aluminum (Frame), Plastic-Wood (Table Top, Chair Slats)
<b>Color</b>	White (as per current variant)
<b>Item Dimensions (L x W x H)</b>	59 x 35 x 29 inches (Dining Table)
<b>Item Weight</b>	66 pounds (Dining Table)
<b>Chair Weight Capacity</b>	220 lbs
<b>Dining Table Weight Capacity</b>	66 lbs
<b>Coffee Table Weight Capacity</b>	44 lbs
<b>Special Feature</b>	Stackable Chairs, Umbrella Hole (1.77" diameter)
<b>Product Care Instructions</b>	Wipe with Damp Cloth

## WARRANTY AND SUPPORT

Pamapic is committed to customer satisfaction. If you have any problems with your product, please feel free to contact our customer service team. We are available to assist with returns or refunds as per our policy.

### Warranty Coverage Requirements:

- Pictures of the damaged parts.
- The name or model number of your product.
- Please gather all of this information BEFORE you contact us.

For further assistance, please visit the [Pamapic Store on Amazon](#).

