

[Manuals.plus](#) /

› [CROWN SHADES](#) /

› CROWN SHADES 12x12 Pop Up Canopy Tent (Model RM144) Instruction Manual

CROWN SHADES RM144

CROWN SHADES 12x12 Pop Up Canopy Tent (Model RM144) Instruction Manual

Easy Outdoor Sun Shade for Events, Parties, Camping

INTRODUCTION

Thank you for choosing the CROWN SHADES 12x12 Pop Up Canopy Tent. This manual provides essential information for the safe and efficient setup, operation, and maintenance of your canopy. Please read these instructions carefully before use and retain them for future reference.



Image: The CROWN SHADES 12x12 Pop Up Canopy Tent, fully assembled in a vibrant red color, providing shade outdoors.

SAFETY INFORMATION

For safe use, avoid prolonged exposure to UV rays, use in suitable weather conditions, and ensure the shelter is properly anchored in windy conditions. Do not use this canopy in extreme weather conditions such as heavy rain, strong winds, or snow. Always secure the canopy with stakes and guy ropes provided.

PACKING LIST

Before assembly, verify that all components are present:

PACKING LIST



1x Steel Frame




1x Cover Bag



4x Guy Ropes



4 x Empty Sandbags



1x Repair Patch



8 x Spikes+
1 x Hexagon Spanner



1x Canopy Top

Image: A visual representation of the packing list, including the steel frame, cover bag, canopy top, guy ropes, empty sandbags, repair patch, spikes, and hexagon spanner.

- 1x Steel Frame
- 1x Cover Bag
- 1x Canopy Top
- 4x Guy Ropes
- 4x Empty Sandbags (for weighting down)
- 1x Repair Patch
- 8x Spikes + 1x Hexagon Spanner

SETUP INSTRUCTIONS

The CROWN SHADES canopy features a patented CenterLok system for quick and easy setup. It is recommended that two people set up the canopy, though one person can manage.

Step-by-Step Assembly:

1. **Expand the Frame:** Place the folded frame in the desired location. With a partner, grasp two opposing outer legs and slowly pull the frame outwards until it is partially open.



Image: A three-step visual guide showing the canopy frame being opened, the top fabric being attached and the center button pressed, and finally the legs being adjusted for height.

2. **Attach the Canopy Top:** Drape the canopy fabric over the partially opened frame. Secure the corners of the fabric to the frame.
3. **Engage CenterLok:** From underneath the canopy, push up on the patented CenterLok hub located at the center of the frame until it clicks into place. This locks the truss system and fully extends the canopy top.



CENTERLOK®

1 Person assembly in 1 minute or less!



STO'N GO

Make transportaion a breeze !

Image: A close-up view of the CenterLok mechanism, highlighting its design for single-person assembly in under a minute.

4. **Adjust Leg Height:** Press the red push-button on each leg and extend the legs to your desired height. There are three adjustable height levels. Ensure all legs are set to the same height for stability.





Image: Demonstrates the adjustable legs for stability on any terrain without tools, and the fast clip for secure attachment.

5. **Secure the Canopy:** Use the provided stakes to anchor the canopy legs to the ground. For added stability, especially in breezy conditions, attach the guy ropes to the canopy corners and stake them into the ground. Fill the sandbags with sand and place them around the base of the legs for additional weight.

Setup Video Guide:


Your browser does not support the video tag.

Video: A detailed instructional video demonstrating the setup process for the Crown Shades 12'x12' Recreational Canopy. This video covers expanding the frame, attaching the canopy top, engaging the CenterLok, and adjusting the leg height.

OPERATING YOUR CANOPY

Sun and Weather Protection:


The canopy top is made from rugged 150D silver-coated fabric, offering UPF 50+ UV protection and water repellency. It is also CPAI-84 rated for flame resistance. The vented top design ensures airflow and temperature control, reducing heat buildup underneath the canopy.



STO'N GO

Our STO'N GO System makes collapsing, storing, and transporting simple.

Image: Illustrates the silver-coated fabric, highlighting its water-resistant and UPF 50+ UV protection properties.



VENTED TOP

Ensures Airflow And Temperature Control.




Image: A view of the canopy's vented top, designed to ensure optimal airflow and temperature regulation underneath.

Portability:

The included STO-N-Go cover bag is designed for convenient transport and storage. It features wheels for easy mobility and a specialized pocket for stakes and guy ropes.

OUR PRODUCT SIZE



Image: A woman easily transporting the canopy in its wheeled storage bag, with product dimensions (12x12 feet, 3-level height adjustment) overlaid.

MAINTENANCE

- **Cleaning:** Clean the canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners, as this may damage the fabric's protective coating. Allow the fabric to dry completely before storing to prevent mildew.
- **Frame Care:** Inspect the steel frame periodically for any signs of corrosion or damage. Clean any dirt or debris from the frame.
- **Storage:** Always store the canopy in its cover bag in a dry, cool place when not in use. Ensure the canopy is completely dry before packing to prevent mold and mildew.
- **Repair Patch:** Use the provided repair patch for minor tears in the canopy fabric. Follow the instructions included with the patch for proper application.

TROUBLESHOOTING

- **Difficulty Opening/Closing:** Ensure all locking mechanisms are disengaged before attempting to close the canopy. If the frame is stiff, gently wiggle the joints while applying pressure. Do not force the frame.
- **Water Pooling on Top:** The canopy is designed with a higher roof for better water runoff. However, in heavy rain, water may still accumulate. The fast clips help prevent water pooling. Ensure the canopy is taut and properly angled to facilitate drainage.
- **Canopy Instability:** Always use the provided stakes and guy ropes to secure the canopy. In windy conditions, consider lowering the canopy height and adding sandbags to the legs for increased stability. Never leave the canopy unattended in strong winds.

SPECIFICATIONS

Brand	CROWN SHADES
Model Number	RM144
Material	Metal (Frame), 150D Silver-Coated Fabric (Canopy)
Color	Red
Item Weight	53 pounds
Dimensions (L x W x H)	144"L x 144"W x 112"H (12ft x 12ft x 9.3ft)
Floor Area	144 square feet
UV Protection	UPF 50+
Water Resistance Level	Water Resistant
Frame Type	Truss (Alloy Steel)

WARRANTY AND SUPPORT

This CROWN SHADES canopy tent is backed by a **2-Year Parts Replacement Warranty** covering manufacturer defects. If any part of your product is not functioning as it should, please contact our support team for assistance. They will provide replacement parts and clear instructions for repair.

For customer support, please contact Crown Shade-2, the seller, through your purchase platform or visit the official CROWN SHADES website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question