

Blow Tab 11

Blow Platinum Tab 11 Tablet User Manual

Model: Tab 11 (S9140056)

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Blow Platinum Tab 11 tablet. Please read this manual thoroughly before operating the device and retain it for future reference. This tablet features a 10.5-inch display, Unisoc Tiger T618 processor, 8GB RAM, 128GB internal storage, and runs on Android 13.

PRODUCT OVERVIEW

Familiarize yourself with the components and features of your Blow Platinum Tab 11 tablet.



Figure 1: Blow Platinum Tab 11 Tablet with an attached keyboard case. The screen displays key features such as 10.5-inch screen, Android 13, 4G LTE, 8GB RAM, 128GB storage, and a 7000mAh battery.

Key Features:

- **Display:** 10.5-inch HD IPS screen
- **Processor:** Unisoc Tiger T618 Octa-core
- **Memory:** 8GB RAM
- **Storage:** 128GB Internal
- **Operating System:** Android 13
- **Connectivity:** 4G LTE, Wi-Fi 5 GHz (802.11ac), Bluetooth 5.0, GPS (A-GPS, Glonass, BeiDou)
- **Battery:** 7000 mAh
- **Cameras:** Front camera included
- **Audio:** Stereo speakers
- **Ports:** USB 2.0

SETUP

1. Initial Charging

Before first use, fully charge the tablet. Connect the provided charger to the tablet's USB port and plug it into a power outlet. The battery indicator on the screen will show charging status. A full charge typically takes several hours.

2. Powering On/Off

- **To Power On:** Press and hold the Power button (usually located on the side or top edge) until the screen lights up and the Blow logo appears.
- **To Power Off:** Press and hold the Power button until a power menu appears on the screen. Select "Power

off" and confirm.

- **To Restart:** From the power menu, select "Restart" and confirm.

3. Initial Configuration

Upon first power-on, the tablet will guide you through the initial setup process. This includes:

1. **Language Selection:** Choose your preferred language.
2. **Wi-Fi Connection:** Connect to a Wi-Fi network to access the internet. This is necessary for software updates and app downloads.
3. **Google Account Setup:** Sign in with your Google account or create a new one. This is required for accessing the Google Play Store and other Google services.
4. **Date and Time:** Set the correct date and time, or allow the tablet to set it automatically via the network.
5. **Security:** Set up a screen lock (PIN, pattern, password, or face unlock if available) to protect your device.

OPERATING INSTRUCTIONS

1. Basic Navigation

- **Touch Gestures:** Use tap, double-tap, swipe, pinch-to-zoom, and long-press for various interactions.
- **Home Screen:** The main screen where you can access apps and widgets.
- **Notification Panel:** Swipe down from the top of the screen to access notifications and quick settings.
- **App Drawer:** Swipe up from the bottom of the screen to view all installed applications.

2. Connectivity

- **Wi-Fi:** Go to **Settings > Network & internet > Wi-Fi** to connect to available networks.
- **Bluetooth:** Go to **Settings > Connected devices > Bluetooth** to pair with Bluetooth accessories like headphones or speakers.
- **Mobile Data (4G LTE):** If your tablet supports a SIM card, insert it into the designated slot. Go to **Settings > Network & internet > Mobile network** to configure mobile data settings.
- **GPS:** Location services can be enabled or disabled via **Settings > Location**.

3. Camera Usage

To use the camera, open the Camera application. You can switch between front and rear cameras (if applicable), take photos, and record videos. Tap the screen to focus and press the shutter button to capture.

4. Audio Playback

The tablet features stereo speakers. You can adjust the volume using the volume buttons on the side of the device or through the quick settings panel. Connect headphones via Bluetooth for private listening.

MAINTENANCE

1. Cleaning the Device

- Use a soft, lint-free cloth to clean the screen and body of the tablet.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner specifically designed for electronics.
- Avoid using harsh chemicals, abrasive materials, or excessive moisture.

2. Software Updates

Regularly check for and install software updates to ensure optimal performance, security, and access to new features. Go to **Settings > System > System update** to check for available updates.

3. Battery Care

- Avoid extreme temperatures, as they can degrade battery life.
- Do not leave the tablet fully charged or fully discharged for extended periods.
- Use only the original or certified compatible chargers.

TROUBLESHOOTING

This section addresses common issues you might encounter with your tablet.

Problem	Solution
Tablet does not power on.	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, perform a forced restart by holding the power button for 10-15 seconds.
Wi-Fi connection issues.	Check if Wi-Fi is enabled in settings. Restart your Wi-Fi router. Forget the network and reconnect. Ensure you are within range of the Wi-Fi signal.
Apps are crashing or freezing.	Close and reopen the app. Clear the app's cache (Settings > Apps > [App Name] > Storage & cache > Clear cache). Restart the tablet. Ensure the app and tablet software are up to date.
Battery drains quickly.	Reduce screen brightness. Close unused apps running in the background. Disable Wi-Fi, Bluetooth, or GPS when not in use. Check battery usage in settings to identify power-hungry apps.
Tablet is slow or unresponsive.	Close unnecessary apps. Clear cache and temporary files. Restart the tablet. If the issue persists, consider a factory reset (back up your data first).

SPECIFICATIONS

Detailed technical specifications for the Blow Platinum Tab 11 tablet.

Feature	Detail
Brand	Blow
Model Name	Tab 11
Model Number	S9140056
Operating System	Android 13
Processor	Unisoc Tiger T618 Octa-core
RAM	8 GB
Internal Storage	128 GB

Feature	Detail
Display Size	10.5 inches
Display Resolution	1280 x 720 pixels (HD IPS)
Connectivity	4G LTE, Wi-Fi 5 GHz (802.11ac), Bluetooth 5.0, GPS (A-GPS, Glonass, BeiDou)
Ports	USB 2.0
Battery Capacity	7000 mAh
Estimated Battery Life	Up to 8 hours
Dimensions (L x W x H)	24.6 x 7.3 x 16.1 cm
Special Features	Front Camera, Stereo Speakers

PlatinumTAB11

MULTIMEDIA TABLET

4G

NOWY MEGAMOCNY TABLET



PAMIĘĆ
WBUDOWANA
128 GB



PAMIĘĆ
RAM
8 GB



WYDAJNA
BATERIA
7000 mAh



WYŚWIETLACZ
FHD IPS
10.5"



WYDAJNY
PROCESOR
8-RDZENI








Figure 2: Marketing graphic for the Platinum Tab 11, visually confirming key specifications such as 128GB built-in memory, 8GB RAM, 7000mAh battery, 10.5-inch IPS display, and 8-core processor.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official Blow website. Keep your proof of purchase for warranty claims.

Related Documents - Tab 11

 <p>INSTRUKCJA OBSŁUGI / USER MANUAL PlatinumTAB10 4G V2 79-0458</p> <p>BLOW</p>	<p>BLOW PlatinumTAB10 4G V2 User Manual and Specifications</p> <p>Comprehensive user manual for the BLOW PlatinumTAB10 4G V2 tablet, covering setup, features, settings, connectivity, app management, multimedia, and technical specifications.</p>
 <p>INSTRUKCJA V380 Pro</p> <p>BLOW</p>	<p>BLOW V380 Pro Camera Instruction Manual</p> <p>Comprehensive instruction manual for the BLOW V380 Pro camera, covering app download, account registration, camera setup (Wi-Fi, 4G, AP Hotspot, WiFi Station), live view, advanced features, and troubleshooting.</p>
 <p>INSTRUKCJA OBSŁUGI / USER MANUAL PL / EN</p> <p>78-426#</p>	<p>BLOW Carplay 5.0 Video Recorder User Manual</p> <p>Comprehensive user manual for the BLOW Carplay 5.0 Video Recorder (Model 78-426#), detailing setup, features like Carplay, Android Auto, Bluetooth, recording, and settings.</p>
	<p>BLOW CityLIGHT Active Loudspeaker Bluetooth with Microphone User Manual</p> <p>User manual for the BLOW CityLIGHT active loudspeaker, detailing its features, controls, Bluetooth connectivity, TWS function, and specifications. Includes safety information and connection guides.</p>
<p>Instrukcja obsługi pilota BLOW do TV LG</p> 	<p>BLOW Remote Control User Manual for LG TVs</p> <p>Comprehensive user manual for the BLOW remote control designed for LG televisions, covering operation, button functions, and pairing instructions.</p>

BLOW

Lokalizator Bluetooth iTag
Bluetooth locator iTag



Instrukcja obsługi / User manual

[BLOW iTag Bluetooth Locator User Manual and Features](#)

Comprehensive user manual for the BLOW iTag Bluetooth locator. Learn how to set up, use features like anti-lost, location tracking, photography, and battery replacement. Includes warranty and compliance information.