

[manuals.plus](#) /› [pTron](#) /› [pTron Bassbuds Eon TWS Earbuds User Manual](#)

pTron Bassbuds Eon

pTron Bassbuds Eon TWS Earbuds User Manual

Model: Bassbuds Eon

1. INTRODUCTION

Thank you for choosing the pTron Bassbuds Eon True Wireless Stereo (TWS) Earbuds. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new earbuds. Please read it carefully before use to ensure optimal performance and longevity of your device.

2. PACKAGE CONTENTS

- pTron Bassbuds Eon TWS Earbuds (Left & Right)
- Charging Case
- USB Type-C Charging Cable
- Eartips (various sizes)
- User Manual



Image: The pTron Bassbuds Eon earbuds resting in their open charging case, illustrating the complete package contents.

3. PRODUCT OVERVIEW

Earbud Components

- **Touch Control Area:** For managing music playback, calls, and voice assistant.
- **Microphone:** Built-in HD mic for calls, enhanced by AI-ENC technology.
- **Speaker:** 13mm dynamic drivers for audio output.
- **Charging Contacts:** Located at the bottom of each earbud.

Charging Case Components

- **Charging Port:** USB Type-C port for charging the case.
- **LED Indicator:** Displays charging status and battery level.
- **Earbud Slots:** Securely holds and charges the earbuds.



Image: The pTron Bassbuds Eon earbuds are shown outside their charging case, highlighting their design and individual components.

4. SETUP

4.1 Charging the Earbuds and Case

- 1. Initial Charge:** Before first use, fully charge the earbuds and charging case.
- 2. Charging the Case:** Connect the provided USB Type-C cable to the charging port on the case and a power source (e.g., wall adapter, computer USB port). The LED indicator will show charging progress.
- 3. Charging the Earbuds:** Place the earbuds into their respective slots in the charging case. Ensure the charging contacts align. The earbuds will automatically begin charging.

A full charge for the earbuds takes approximately 1 hour, and the case also takes about 1 hour. The case provides up to 30 hours of total playback time.



Image: The pTron Bassbuds Eon earbuds and charging case are depicted with icons indicating Type-C fast charging, 1-hour charge time, and DC5V-1A charge input.

4.2 Pairing with a Device

- Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode.
- Activate Bluetooth:** On your smartphone or other Bluetooth-enabled device, go to the Bluetooth settings and turn on Bluetooth.
- Select Device:** Look for "pTron Bassbuds Eon" in the list of available devices and select it to connect.
- Confirmation:** Once connected, you will hear an audio prompt, and the earbuds' LED indicators will change (e.g., turn off or flash slowly).

The earbuds support Bluetooth v5.3 for a stable and fast connection with a wireless range of up to 10 meters. They also feature 1-step pairing for convenience.

Bluetooth V5.3 Wireless

Superfast & Stable Wireless Connectivity



1-Step
Pairing

10M
Wireless Range

Stereo/Mono
Bud Capability

Wide
Compatibility

Image: The pTron Bassbuds Eon earbuds and charging case are shown with a Bluetooth icon, emphasizing Bluetooth V5.3 wireless connectivity, 1-step pairing, 10m wireless range, stereo/mono bud capability, and wide compatibility.

5. OPERATING INSTRUCTIONS

5.1 Touch Controls

The pTron Bassbuds Eon feature intuitive touch controls on each earbud. The functions are as follows:

Action	Function
Single Tap (Left/Right)	Play/Pause Music, Answer/End Call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (Right)	Volume Up
Triple Tap (Left)	Volume Down
Long Press (2 seconds)	Reject Call, Activate Voice Assistant



Image: The pTron Bassbuds Eon earbuds are shown with various feature callouts, including 'Touch Control Buds', 'Voice Assist', 'Passive Noise Cancellation', 'IPX4 Water Resistant', 'Round Edges Case', and 'Stereo Calls'.

5.2 Making Calls

The earbuds feature built-in HD microphones and AI-ENC (Environmental Noise Cancellation) technology for clear call quality.

- **Answering/Ending Calls:** Single tap either earbud.
- **Rejecting Calls:** Long press either earbud for 2 seconds.



Image: The pTron Bassbuds Eon earbuds are displayed with a graphic illustrating 'ENC Technology Enhances Your Voice on the Call' and 'TruTalk Technology', showing noise reduction and voice clarity.

5.3 Voice Assistant

Long press either earbud for 2 seconds to activate your device's voice assistant (e.g., Google Assistant, Siri).

6. MAINTENANCE

6.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove eartips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Ensure charging contacts on both earbuds and case are clean and free of debris to maintain proper charging.

6.2 Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged.

6.3 Water Resistance

The earbuds are IPX4 water-resistant, meaning they can withstand splashes of water and sweat. They are not designed for submersion in water. Avoid exposing them to heavy rain or showering.

7. TROUBLESHOOTING

- Earbuds not pairing:** Ensure both earbuds are charged. Place them back in the case, close it, then open it again to re-enter pairing mode. Check your device's Bluetooth settings and try reconnecting.
- Only one earbud working:** Place both earbuds back in the charging case, close the lid, wait a few seconds, then open it again. This often re-syncs them. If the issue persists, try resetting the earbuds (refer to manufacturer's website for specific reset instructions if not in manual).
- No sound:** Check the volume level on both your device and the earbuds. Ensure the earbuds are properly connected to your device.
- Charging issues:** Ensure the charging cable is securely connected and the power source is active. Clean the charging contacts on both the earbuds and the case.
- Poor call quality:** Ensure the microphone is not obstructed. Move closer to your connected device to avoid signal interference.

8. SPECIFICATIONS

Feature	Specification
Model Name	Bassbuds Eon
Connectivity Technology	Wireless (Bluetooth v5.3)
Bluetooth Range	10 Meters
Audio Driver Size	13 Millimetres
Frequency Range	20Hz-20kHz
Impedance	32 Ohm
Earbud Battery	30mAh
Case Battery	300mAh
Battery Life (Total)	Up to 30 Hours with case
Charge Time (Earbuds/Case)	Approx. 1 Hour
Water Resistance Level	IPX4
Control Type	Touch
Item Weight	32 Grams
Product Dimensions	6 x 4.3 x 2.5 cm




9. WARRANTY AND SUPPORT

The pTron Bassbuds Eon comes with a **1-Year manufacturer warranty** from the date of purchase. For warranty claims, technical support, or any other inquiries, please contact our customer care team:

- **Phone:** 040-67138888
- **Email:** Support@ptron.in

Please retain your proof of purchase for warranty validation.

Related Documents - Bassbuds Eon


	<p>pTron Bassbuds B21 TWS Earbuds: Product Manual & User Guide</p> <p>Official product manual for the pTron Bassbuds B21 TWS Earbuds. This guide provides detailed instructions on pairing, smart power functions, charging, troubleshooting common issues, and safety precautions for your wireless earbuds.</p>
	<p>pTron Bassbuds Joy User Guide: True Wireless Stereo Earbuds Manual</p> <p>Comprehensive user guide for pTron Bassbuds Joy True Wireless Stereo Earbuds. Learn about pairing, controls, charging, troubleshooting, and safety precautions.</p>
	<p>pTron Bassbuds Duo True Wireless Stereo Earbuds User Manual</p> <p>Official user manual for pTron Bassbuds Duo True Wireless Stereo Earbuds, detailing setup, pairing, operation, charging, troubleshooting, and safety guidelines for optimal use.</p>
	<p>pTron Bassbuds Nyx TWS Earbuds - User Manual and Guide</p> <p>Comprehensive user manual for pTron Bassbuds Nyx True Wireless Stereo (TWS) earbuds. Learn about pairing, controls, charging, troubleshooting, and safety precautions.</p>
	<p>pTron Bassbuds Duo True Wireless Stereo Earbuds User Manual</p> <p>User manual for pTron Bassbuds Duo True Wireless Stereo Earbuds, detailing features, controls, pairing, charging, and troubleshooting for optimal use.</p>



[pTron Bassbuds Loop TWS Earbuds User Guide](#)

User guide for pTron Bassbuds Loop TWS Earbuds, covering pairing, functions, charging, troubleshooting, and safety precautions. Learn how to connect, control music, and use voice assistants with your wireless earbuds.

Documents - pTron – Bassbuds Eon



[\[pdf\] User Manual](#)

arvind verma User Manual pTron Bassbuds Eon Truly Wireless in Ear Earbuds with Mic ENC 13mm Driver Immersive Sound BT 5.3 Quick Pairing Touch Control Fast Charging Upto 30Hrs Playtime IPX4 Voice Asst Grey Black Amazon Electronics 71bzmHc1SIL m media amazon images | |||

Bassbuds Eon - Product Manual Important: pTron **Bassbuds Eon** is set at 50% default volume, and the earbuds does not support volume adjustment. Please control the volume through the connected phone.

Smart Power On & Pairing
1. Open the charging case and take out both the earbuds together. Earbuds will power on automatically. 2. Wait for 2-3 seconds and L & R earbuds pair with each other.

Smart Power Off
Touch TSA on both earbuds for 5 seconds. Or Keep both the earbuds into the charging case and close the charging case.

Note: TSA stands for Touch Sensitive Area.

Connectivity Bluetooth - Automatic They will automatically connect to the last connected device (instant wake & pair technology).

Note: The last connected device must be in 10 meters wireless range and Bluetooth function must be On.

Calling or Music through Mono & Dual Buds

Mono Buds Use - Just place the right or left earbud back into the charging case and close the charging case cap. Note: TSA stands for Touch Sensitive Area.

Voice Assistant Activation

Touch TSA on either earbud for 2-3 seconds, you will hear a 'didi' sound which indicates that the phone's voice assistant is awake.

Call & Music Functions

Answer/Hangup a Phone Call - Touch TSA on either earbud once.


Reject a Phone Call - Long Touch TSA on either earbud once.

Music Play/Pause - Touch TSA on either earbud once.

Next Song - Touch TSA once on Right earbud.

Previous Song - Touch TSA once on Left earbud.

Note: TSA stands for Touch Sensitive Area.



[\[pdf\] User Manual](#)

arvind verma HERE Bassbuds Eon pTron India IM 19 08 2022 v 1660907646 cdn shopify s files 1 0040 4396 4531 |||

Bassbuds Eon - Product Manual Important: pTron **Bassbuds Eon** is set at 50% default volume, and the earbuds does not support volume adjustment. Please control the volume through the connected phone.

Smart Power On & Pairing
1. Open the charging case and take out both the earbuds together. Earbuds will power on automatically. 2. Wait for 2-3 seconds and L & R earbuds pair with each other.

Smart Power Off
Touch TSA on both the earbuds for 5 seconds. Or Keep both the earbuds into the charging case and close the charging case.

Note: TSA stands for Touch Sensitive Area.

Connectivity Bluetooth - Automatic

Just Turn On the Bluetooth earbuds. They will automatically connect to the last connected device (instant wake & pair technology).

Note: The last connected device must be in 10 meters wireless range and Bluetooth function must be On.

Calling or Music through Mono & Dual Buds

Mono Buds Use - Just place the right or left earbud back into the charging case and close the charging case cap.

Dual Buds Use - Use left & right earbuds together.

Voice Assistant Activation

Touch TSA on either earbud for 2-3 seconds, you will hear a 'didi' sound which indicates that the phone's voice assistant is awake.

Call & Music Functions

Answer/Hangup a Phone Call - Touch TSA on either earbud once.

Reject a Phone Call - Long Touch TSA on either earbud once.

Music Play/Pause - Touch TSA on either earbud once.

Next Song - Touch TSA once on Right earbud.

Previous Song - Touch TSA once on Left earbud.

Note: TSA stands for Touch Sensitive Area.