

Monster Jam 6068269

Monster Jam Grave Digger Trax

ALL-TERRAIN REMOTE CONTROL VEHICLE INSTRUCTION MANUAL

Model: 6068269 | Brand: Monster Jam

Introduction

The Monster Jam Grave Digger Trax is a 1:15 scale all-terrain remote control vehicle designed for diverse environments, including land and water. This manual provides essential information for the safe and optimal use of your vehicle, covering setup, operation, maintenance, and troubleshooting.

Package Contents

Ensure all items listed below are present in your package:

- 1 Grave Digger Trax RC Vehicle
- 1 Remote Control (requires 2 AAA batteries, not included)
- 1 USB Charging Cable (integrated into the vehicle)
- 1 Instruction Guide (this document)

Safety Information

Please read and understand all safety warnings before operating the vehicle. Failure to do so may result in injury or damage to the product.

- **Age Recommendation:** Suitable for ages 4 and up. Adult supervision is recommended.
- **Battery Safety:** Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Insert batteries with correct polarity. Remove batteries if the product is not used for an extended period.
- **Water Use:** The vehicle is designed to float and travel through water. However, it is not submersible. Avoid fully submerging the remote control.
- **Obstacles:** Operate in open areas free from people, pets, and obstacles.
- **Charging:** Only use the provided USB charging cable. Connect to a computer or other 5VDC rated power

source.

Setup

1. Remote Control Battery Installation

The remote control requires 2 AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Open the battery cover.
3. Insert 2 new AAA batteries, ensuring correct polarity (+/-).
4. Close the battery cover securely.

2. Vehicle Charging

The Grave Digger Trax vehicle has an integrated rechargeable battery.

1. Ensure the vehicle is turned OFF before charging.
2. Locate the charging cable compartment on the vehicle. Slide down the bottom panel to access the USB charging cable.
3. Plug the USB charging cable into a computer or a 5VDC wall adapter.
4. The vehicle's headlights will blink during charging and remain ON when fully charged.
5. Charging typically takes approximately 30 minutes for up to 20 minutes of play.

UP TO 20 MINUTES OF PLAY ON A SINGLE CHARGE



Image: The Grave Digger Trax vehicle highlighting its USB charging capability and 150-foot control range.

3. Pairing the Controller

Follow these steps to pair the remote control with the vehicle:

1. Turn the vehicle OFF.
2. Remove batteries from the remote control.
3. Push the throttle lever on the remote control up and down several times to drain any residual power.
4. Turn the vehicle ON.
5. Insert batteries back into the remote control.
6. Push the throttle lever up to its maximum position for approximately 3 seconds, then return it to the minimum position.
7. The vehicle's wheels should turn to the right and then return to confirm successful pairing.

Operation

Driving the Vehicle

Use the dual joystick controller to operate the Grave Digger Trax:

- **Forward/Reverse:** Use the left joystick to control forward and reverse movement.
- **Steering:** Use the right joystick to steer left or right.
- **Range:** The vehicle can be controlled from up to 70-150 feet away.

Conquering All Terrains

The Grave Digger Trax features all-terrain tank treads, allowing it to operate on various surfaces:

- **Land:** Drive on dirt, rocks, grass, and other outdoor surfaces.
- **Water:** The unique design allows the vehicle to float and travel through water. Avoid full submersion.
- **Snow/Mud:** The tank treads provide traction for movement through snow and mud.



PERFORM EPIC STUNTS

Image: The Grave Digger Trax demonstrating its ability to conquer various terrains including rocks, snow, grass, and dirt.



Image: The Grave Digger Trax showcasing its versatility across different outdoor environments.

Performing Stunts

The Grave Digger Trax can perform various stunts:

- **Wheelies:** To perform a wheelie, press the throttle toggle back, then quickly push it forward.
- **Donuts:** Practice steering sharply while accelerating to perform donuts.



FASTEST LAND & WATER MONSTER JAM RC

Image: The Grave Digger Trax executing a nose wheelie, donuts, and a tail wheelie.



Image: The Grave Digger Trax demonstrating its stunt capabilities.

Maintenance

- **Cleaning:** After outdoor use, especially in mud or water, gently clean the vehicle with a damp cloth. Do not

use harsh chemicals or immerse the vehicle in water for cleaning.

- **Storage:** Store the vehicle and remote control in a cool, dry place away from direct sunlight. Remove batteries from the remote control if storing for extended periods.
- **Charging Cable:** Ensure the integrated USB charging cable is properly stored in its compartment when not in use.

Troubleshooting

If you encounter issues with your Grave Digger Trax, refer to the following common solutions:

- **Vehicle Not Turning On:**
 - Charge the RC vehicle until the headlights stop blinking and remain ON.
 - Ensure the vehicle is turned OFF while charging.
- **Controller Not Turning On:**
 - Remove the batteries from the controller and reinsert them, or replace with new premium batteries.
 - Ensure batteries are inserted with the correct orientation.
- **Trouble Pairing Controller:**
 - Turn the vehicle off and remove batteries from the controller.
 - Push the throttle up and down to drain any remaining power after batteries are removed.
 - Turn on the truck.
 - Insert batteries into the controller.
 - Push the throttle lever up to the maximum position for approximately 3 seconds and back to the minimum position to complete the connection.
 - The wheels should turn to the right and return back to confirm pairing is successful.

Specifications

Product Dimensions	9.5 x 8 x 14.5 inches
Item Weight	3.09 pounds
Item Model Number	6068269
Manufacturer Recommended Age	4 - 14 years
Manufacturer	Spin Master
Battery Life (Vehicle)	Up to 20 minutes on a single charge
Control Range	Up to 150 feet

Warranty and Support

This product is covered by the Spin Master Care Commitment. For detailed warranty information, product support, or to contact customer service, please refer to the official Spin Master website or the contact information provided on the product packaging. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why is my Monster Jam Grave Digger Trax showing 4V but not staying turned on, stopping immediately after trying to move?

Based on the manual for the Monster Jam Grave Digger Trax (Model 6068269), the behavior you are describing—where the vehicle turns on but shuts down as soon as it tries to move—is typically a...

[Read full answer](#)