

[Manuals.plus](#) /

› [Aigostar](#) /

› Aigostar Robert - Quiet Tower Fan Instruction Manual

Aigostar B30101I3A

Aigostar Robert - Quiet Tower Fan Instruction Manual

Model: B30101I3A

1. INTRODUCTION

Thank you for choosing the Aigostar Robert Tower Fan. This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your new fan. Please read this manual thoroughly before use and retain it for future reference.






Image: The Aigostar Robert Tower Fan in white, accompanied by its remote control, showcasing its sleek design.

2. SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Ensure the power supply matches the voltage specified on the fan's rating label.
- Do not operate the fan with a damaged cord or plug.
- Keep fingers, pencils, or any other objects out of the fan grille when it is operating.
- Unplug the fan from the outlet when not in use, when moving it from one location to another, and before cleaning.
- Do not use the fan in wet or damp locations such as bathrooms.
- Place the fan on a stable, level surface to prevent tipping.

Stabiler Standfuß und Schutzgitter erhöhen die Sicherheit



Image: Illustration highlighting the stable base and protective grille of the tower fan, emphasizing safety features.

3. PACKAGE CONTENTS

Upon unpacking, please ensure all items listed below are present and undamaged:

- Aigostar Robert Tower Fan Unit
- Remote Control
- Power Cord (integrated)
- Instruction Manual (this document)

4. PRODUCT OVERVIEW

The Aigostar Robert Tower Fan is designed for efficient air circulation with a compact and modern aesthetic. It features a quiet motor, multiple modes and speeds, a timer function, and remote control operation.

Key Features:

- **Super Quiet Operation:** Equipped with a long-life motor for minimal noise, ideal for bedrooms.
- **Remote Control:** Conveniently operate the fan from a distance.
- **Adjustable Modes & Speeds:** 3 modes (Natural, Normal, Sleep) and 3 speeds (low, medium, high).
- **7-Hour Timer:** Set the fan to automatically turn off after a specified duration.
- **LED Display:** Indicates current settings (speed, mode, timer). Adjustable LED brightness.
- **70° Oscillation:** Wide-angle oscillation for broad air distribution.
- **Portable Design:** Lightweight (2.8 kg) with a practical handle for easy relocation.

Tragbar

Sie können es leicht bewegen

 **2.8kg**



Image: A person demonstrating the ease of moving the Aigostar Tower Fan, highlighting its lightweight and portable design (2.8 kg).

5. SETUP

The Aigostar Robert Tower Fan requires minimal assembly. Follow these steps to set up your fan:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Base Assembly:** The fan comes with a pre-assembled base. Ensure it is securely attached and stable. If the base needs to be attached, align the base halves and snap them together, then secure to the bottom of the fan unit with the provided screws (if any).
3. **Placement:** Place the fan on a firm, level surface, away from obstacles that might impede airflow. Ensure it is at least 20 cm away from walls or furniture.
4. **Power Connection:** Plug the power cord into a standard electrical outlet.



Image: A four-step visual guide demonstrating the simple assembly process of the fan's base, including securing the buckles.

6. OPERATING INSTRUCTIONS

Your Aigostar Robert Tower Fan can be operated using the touch buttons on the top panel or the included remote control.

Control Panel & Remote Control:

LED-Anzeigelicht und Fernbedienung



Ein-/Ausschalter



OSC-Funktion

Moduseinstellung



Geschwindigkeitseinstellung



Timer



Image: Close-up view of the fan's top control panel with touch buttons and the remote control, showing various function icons.

Fernbedienung und 7-Stunden-Timer

Ein-/Ausschalter

Moduseinstellung



Geschwindigkeitseinstellung



Timer



OSC-Funktion



Image: An annotated diagram illustrating the functions of the remote control and the fan's top panel, including power, oscillation, mode, speed, and timer settings.

Functions:

- **Power On/Off:** Press the power button () to turn the fan on or off.
- **Mode Selection:** Press the "Mode" button (M) to cycle through the three modes:
 - **Normal Mode:** Provides a constant airflow at the selected speed.
 - **Natural Mode:** Simulates a natural breeze by varying fan speed.
 - **Sleep Mode:** Operates at a very low, quiet speed with reduced LED brightness for undisturbed sleep.
- **Speed Adjustment:** Press the "Speed" button (≡) to select between Low, Medium, and High speeds.
- **Oscillation:** Press the "OSC" button (↺↻) to activate or deactivate the 70° oscillation feature, which distributes air across a wider area.



Image: The tower fan demonstrating its 70-degree oscillation, showing air flow reaching different parts of a room.

- **Timer Setting:** Press the "Timer" button (⌚) to set the fan to automatically turn off after 1, 2, 4, or 7 hours. The LED display will show the selected timer duration.

- **LED Light Control:** The LED display shows the current settings. You can adjust its brightness (100%, 50%, or off) by pressing the LED button on the remote control. This is particularly useful for sleep mode.



Image: The tower fan operating quietly in a bedroom at night, with a sleeping couple, highlighting its low noise level ($\leq 58\text{dB}$) and 7-hour timer function for undisturbed sleep.

7. MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Aigostar Robert Tower Fan.

- **Cleaning:**

- Always unplug the fan before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- Use a vacuum cleaner with a brush attachment to remove dust from the air intake and outlet grilles.
- Do not immerse the fan in water or allow water to drip into the motor housing.

- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging.

8. TROUBLESHOOTING

If you encounter any issues with your Aigostar Robert Tower Fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply; power cord not plugged in; power outlet faulty.	Ensure the fan is properly plugged into a working outlet. Check the circuit breaker.
Weak airflow.	Air intake/outlet blocked; fan speed set too low.	Clear any obstructions from the grilles. Increase the fan speed setting.
Fan makes unusual noise.	Fan not on a level surface; foreign object inside.	Place the fan on a flat, stable surface. Unplug and carefully check for any foreign objects.
Remote control not working.	Batteries depleted; remote not pointed at receiver; obstruction.	Replace remote control batteries. Ensure direct line of sight to the fan's receiver.

If the problem persists after trying these solutions, please contact Aigostar customer support.

9. SPECIFICATIONS

Feature	Detail
Model Number	B30101I3A
Brand	Aigostar
Power Supply	220-240V~, 50Hz
Rated Power	50 Watts
Noise Level	≤58 dB
Oscillation Angle	70°
Timer	Up to 7 hours
Dimensions (approx.)	91.2 x 18 x 18 cm (Packaging)
Weight	2.8 Kilograms

10. WARRANTY AND SUPPORT

Aigostar products are manufactured to the highest quality standards. This product is covered by a manufacturer's warranty against defects in materials and workmanship from the date of purchase. Please refer to the warranty card included with your product for specific terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact Aigostar customer service through their official website or the contact information provided in your product packaging. When contacting support, please have your model number (B30101I3A) and proof of purchase ready.

You can visit the Aigostar store for more information:[Aigostar Store](#)

© 2024 Aigostar. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CP7N55G5>

More documents and user manuals: <https://manuals.plus/>