

Xmenha D20

Xmenha D20 Wireless Bluetooth 5.3 Sport Neck Headphones User Manual

Model: D20

1. INTRODUCTION

Thank you for choosing the Xmenha D20 Wireless Bluetooth 5.3 Sport Neck Headphones. This manual provides essential information for the safe and effective use of your new headphones. Please read it thoroughly before use and retain it for future reference.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following precautions:

- Do not expose the headphones to extreme temperatures, humidity, or corrosive environments.
- Avoid dropping or subjecting the headphones to strong impacts.
- Do not attempt to disassemble or modify the headphones. This will void the warranty.
- Keep the headphones away from children and pets.
- Use only the provided charging cable or a certified equivalent.
- Prolonged listening at high volume levels may cause hearing damage. Adjust volume to a safe level.

3. PRODUCT OVERVIEW

3.1 Package Contents

- Xmenha D20 Wireless Bluetooth Headphones x 1
- USB Charging Cable x 1
- User Manual x 1

3.2 Headphone Components

Familiarize yourself with the various parts of your headphones:

Born for Sports

Ear hooks

Secure to your ear

Fumble-FREE Control

Volume up/down, play, pause

Earbuds

Soft rubbery Quality

Ear tips

S/M/L sizes of ear tips



Image 1: Headphone Components. This image illustrates the key components of the Xmenha D20 headphones, including the ear hooks for secure fit, the earbuds, replaceable ear tips (S, M, L sizes), and the integrated control buttons for volume and playback.



Image 2: Flexible Design. This image highlights the soft and flexible nature of the neckband, designed for comfortable wear and easy storage.

4. SETUP

4.1 Charging the Headphones

Before first use, fully charge the headphones.

1. Connect the USB charging cable to the charging port on the headphones.
2. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The indicator light will show charging status (e.g., red for charging, blue for fully charged).
4. A full charge typically takes approximately 2 hours.

Strong Battery and Endurance

With lithium polymer battery and optimized circuit design, provide you better use experience.

Listen **10** hours at a time



Double protection board

Protected from overcharge
short circuit
losing power
.....

Image 3: Battery and Endurance. This graphic illustrates the battery performance, indicating approximately 2 hours for a full charge, 10 hours of music/talk time, and up to 300 hours of standby time.

4.2 Bluetooth Pairing

To connect your headphones to a device:

1. Ensure the headphones are charged and turned off.
2. Press and hold the multi-function button (usually the power button) until the indicator light flashes red and blue alternately, indicating pairing mode.
3. Enable Bluetooth on your device (smartphone, tablet, computer).
4. Search for available Bluetooth devices and select "D20" from the list.
5. Once connected, the indicator light will typically flash blue slowly or turn solid blue.
6. The headphones will automatically reconnect to the last paired device when turned on, if the device's Bluetooth is active and within range.

5. OPERATING INSTRUCTIONS

5.1 Basic Controls

Function	Action
Power On/Off	Press and hold the multi-function button.
Play/Pause	Short press the multi-function button.
Volume Up	Short press the '+' button.
Volume Down	Short press the '-' button.
Next Track	Long press the '+' button.
Previous Track	Long press the '-' button.
Answer/End Call	Short press the multi-function button during a call.
Reject Call	Long press the multi-function button during an incoming call.

5.2 Wearing the Headphones

The Xmenha D20 headphones are designed with ear hooks for a secure fit, especially during physical activities.

1. Select the appropriate size of ear tips for a comfortable and snug fit.
2. Place the earbuds into your ears.
3. Gently loop the ear hooks over the top of your ears to secure the headphones in place.
4. Adjust the neckband for comfort.




Image 4: Usage Scenarios. This image demonstrates the versatility of the Xmenha D20 headphones for various sports and activities, highlighting their secure fit during movement.

6. MAINTENANCE

6.1 Cleaning

- Wipe the headphones with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or chemical sprays.
- Remove ear tips periodically and clean them with mild soap and water, then dry thoroughly before reattaching.

6.2 Storage

- Store the headphones in a cool, dry place away from direct sunlight.
- Avoid storing them with sharp objects that could cause damage.

6.3 Water Resistance (IPX4)

The Xmenha D20 headphones are rated IPX4, meaning they are resistant to splashing water from any direction. This makes them suitable for workouts and light rain. However, they are *not* designed for submersion in water or exposure to pressurized water jets. Do not use them while swimming or showering.

7. TROUBLESHOOTING

Problem	Possible Solution
Headphones won't turn on.	Ensure the headphones are fully charged.
Cannot pair with device.	<ul style="list-style-type: none">◦ Ensure headphones are in pairing mode (flashing red/blue).◦ Turn off and on Bluetooth on your device.◦ Move headphones closer to the device.◦ Forget/delete "D20" from your device's Bluetooth list and try pairing again.
No sound or low volume.	<ul style="list-style-type: none">◦ Increase volume on both headphones and your connected device.◦ Ensure headphones are properly connected to your device.◦ Check if the audio output on your device is set to the headphones.
Sound quality is poor.	<ul style="list-style-type: none">◦ Ensure there are no obstructions between the headphones and your device.◦ Move away from sources of interference (e.g., Wi-Fi routers, other Bluetooth devices).◦ Check if the ear tips provide a good seal in your ears.

8. SPECIFICATIONS

Immersive Sound Quality

13mm large-size dynamic driver powerful bass and stunning treble



Image 5: Immersive Sound Quality. This image details the audio technology, including an advanced chip, 13mm dynamic drivers for powerful bass and clear treble, and support for SBC & AAC audio codecs.

- **Model Name:** D20
- **Connectivity Technology:** Wireless (Bluetooth)
- **Bluetooth Version:** 5.3
- **Wireless Communication Technology:** Bluetooth
- **Form Factor:** In Ear with Ear Hooks
- **Noise Control:** Sound Isolation
- **Water Resistance Level:** IPX4 (Waterproof)
- **Audio Driver Type:** Dynamic Driver (13mm)
- **Control Method:** Remote (Integrated buttons)
- **Compatible Devices:** Smartphones, Laptops, Desktops, Tablets, Smart Speakers
- **Material:** Plastic
- **Item Weight:** 3.2 ounces
- **Product Dimensions:** 0.3 x 0.2 x 0.5 inches
- **Battery:** 1 Lithium Ion battery (included)
- **Manufacturer:** Shenzhen Xiangxing Digital Technology Co., Ltd.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact Xmenha customer service through the retailer where the product was purchased. Please have your product model (D20) and purchase details ready when contacting support.